



IntelliFlow™ RF2 Automatic and Manual Systems



For other languages of this service manual and additional product information, please scan the QR code above.



CONTENTS

SAFETY	4-8
Safety Precautions	7
Hazards/Safeguards	5-8
EU CONFORMITY	9
EU Declaration of Conformity	9
INTRODUCTION	11-25
System Components-Automatic	11
Control Panel-Automatic	12
Fluid Components-Automatic	13
Theory of Operation-Automatic	14
System Configuration-Automatic	16
System Components-Manual	17
Control Panel-Manual	18
Fluid Components-Manual	19
Theory of Operation-Manual	20
System Configuration-Manual	22
Product Introduction	23
Complete System Part Numbering	27
Technical Specifications	27
Process Configuration	28
INSTALLATION	32-56
Electrical	32
Pneumatics	33
Paint Materials	35
Air Cut-Off Kit (Manual Mode)	37
CCV Pulse Setup (Manual Mode)	42
External Air Connections	45
Auxiliary Signals	46
Disposal Information	52
RF2 Cloud Setup	53
OPERATION	57-95
Powering Up the System	57
Navigation Bar	52
Language Settings	59
Running the System	59

CONTENTS (cont.)

OPERATION (cont.)

Calibration	68
Manual Override/Local Fluid Control	69
Shutting Down the System	71
Administrator Functions	72
Setup	75
Back-Up/Restore	92
Diagnostics	94
Data Log/Reporting	96
Multi-Color Stack Light Functions	98

MAINTENANCE

100-123

Regular Maintenance Procedures and Recommendations	100
Top Level Part Numbers	101
Component View and Spare Parts	102

TROUBLESHOOTING

124-134

Alarm List	124
Troubleshooting-Festo VTEM Pressure regulator manifold	128
Troubleshooting-Festo VTUG Solenoid Manifold	132

APPENDIX

135-205

Fieldbus I/O	135
Schematics	150

MANUAL CHANGE SUMMARY

206

WARRANTY POLICY

208

SAFETY

SAFETY PRECAUTIONS

Before operating, maintaining or servicing any Carlisle system, read and understand all of the technical and safety literature for your Ransburg products. This manual contains information that is important for you to know and understand. This information relates to **USER SAFETY and PREVENTING EQUIPMENT PROBLEMS.**

To help you recognize this information, we use the following symbols. Please pay particular attention to these sections.

WARNING

A WARNING! states information to alert you to a situation that might cause serious injury if instructions are not followed.

CAUTION

A CAUTION! states information that tells how to prevent damage to equipment or how to avoid a situation that might cause minor injury.

NOTE

A NOTE is information which is relevant to the procedure in progress.

This manual lists standard specifications and service procedures. Minor differences can occur between this literature and your equipment. Differences in local or municipal codes, manufacturer or plant requirements, material delivery requirements, and more can make variations unpreventable. Compare this manual to your system installation drawings and other applicable Ransburg equipment manuals to find these differences.

Careful study and continued use of this manual will provide a better understanding of the equipment functions and procedures. This will result in improved operation, efficiency, and longer, trouble-free service with faster and easier troubleshooting. If you need the necessary manuals and safety literature for your specific Ransburg system, contact your local Ransburg representative or Ransburg directly.

WARNING


The user **MUST** read and be familiar with the Safety Section in this manual and the Ransburg safety literature therein identified.



This equipment is intended to be used by trained personnel **ONLY**.


This manual **MUST** be read and thoroughly understood by **ALL** personnel who operate, clean or maintain this equipment! Special care should be taken to ensure that the **WARNINGS** and safety requirements for operating and servicing the equipment are followed. The user should be aware of and adhere to **ALL** local building and fire codes and ordinances as well as **NFPA-33 AND EN 50176 SAFETY STANDARDS, LATEST EDITION**, or applicable country safety standards, prior to installing, operating, and/or servicing this equipment.




WARNING


The hazards shown on the following pages may occur during the normal use of this equipment.

AREA Tells where hazards may occur.	HAZARD Tells what the hazard is.	SAFEGUARDS Tells how to avoid the hazard.
<p>Spray Area</p> 	<p>Fire Hazard</p> <p>Improper or inadequate operation and maintenance procedures will cause a fire hazard.</p> <p>Protection against inadvertent arcing that is capable of causing fire or explosion is lost if any safety interlocks are disabled during operation.</p> <p>Frequent Power Supply or Controller shutdown indicates a problem in the system requiring correction.</p>	<p>Fire extinguishing equipment must be present in the spray area and tested periodically.</p> <p>Spray areas must be kept clean to prevent the accumulation of combustible residues.</p> <p>Smoking must never be allowed in the spray area.</p> <p>The high voltage supplied to the atomizer must be turned off prior to cleaning, flushing or maintenance.</p> <p>Spray booth ventilation must be kept at the rates required by NFPA-33, OSHA, country, and local codes. In addition, ventilation must be maintained during cleaning operations using flammable or combustible solvents.</p> <p>Electrostatic arcing must be prevented. Safe sparking distance must be maintained between the parts being coated and the applicator. A distance of 1 inch for every 10KV of output voltage is required at all times.</p> <p>Test only in areas free of combustible material. Testing may require high voltage to be on, but only as instructed.</p> <p>Non-factory replacement parts or unauthorized equipment modifications may cause fire or injury. If used, the key switch bypass is intended for use only during setup operations. Production should never be done with safety interlocks disabled.</p> <p>The paint process and equipment should be set up and operated in accordance with NFPA-33, NEC, OSHA, local, country, and European Health and Safety Norms.</p>

<p>AREA</p> <p>Tells where hazards may occur.</p>	<p>HAZARD</p> <p>Tells what the hazard is.</p>	<p>SAFEGUARDS</p> <p>Tells how to avoid the hazard.</p>
<p>Spray Area</p> 	<p>Explosion Hazard</p> <p>Improper or inadequate operation and maintenance procedures will cause a fire hazard.</p> <p>Protection against inadvertent arcing that is capable of causing fire or explosion is lost if any safety interlocks are disabled during operation.</p> <p>Frequent Power Supply or Controller shutdown indicates a problem in the system requiring correction.</p>	<p>Electrostatic arcing must be prevented. Safe sparking distance must be maintained between the parts being coated and the applicator. A distance of 1 inch for every 10KV of output voltage is required at all times.</p> <p>Unless specifically approved for use in hazardous locations, all electrical equipment must be located outside Class I or II, Division 1 or 2 hazardous areas, in accordance with NFPA-33.</p> <p>Test only in areas free of flammable or combustible materials.</p> <p>The current overload sensitivity (if equipped) MUST be set as described in the corresponding section of the equipment manual. Protection against inadvertent arcing that is capable of causing fire or explosion is lost if the current overload sensitivity is not properly set. Frequent power supply shutdown indicates a problem in the system which requires correction.</p> <p>Always turn the control panel power off prior to flushing, cleaning, or working on spray system equipment.</p> <p>Before turning high voltage on, make sure no objects are within the safe sparking distance.</p> <p>Make sure that the control panel is interlocked with the ventilation system and conveyor in accordance with NFPA-33, EN 50176.</p> <p>Have fire extinguishing equipment readily available and tested periodically.</p>
<p>General Use and Maintenance</p> 	<p>Improper operation or maintenance may create a hazard.</p> <p>Personnel must be properly trained in the use of this equipment.</p>	<p>Personnel must be given training in accordance with the requirements of NFPA-33, EN 60079-0.</p> <p>Instructions and safety precautions must be read and understood prior to using this equipment.</p> <p>Comply with appropriate local, state, and national codes governing ventilation, fire protection, operation maintenance, and housekeeping. Reference OSHA, NFPA-33, EN Norms and your insurance company requirements.</p>

<p>AREA</p> <p>Tells where hazards may occur.</p>	<p>HAZARD</p> <p>Tells what the hazard is.</p>	<p>SAFEGUARDS</p> <p>Tells how to avoid the hazard.</p>
<p>Spray Area High Voltage Equipment</p> 	<p>Electrical Discharge</p> <p>There is a high voltage device that can induce an electrical charge on ungrounded objects which is capable of igniting coating materials.</p> <p>Inadequate grounding will cause a spark hazard. A spark can ignite many coating materials and cause a fire or explosion.</p>	<p>Parts being sprayed and operators in the spray area must be properly grounded.</p> <p>Parts being sprayed must be supported on conveyors or hangers that are properly grounded. The resistance between the part and earth ground must not exceed 1 meg ohm. (Refer to NFPA-33.)</p> <p>Operators must be grounded. Rubber soled insulating shoes should not be worn. Grounding straps on wrists or legs may be used to assure adequate ground contact.</p> <p>Operators must not be wearing or carrying any ungrounded metal objects.</p> <p>When using an electrostatic handgun, operators must assure contact with the handle of the applicator via conductive gloves or gloves with the palm section cut out.</p> <p>NOTE: REFER TO NFPA-33 OR SPECIFIC COUNTRY SAFETY CODES REGARDING PROPER OPERATOR GROUNDING.</p> <p>All electrically conductive objects in the spray area, with the exception of those objects required by the process to be at high voltage, must be grounded. Grounded conductive flooring must be provided in the spray area.</p> <p>Always turn off the power supply prior to flushing, cleaning, or working on spray system equipment.</p> <p>Unless specifically approved for use in hazardous locations, all electrical equipment must be located outside Class I or II, Division 1 or 2 hazardous areas, in accordance with NFPA-33.</p> <p>Avoid installing an applicator into a fluid system where the solvent supply is ungrounded.</p> <p>Do not touch the applicator electrode while it is energized.</p>

<p>AREA</p> <p>Tells where hazards may occur.</p>	<p>HAZARD</p> <p>Tells what the hazard is.</p>	<p>SAFEGUARDS</p> <p>Tells how to avoid the hazard.</p>
<p>Electrical Equipment</p> 	<p>Electrical Discharge</p> <p>High voltage equipment is utilized in the process. Arcing in the vicinity of flammable or combustible materials may occur. Personnel are exposed to high voltage during operation and maintenance.</p> <p>Protection against inadvertent arcing that may cause a fire or explosion is lost if safety circuits are disabled during operation.</p> <p>Frequent power supply shutdown indicates a problem in the system which requires correction.</p> <p>An electrical arc can ignite coating materials and cause a fire or explosion.</p>	<p>Unless specifically approved for use in hazardous locations, the power supply, control cabinet, and all other electrical equipment must be located outside Class I or II, Division 1 and 2 hazardous areas in accordance with NFPA-33 and EN 50176.</p> <p>Turn the power supply OFF before working on the equipment.</p> <p>Test only in areas free of flammable or combustible material.</p> <p>Testing may require high voltage to be on, but only as instructed.</p> <p>Production should never be done with the safety circuits disabled.</p> <p>Before turning the high voltage on, make sure no objects are within the sparking distance.</p>
<p>Toxic Substances</p> 	<p>Chemical Hazard</p> <p>Certain materials may be harmful if inhaled, or if there is contact with the skin.</p>	<p>Follow the requirements of the Safety Data Sheet supplied by coating material manufacturer.</p> <p>Adequate exhaust must be provided to keep the air free of accumulations of toxic materials.</p> <p>Use a mask or respirator whenever there is a chance of inhaling sprayed materials. The mask must be compatible with the material being sprayed and its concentration. Equipment must be as prescribed by an industrial hygienist or safety expert, and be NIOSH approved.</p>
<p>Spray Area</p> 	<p>Explosion Hazard — Incompatible Materials</p> <p>Halogenated hydrocarbon solvents for example: methylene chloride and 1,1,1, - Trichloroethane are not chemically compatible with the aluminum that might be used in many system components.</p> <p>The chemical reaction caused by these solvents reacting with aluminum can become violent and lead to an equipment explosion.</p>	<p>Spray applicators require that aluminum inlet fittings be replaced with stainless steel.</p> <p>Aluminum is widely used in other spray application equipment - such as material pumps, regulators, triggering valves, etc. Halogenated hydrocarbon solvents must never be used with aluminum equipment during spraying, flushing, or cleaning. Read the label or data sheet for the material you intend to spray. If in doubt as to whether or not a coating or cleaning material is compatible, contact your coating supplier. Any other type of solvent may be used with aluminum equipment.</p>

Product Description / Object of Declaration:	IntelliFlow RF2	
This Product is designed for use with:	Solvent-based and waterborne materials	
Suitable for use in hazardous area:		
Protection Level:	Not applicable	
Notified body details and role:	Intertek USA 7250 Hudson Blvd N STE 100, St Paul, MN 55128, USA	
This Declaration of Conformity / Incorporation is issued under the sole responsibility of the manufacturer:	Carlisle Fluid Technologies Inc 7166 4th St. N. Oakdale, MN 55128 USA	
Representative authorised to compile the technical file	Sales and Marketing Director. CFT UK Ltd 1 Avenue de Lattre de Tassigny 94736 Nogent, Cedex. France	
EU Declaration of Conformity		
CE		
This Declaration of Conformity / Incorporation is issued under the sole responsibility of the manufacturer:		
Machinery Directive 2006/42/EC EMC Directive 2014/30/EU RoHS Directive 2011/65/EU by complying with the following statutory documents and harmonised standards: EN ISO 12100:2010 Safety of Machinery - General Principles for Design EN 60204-1:2006 Safety of Machinery - Electrical Equipment of Machines - General requirements. BS EN 61000-6-2:2019 Electromagnetic Compatibility Generic Standards Immunity for residential/commercial/light industry environments EN 63000: 2018 Technical documentation for the assessment according to REACH BS EN 61000-6-4:2019 Electromagnetic Compatibility (EMC) - Generic standards - Emission standard for industrial environments		
Providing all conditions of safe use / installation stated within the product manuals have been complied with and also installed in accordance with any applicable local codes of practice.		
Signed for and on behalf of Carlisle Fluid Technologies:		F. A. Sutter Executive President: Engineering and Operations, Scottsdale, AZ, 85254. USA 1-Dec-21
X-XXXX-X		

Page intentionally left blank

INTRODUCTION—AUTOMATIC

The IntelliFlow RF2 (or RF2) is a standalone system designed to control material delivery from a supply source (pressure pot or circulation system) to an applicator. It accurately controls material mixture ratio and/or material flow in a coating process, which can include single component, 2k, or 3k materials, and handles flushing and loading of the materials.

The RF2 can include up to four fluid channels (for additional details on Channels, refer to page 14 of this manual) which can be arranged in many ways. The available channels can be configured into 1, 2, or 3 component mixes (guns), using any combination of these mixes to utilize all the available channels. The RF2 can be configured to include anywhere from 32 to 128 solenoids, all of which are fully addressable to be used in various ways to control the process (examples include applicator triggers, dump, solvent flush, color-valve selects, etc.).

The channels and fluid mixes can be grouped into up to two stations with individual sets of color stacks, which can be controlled completely independently of one another.


The RF2 can be operated locally, from its included 15-inch touch screen, or it can be easily integrated into an automated process by use of discrete signals for simple systems or by multiple different industrial fieldbus protocols for more advanced control.

The RF2 can be connected to the cloud, allowing access to Carlisle Fluid Technologies technical experts for the purpose of remote troubleshooting. This access may also be granted to local plant personnel.

Data gathered by the RF2, including alarms and flow-totalization data is stored in an onboard SD card, and can be accessed via FTP, or other methods.

SYSTEM COMPONENTS

1. Control panel
2. Valve stacks
3. Fluid control module
4. Mixing module



CONTROL PANEL


External Components

1. Status light
2. Main power entry
3. Main power disconnect switch
4. Panel opening latch
5. Emergency stop button
6. HMI



Internal Components


1. Safety relay
2. Electronic circuit protector
3. Local ethernet switch
4. CPU/Controller
5. DC Power supply
6. Main power circuit breaker
7. Line filter
8. Connection to status light
9. Main power disconnect switch connector
10. I/O block and additional terminals
11. Terminal blocks
12. Connection to HMI and emergency stop button



FLUID COMPONENTS


Valve Stack

1. Fluid pressure regulator (Optional)
2. Connection to fluid panel
3. Fluid valves
4. Connection to solenoids
5. Air push valve
6. Air regulator
7. Solvent flush valve
8. Check valve




Flow Control Module

1. Connection to valve stack
2. MVR (Material Valve Regulator) with air gauge
3. Flow Meter
4. Connection to control panel
5. Calibration block
6. Connection to mix module



Mix Manifold


1. Connection to gun
2. Static mix tube
3. Mix block
4. Solvent flush valve
5. Connections to flow control modules




THEORY OF OPERATION

The RF2's operating principle is as follows:


1. The material is fed through the hoses towards the material valves in each stack.
2. If multiple materials of the same type (Resin, Hardener, or Reducer) are being used, each valve will control its flow separately.




3. The material valves are normally closed. When material flow is needed, the system controller opens the valve via the solenoid addressed to it.



4. The material flows from the valves to the flow control module.
5. The flow meter sends a signal to the control panel indicating the material's current flow rate.
6. The control panel determines if the flow rate is within specification or not.
7. Through the MVR, the control panel increases or decreases the flow rate of material passing through, to reach the desired value.



8. The material proceeds to the mix manifold where it combines with the second and/or third material.



9. The mixed material then flows to the gun's inlet connection.

RF2 AUTOMATIC SYSTEM CONFIGURATION

 **Air hosing**


 **Solvent hosing**

 **Material A lines**

 **Material B lines**

 **Mixed material lines**

- | | |
|----------------------------------|---------------------------|
| 1. Air manifold | 5. Material B valve stack |
| 2. Valve stack solenoid manifold | 6. Material A fluid panel |
| 3. Pressure solenoid manifold | 7. Material B fluid panel |
| 4. Material A valve stack | 8. Mix chamber |



INTRODUCTION—MANUAL

The IntelliFlow RF2 (or RF2) is a standalone system designed to control material delivery from a supply source (pressure pot or circulation system) to an applicator. It accurately controls material mixture ratio and/or material flow in a coating process, which can include single component, 2k, or 3k materials, and handles flushing and loading of the materials.

The RF2 can include up to four fluid channels (for additional details on Channels, refer to page 20 of this manual) which can be arranged in many ways. The available channels can be configured into 1, 2, or 3 component mixes (guns), using any combination of these mixes to utilize all the available channels. The RF2 can be configured to include anywhere from 32 to 128 solenoids, all of which are fully addressable to be used in various ways to control the process (examples include applicator triggers, dump, solvent flush, color-valve selects, etc.).

The channels and fluid mixes can be grouped into up to two stations with individual sets of color stacks, which can be controlled completely independently of one another.


The RF2 can be operated locally, from its included 15-inch touch screen, or it can be easily integrated into an automated process by use of discrete signals for simple systems, or by multiple different industrial fieldbus protocols for more advanced control.

The RF2 can be connected to the cloud, allowing access to Carlisle Fluid Technologies technical experts for the purpose of remote troubleshooting. This access may also be granted to local plant personnel.

Data gathered by the RF2, including alarms and flow-totalization data is stored in an onboard SD card, and can be accessed via FTP, or other methods.

SYSTEM COMPONENTS

1. Control panel
2. Valve stacks
3. Fluid control module
4. Mixing module



CONTROL PANEL


External Components

1. Status light
2. Main power entry
3. Main power disconnect switch
4. Panel opening latch
5. Emergency stop button
6. HMI



Internal Components


1. Safety relay
2. Electronic circuit protector
3. Local ethernet switch
4. CPU/Controller
5. DC Power supply
6. Main power circuit breaker
7. Line filter
8. Connection to status light
9. Main power disconnect switch connector
10. I/O block and additional terminals
11. Terminal blocks
12. Connection to HMI and emergency stop button



FLUID COMPONENTS


Valve Stack

1. Connection to fluid panel
2. Fluid valves
3. Connection to solenoids
4. Air push valve
5. Air regulator
6. Solvent flush valve



Pulse Valves

1. Connection to valve stack
2. Pulse valve
3. Flow meter
4. Connection to control panel
5. Calibration block
6. Connection to mix module



Component B & C



Component A


THEORY OF OPERATION

The RF2's operating principle is as follows:


In RF2 manual gun configurations with a pulse-valve channel type for the B and/or C components, fluid from the hardener or reducer channels is "dosed" into the mixture in order to accurately control the material ratio. The rate of pulsing and length of each pulse of fluid is regulated in order to achieve the desired ratio.

For optimal performance, the pulse-valve will operate at 3Hz rate of fire, and all adjustments by the controller will be through varying the length of each pulse. To achieve this, adjust the pulse-valve so the flow through the valve when it is open is at 3Hz rate. Further instructions for adjusting the pulse-valve are


1. The material is fed through the hoses towards the material valves in each stack.
2. If multiple materials of the same type (Resin, Hardener, or Reducer) are used, each valve will control its flow separately.




3. The material valves are normally closed. When material flow is needed, the system controller opens the valve via the solenoid addressed to it.



4. The material flows from the valve to the flow meter.
5. The flow meter sends a signal to the control panel indicating the material's current flow rate.
6. The control panel determines if the flow rate is within specification or not.
7. Through the pulse valve, the control panel increases or decreases the flow rate of material passing through, to reach the desired value.



8. The material proceeds to the mix manifold where it combines with the second and/or third material.



9. The mixed material then flows to the gun's inlet connection.
10. If needed, the system can flush only mixed material through the mix manifold, or through the valve stack for color changes.

RF2 MANUAL SYSTEM CONFIGURATION

 **Air hosing**


 **Solvent hosing**

 **Material A lines**

 **Material B lines**

 **Mixed material lines**

- | | |
|----------------------------------|---------------------------|
| 1. Air manifold | 5. Material B valve stack |
| 2. Valve stack solenoid manifold | 6. Material A fluid panel |
| 3. Pressure solenoid manifold | 7. Material B fluid panel |
| 4. Material A valve stack | 8. Mix chamber |



INTRODUCTION

The RF2 is a versatile system that can be configured in many ways. This section details the terminology of the various components that make up the system and process.

It should be noted, that although the following is relatively complex, the vast majority of RF2 units will be factory-configured based on the fluid components that were purchased, and will only require slight modifications, if any, before operating the system.

TERMINOLOGY

In demonstrating the ways to configure and operate the RF2, the following terminology will be used throughout the manual.

Outputs

Outputs are either (1) discrete signals that are assigned to pneumatic solenoids (up to 128 can be controlled by the RF2 via four separate manifolds) or (2) hardwired digital signals.

Outputs can be configured as several types:

- Color Valve (CCV)—used on a material stack to select different materials. Each CCV output has a number associated with it for the valve number on the color stack.
- Dump—output is used as a dump, which operates much like a trigger. The system expects flow when this is active.
- Flow Control Pulse—used as a flow control method for manual configurations that use a pulsing channel. Assigned to a specific channel.
- Flow Test—used by each channel as an automated calibration port.
- FL. OVRD. (Fluid Override)—used when a DR-1 or HGB air-piloted fluid regulator is used as the flow control device. Fluid override port forces the unit open for cleaning. The flow control functionality is stopped.
- Material Select—used on a mix manifold to allow or disallow a material channel from entering the mixed section.
- Pass Through—allows the user to assign a solenoid to a user-defined input, basically giving direct control of the solenoid to external processes.
- Sequence—output used in flush, load, and other fluid sequences.
- Standard—output is active during a sequence but has no particular effect on flow control (examples are solvent and air valves).
- Trigger—starts an applicator
- Unused

Functions

Functions of different types are assigned to the programmed outputs and operate on them in different ways. Functions are called during fluid sequences. Types are:

- Unused
- Simple—output assigned to the function is active while the function is active during a fluid sequence.
- Latch—when the function is activated during a fluid sequence, the output assigned to the function turns on and holds on until an unlatch command is given.
- Unlatch—opposite of latch example: when the function is activated during a fluid sequence, the output assigned to the process turns off and stays off.
- Chop—this function contains two outputs, and when active, alternates between the two. This is typically used with stack solvent and air solenoids.
- Pulse—the assigned output turns on for a set period (programmable) when the function becomes active.
- Wait—(future feature)—the function causes the fluid sequence to pause until the assigned input is true.

Functions can be made available to any of the available fluid sequences.

Sequences

A sequence consists of twelve steps with programmable times per step. During each step, specific functions can be activated or deactivated, causing their outputs to react according to the function setup.

Channel

A channel is a single flow-control path for fluid. Channels can be grouped together to build a gun or mixer. The RF2 controller can handle up to four channels.

Channels have multiple possible configurations – options include:

- Flow Control Type
 - MVR—the channel uses a 0-100psi pressure pilot signal to control an MVR (Material Volume Regulator) to control flow.
 - DR1—the channel uses a 0-100psi pressure pilot signal to control a DR1 pressure regulator to actuate flow.
 - Gear Pump (Future)—the channel uses a gear-pump to actuate flow.
 - Pulse—for manual slave channels only—the channel uses a pulsing valve to regulate the ratio of the mixture—note in manual applications, flow control is carried out by the handgun.
 - Feedback Only (Future)—for manual master channels only—no flow regulator is used.
- Feedback Type
 - Square Wave—a flow meter that produces a quadrature signal is used for reading flow.
- Inlet Pressure Regulation
 - Enabled or disabled to control the fluid pressure to the inlet of the flow control device.

Gun/Mixer

A gun or mix is a combination of 1-3 fluid channels. Depending on ratio setpoints, the flow command of the gun is divided into flow rates for the assigned channels, to accurately mix the material.

Configurations for gun/mixers are:

- Fluid Type
 - Unused, 1K, 2K, 3K.
- Control Type
 - Automatic—an automatic gun is used triggered by an external request of some type. Flow and ratio are controlled.
 - Manual Pulse—a manual gun is controlled using pulse channels to modulate the secondary materials. Only ratio is controlled.

The RF2 can have up to four gun / mixers configured. Note that these can be built out of only four channels, and each channel can only be assigned to one mixer. There can only be two 2k mixers, but there can be four 1k mixers.

Station


A station is a collection of guns/mixers—up to four, which are built from their assigned channels, and several outputs and fluid stacks. The RF2 can control up to two stations with independent color stacks to make it a two-applicator controller.

Configuration of Stations and Guns must be built out of the components available—four fluid channels and up to 128 solenoid outputs.

Page intentionally left blank

COMPLETE SYSTEM PART NUMBERING

RF2 - # # # - # # - # # - #



TECHNICAL SPECIFICATIONS

ITEM	DETAILS
Dimensions	Main control console: 24"x 24"x 10" Pneumatic interface panel: 24"x 12"x 9"
Weight	150-250 lb (Depending on added components)
Operating temperature	40°F to 122°F (5-50°C) inside enclosures 100°F (38°C) maximum ambient temperature
Operating humidity	5% to 85% RH (non condensing)
Environmental conditions	Indoor use, pollution degree 2, installation category II
Air input pressure	75 to 105 PSI (5.17-7.24 BAR)
Air filtration	5 micron or better, -40°F (-40°C) dew point
Ratio tolerance	< = 1% (Ratio accuracy can be affected by process factors such as hardware configuration, extremely low flow rates, etc.)
Mixing ratio range	1:1 to 50:1
Power input	85-264 VAC 0.8A @ 115 VAC, 0.4A @ 230 VAC
LCD display	15" True Glass Capacitive Multitouch display, 1366x768 pixels, HD
Flow capacity	<10 ml/min to 3500 ml/min per channel (depending on material and flow meter limitations)
Viscosity range	<1 cp to >500 cp (depending on flow meter & hardware selected)
Fluid filtration	100 mesh or better (150 micron)
I/O update time	5 ms (200 times/s), Process scan at 10 ms
Recipe tables	250 per station (2 stations available)
Wetted parts	300 & 400 series stainless steel, PTFE, perfluoroelastomer, UHMW polyethylene

PROCESS CONFIGURATION

In addition to the multiple configurations of the RF2's physical hardware, the flow control processes can vary greatly from one application to another. The RF2 software can be configured through global setup parameters, which affect system behavior independently of the material being used, and through "recipe" parameters, which can be modified per the material in use.

Recipes

A recipe is a set of material-specific parameters used to govern system operations. Each Station (see above) can store up to 250 recipes. The parameters for each recipe are organized into three groups:

Materials—parameters that apply to the system as a whole

- Channel A (Resin)—CCV Number—the color valve assignment for the resin stack for the selected recipe.
- Channel B (Catalyst)—CCV Number—the color valve assignment for the catalyst stack for the selected recipe. Available only for 2 or 3 component materials.
- Channel C (Reducer)—CCV Number—the color valve assignment for the reducer stack for the selected recipe. Available only for 3 component materials.
- Pot-Life Time—the amount of time, in minutes, that a mixed material can remain in the line before it must be flushed from the system. This dictates the pot-life warning alarm. Setting this to zero disables the feature.
- Ratio (A, B, C)—the ratio for 2 or 3 component mixers. A: B (resin: catalyst) are given in parts—Channel C is given in percentage of total flow.
- Sequence Assignments:
 - Flush A Only—programmable sequence number that is run when a "purge A only" command is given. This occurs when a new material is loaded that uses the same catalyst and reducer.
 - Flush All—programmable sequence number that is run when a "purge all" command is given. This occurs when a new material is loaded, requiring either a change in catalyst or reducer.
 - Load—programmable sequence number that is run when a "load" command is given. This occurs when a new material is loaded, after any necessary purges have been completed.

Gun/Mix—parameters that apply to the gun or mixers that are used by the station selected

- Trigger-On Delay—when a trigger occurs, the applicator trigger solenoid opens this amount of time prior to the actuation of flow.
- Trigger-Off Delay—when a trigger stops, the applicator trigger solenoid will remain on for this amount of time after flow has been shut down.
- MVR Hold—for channels that use an MVR type controller, the MVR will hold at its previous value after a "trigger-off" event for this amount of time, before returning to the "minimum control pressure" value.
- Minimum/Maximum Flow—these parameters scale an optional analog (0-10V or 4/20mA) flow command between these values. These parameters are also used to scale the gauges on the main status screen showing the flow feedback.

- Default Flow—if no flow command is given by either fieldbus signal or analog input, this flow will be used.
- Sequence High Flow Rate—optional higher flow rate for when “Max Flow” system output is active.
- Flow Rate Tolerance—the percentage error in flow rate for the gun/mixer or any of its channels that is tolerable.
- Flow Rate Tolerance Time—the amount of time that the flow rate must be out of tolerance before a flow rate tolerance alarm will occur.
- Ratio Tolerance—the percentage error in mixture ratio that is tolerable.
- Ratio Tolerance Volume—the amount of volume that the ratio is measured over before producing a ratio alarm.

Channel—parameters that apply to the individual fluid channels used by the mixer selected

- Flow Calibration:
 - For quadrature flow meters—the number of pulses per liter. There are four pulses per flow-meter cycle, so if a flow meter is rated for 14000 cycles / liter, the pulses per liter = 56000.
 - For analog flow meters—given in a simple scaling (In High, In Low, Scaled High, Scaled Low)

NOTE: Flow calibration can be done by an automated process, in which a measured output of material can be inputted and compared with the counts during a calibration cycle to fine-tune the calibration for different materials. See more about flow calibration below.
- Flow Control PID parameters:
 - Kp/Ki—the P and I components of the PID which govern flow control. While these may need to be adjusted slightly based on different materials and nominal flow rates, good numbers to start with are 2000 and 150.
 - C-band—given in cc/min—if the flow rate error is greater than this, than the Flow control PID Kp value will be multiplied to give a faster response.
 - I-Band—given in cc/min—if the flow rate error is greater than this, the Ki value will be multiplied to give a faster response.
 - For C-band and I-band, a setting of 5-6 will suffice for higher flow rate channels. For lower flow rate (typically catalyst) channels, a lower setting may be used. If too low of a setting is used, it may cause oscillations in flow rate and unstable operation. A zero setting disables this feature.
- Minimum Control Pressure—this is the lowest pressure that an MVR pilot valve will operate. This should be set at slightly below the “cracking pressure” of the MVR to give a faster response. Typically with weep-less MVRs, a value of 10 psi is used. Weeping MVRs use a value closer to 20 psi.
- MVR Enable—this feature, available only when an MVR is used for the flow control of a channel, allows the channel’s color valves to shut off when no trigger exists.
- Inlet Pressure Control—if inlet pressure regulation is used, this is the pressure that the channel will operate. Note: In gear-pump systems, this value represents the “delta” above or below the outlet pressure of the pump.

Global parameters

Global parameters affect operation independently of the material(s) being used. These are organized into several groups:

Gun/channel parameters

- Mixed Volume—given in cc or mL, the volume of tubing between the mix block and the applicator. This is used to track material pot-life time.
- Blowoff Time—for manual guns only, this time elapses as the gun trigger is detected (through installed air-flow switches utilizing the Manual Gun/Flux Box interface kit). If the set time elapses before flow is detected, a “No Master Pulses” alarm will occur.
- Default Flow Meter Calibration—PPL or Analog scaling values – in the event a recipe is loaded that has not been appropriately defined, these values will be used in calculation of actual flow rate.
- Inlet/Outlet Pressure Scaling—used to calculate inlet and outlet pressures from pressure sensors. Used only with gear-pump systems.
- Reverse Flow Volume—the amount of volume (cc or mL) that is allowed before a fault is generated—this is used to protect against stuck check valves that might allow material to feed backward in circulation lines.

Alarm masking

- This allows various alarms to be used as warning only or “spray-shutdown” alarms that halt the system.

Fluid system setup

- Outputs—defines the description, type, and interlocks for each output in the fluid system. See more about configuring the fluid system below.
- Functions—defines the description, function type, outputs acted upon. Sequences which use the function are defined here. See more about configuring the fluid system below.
- Sequence—defines the description, whether the sequence is used or not in the system, and global times for “chop air” and “chop solvent.” See more about configuring the fluid system below.
- Sequences—defines timing and which functions are active per step in each fluid sequence.

Display preferences

- “Show Summary Page On Startup”—when enabled, shows a configuration summary page for the system when powered up.
- Flow Totals Units—Liters or Gallons—units for material total display.
- Pressure Unit—PSI or Bar—units for pressure display.
- Default Max-Y Values for Flow Trend Displays—when a trend display is open, it will revert to this value for scaling the flow feedback.
- Language: Language shown on the display.

Note some items that are defined by user entry will not be translated, but these values are editable by the user.

Security

The system administrator has access to settings not available to other users. This includes the ability to add, delete, or modify users, as well as the ability to assign access to various features to different user groups (levels 1-10).

Functions that can be access-controlled are:

- Edit Recipe: User can enter the recipe edit menu and make changes.
- Copy Recipe: User can copy recipe parameters from one location to others.
- Setup Menu: User can access the global setup menu (besides administrator only functions).
- Edit Fluid System: User can access fluid system configuration pages (Sequence Definition, Function Definition, Output Setup).
- Edit Fluid Sequences: User can modify sequence timing for sequences that have been defined.
- Edit Active Flow Settings: User can modify the active parameters (recipe driven) pertaining to flow.
- Edit Active Mix/Gun Settings: User can modify the active parameters (recipe driven) pertaining to a mixer or gun.
- Edit Active Inlet: User can modify the active parameters (recipe driven) pertaining to inlet pressure.
- Calibrate Flow Meter: User can calibrate the flow meter.
- Hardware Browser: User can access the "hardware browser" page, which gives access via a webpage for various internal system components.
- Local Control: Allows individual functions and solenoid valves to be controlled manually.

INSTALLATION

Before operating the RF2, Make sure all the below installation steps are complete. Schematics and further information are provided separately from this manual.

WARNING

This equipment is intended to be installed outside of classified hazardous areas. While there are accessories for this equipment, sold separately, which will allow devices such as flow meters to be installed within the hazardous zone, this should only be done following the instructions that are provided with those accessories.


ELECTRICAL

The RF2 can accept either 120VAC or 240VAC as a power source. Its internal 24VDC power supply automatically detects the input voltage and produces control power accordingly.

Main power entry to the cabinet is located at the top right-hand side of the cabinet. A 1/2" hole is pre-drilled in the enclosure to accept a conduit or cord-grip, etc.

Process

1. Locate the main power entry in the upper right section of the cabinet.
2. Using a plug, insert a wire with minimum 16 and maximum 10 gauge into the slot.
3. Locate the disconnect switch connector inside of the control panel.
4. Using the wire, connect the L1 and N lines to the top lugs opposite their secondary connections.
5. Connect ground wire to the ground block in the cabinet.



NOTE

Any conductive parts within 2.5m of this equipment (ladders, rails, fences, etc.) shall be bonded appropriately to ground.

PNEUMATICS


For convenience, all necessary air input connections are centralized in a single manifold, so that incoming air pressure can be managed in one place.

Always use clean, dry air to operate the RF2.

The maximum air input pressure is 105 PSI/7 BAR.


Pneumatic Connections

1. Locate the air manifold inlet connection at the top right corner of the system chassis.
2. Attach a 3/8" main air line with 1/4" NPS swivel connection to the main air inlet.





The following steps may have been completed by the factory before shipment.

3. On the opposite side of the air inlet, locate the manifold fittings for the interconnected air tubing.
4. Connect the manifold to each destination:
 - a. Resin and catalyst solenoid manifold.
 - b. Flow & pressure solenoid manifold.
 - c. Resin air flush valve.
 - d. Depending on your gun type, the gun's air regulator.





Resin and Catalyst Solenoid Manifold and Valve Stacks

5. Locate the solenoid manifold on the back left side of the system. This manifold houses all the air outputs to the valve stacks for the three materials.
6. Using the desired mapping, connect the manifold outputs (e) to each resin/catalyst valve (f).



Flow and Pressure Solenoid Manifold

7. Locate the solenoid manifold on the back right side of the system. This manifold houses all the air outputs for the fluid regulators and MVRs.
8. Using the desired mapping, connect the manifold outputs (g) to each material pressure valve (h).
9. Using the desired mapping, connect the manifold outputs (g) to each MVR (i).



PAINT MATERIALS


Your system may include up to three valve stacks for three different channels. The process to connect each is the same; repeat the steps below as needed. The number of valves each stack will have depends on your application and needs.

Paint Material Connections

1. Locate the valve stack you want to connect.

Either side of the system can have two different stacks with one above the other.


One stack configuration



Two stack configuration





2. Locate each of the material input connections on each valve on the stack (a).
3. Connect your material supply to the material input connection according to your desired mapping. Be careful not to mix different kinds of materials into the same stack. Each material (Resin, Catalyst and Reducer) must have his own.
4. Connect your solvent supply to the input valve below the stack (b).





5. Locate the fluid pressure regulator on the top of the stack.
6. Connect the regulator (c) to the MVR (d) in the fluid panel.
7. Depending on your configuration, connect the flow meter (e) below the MVR to the calibration block (f). If not using a calibration block, skip this step and connect the flow meter to the mixing block (g) directly.
8. If you are using a calibration block, connect it to the mix block (g).
9. Plug your gun's material input to the mixing tube's output connection (h).



INSTALLATION OF AIR CUT OFF KIT

The air cut off (ACO) kit is installed when the RF2 system is to be used in manual mode. The ACO kit can be used in conjunction with a gun flush box or on its own. The functions of the ACO kit are (1) to control air flow to prevent solvent atomization when using the flush box and (2) to sense air flow through the gun and send a trigger signal to the controller to enable material flow.

The air cut off kit is capable of controlling the air flow for two guns. The first set of connections, labeled with a 1 on the ACO box, is for gun one. The second set, labeled 2, is for gun two. Installing the second set of connections is unnecessary if only using one gun.

The box consists of three main components:

1. Air cut off valves: disable air flow to the guns when flushing them.
2. Flow switches: used to sense when the operator has opened the spray applicator. The trigger signal is fed to the system controller to enable material flow.
3. Gun-in-box (GIB) pressure switches: used in conjunction with the flush box. They send a signal to the controller when the flush box is closed and the gun is ready for flushing.

Possible Configurations for Air Cut Off Kit

- 310-3905-S0 (for one gun at standard air flowrate)
- 310-3905-L0 (for one gun at low-volume air flowrate)
- 310-3905-LL (for two guns at low-volume air flowrate)
- 310-3905-SS (for two gun at standard air flowrate)
- 310-3905-SL (for two gun, one at standard and one at low-volume air flowrate)

Parts Included


1. Air cut off box
2. Air cut off valves and associated fittings
3. 10" of 5/32" pneumatic tubing per gun
4. 10 m of M12 cable

ACO Connections

- a. GIB1 (Gun-in-box pressure switch for gun one, 5/32" or 4 mm tube)
- b. GIB2 (Gun-in-box pressure switch for gun two, 5/32" or 4 mm tube)
- c. M12 cable to controller
- d. ACO valve signal gun 1 (5/32" or 4 mm tube)
- e. ACO valve signal gun 2 (5/32" or 4 mm tube)
- f. Atomization air connection to gun 1 (1/4" NPS male)
- g. Atomization air connection to gun 2 (1/4" NPS male)
- h. Air supply input for gun 1 (1/4" NPS male)
- i. Air supply input for gun 2 (1/4" NPS male)

WARNING

Installation should be performed by a qualified electrician.
Improper installation could create a spark,
resulting in fire or explosion.




ACO Kit Installation



1. Mount the ACO box near the RF2 controller in a non-hazardous location.
2. Next, mount the solenoid valves to the air cut off box, as shown.
3. Route 5/32" pneumatic tubing from the air cut off valve (d and e) to port 10 (trigger g1) and port 11 (trigger g2) on the RF2 solenoid outputs.
4. Connect the air supply inlet to the air supply inputs for gun one and/ gun two (h and i).
5. Connect the atomized air to the atomization air connection for gun 1 and/or gun 2 (f and g). The air supplied to the air supply input for gun one (h) will be output in the atomization air connection to gun one (f).
6. Route the M12 cable from the M12 cable connection (c) and into the RF2 enclosure either (1) through an available strain relief or (2) by replacing the hole plug with the strain relief included with the RF2 controller. See the next page for terminal connections.

If used with a gun flush box:

7. Route 5/32" tubing from GIB 1 and 2 (a and b) to each respective gun flush box for each gun.




Once the M12 cable from the air cut off box is in the enclosure, connect it to the terminals indicated below.




Verify the M12 cable from air cut off box to RF2 connections in the table below.

ITEM	WIRE COLOR	SIGNAL	PLC and TERMINAL BLOCK-LANDING LOCATION
a	BROWN	24VDC	TERMINAL BLOCK 1141
b	BLUE	GUN-IN-BOX, GUN 1	SLOT 1, PIN 4
c	WHITE	GUN-IN-BOX, GUN 2	SLOT 1, PIN 8
d	GRAY	FLOW SWITCH, GUN 1	SLOT 2, PIN 5
e	BLACK	FLOW SWITCH, GUN 2	SLOT 2, PIN 6

Air Cut Off Box Connections Diagram





MANUAL VALVE PULSE SETUP


CCV Pulse Flow Adjustment-Below Range

The correct pulse flow range is in the green zone as shown between the green arrows.

In the image shown at the right, the blue diamond shape is left of the green zone and below range. The flow must be increased to a specified 50%. Follow the steps below to adjust the valve flow.




1. Use a 13 mm wrench and turn it counterclockwise to loosen the jam nut on the adjustment screw.
2. Turn the adjustment screw clockwise until the blue diamond moves to the center of the green zone range.
3. Turn the wrench clockwise to set the adjustment screw in position.




CCV Pulse Flow Adjustment-Above Range

The correct pulse flow range is in the green zone as shown between the green arrows.

In the image shown at the right, the blue diamond shape is right of the green zone and above range. The flow must be decreased to a specified 50%. Follow the steps below to adjust the valve flow.



1. Use a 13 mm wrench and turn it counterclockwise to loosen the jam nut on the adjustment screw.
2. Turn the adjustment screw counterclockwise until the blue diamond moves to the center of the green zone range.
3. Turn the wrench clockwise to set the adjustment screw in position.




CCV Pulse Flow Adjustment-In Range

The correct pulse flow range is in the green zone as shown between the green arrows.

In the image shown at the right, the blue diamond shape is in the center of the green zone and is in range. This is the optimal position, and no more adjustment is necessary.

To enable pulse valve flow control, go to page 2 of 4 in the System Configuration menu (discussed on manual page 67). Select "Pulse" for Channel 2.



EXTERNAL AIR CONNECTIONS

The RF2 can (and in some cases must) control air signals that are external to the RF2; these include gun trigger and dump signals. Every solenoid controlled by the RF2 is programmable, so the individual port location for any signal depends on the programmed location for that signal.

The RF2 will be pre-programmed from the factory with a standard list of signals for the purchased configuration. A list will be provided showing the air connections as programmed. It is also possible to view and modify this list as desired.

To view the list of connections:


1. Navigate to the Setup Menu -> Output Configuration (see "Running the System" section for more information).
2. Select the manifold (on the top of the output config menu) to view. Note the RF2 can control up to four solenoid manifolds, but in many cases the system will only be configured for one. Only manifolds that are present will be shown.
3. The list of outputs is shown as Port 4 and Port 2, with 16 rows represent the possible 16 modules (each having two solenoids) in the selected manifold. The orientation is the same as the view of the air connections at the base of the solenoid manifold.

All air signals that control elements that are provided with the RF2 will be pre-programmed, and their air tubing will be pre-installed if possible. But their solenoid locations may also be viewed or modified using the same procedure as above.

If a solenoid fails due to wear, or other damage, etc., a quick "output swap" process is provided so that any two outputs configurations and functionality can be swapped. This function is located in the Output Configuration section of the System Setup Menu.

Normally, the system will be provided with some unused solenoids that can be used for this purpose. Refer to the Setup section of this manual for more details.

More information about output configuration is given in "System Configuration" and "Running the System" sections.



CCV Output Definition Key	For example:
k = Component	k1cal = Component 1 Calibration
# = Channel/Component #	k1c3 = Component 1 Color 3
ss = Stack Solvent	k2c3 = Component 2 Color 3
sa = Stack Air	k1pv = Component 1 Pulse Valve
c = Color	
pv = Pulse Valve	
cal = Calibration	
mbs = Mix Block Solvent	

AUXILIARY SIGNALS

The RF2 is designed to be placed inside a larger process to take commands from paint / assembly lines, robotic cells, etc. Commands and Status information can be communicated to and from the unit via discrete wiring or by fieldbus. Both methods can be used simultaneously if desired. While it is possible to fully run the RF2 system with hardwired signals, much more functionality is available through fieldbus communications.

Hardwired I/O (Discreet Wiring)

If it is desired to use hardwired signals to give basic commands and receive basic status information, the following digital signals are available.


The table on the preceding pages references I/O slot and pin numbers. These correspond to the physical location of the connection. Slots being cards, numbered low to high from the left, and pin numbers being the connection from low to high from the top of a given slot.

SLOT 1 (DIGITAL INPUTS)	
1	Station #1 Sequence Interlock-24V = Interlock OK
2	Station #1 Spray Interlock-24V = Interlock OK
3	Station #1 Recipe Strobe-24V Pulse loads selected Recipe
4	Auto gun = Station #1 Applicator ready; Manual Gun = Station #1 Flush box
5	Station #2 Sequence Interlock-24V = Interlock OK
6	Station #2 Spray Interlock-24V = Interlock OK
7	Station #2 Recipe Strobe-24V Pulse loads selected Recipe
8	Auto gun = Station #2 Applicator ready; Manual Gun = Station #2 Flush box
SLOT 2 (DIGITAL INPUTS)	
1	User Input #1 (For Pass-Through)
2	User Input #2 (For Pass-Through)
3	User Input #3 (For Pass-Through)
4	User Input #4 (For Pass-Through)
5	Auto Gun = Mix #1 Trigger Cmd, Manual Gun = Mix #1 Manual Trig Flow Switch
6	Auto Gun = Mix #2 Trigger Cmd, Manual Gun = Mix #2 Manual Trig Flow Switch
7	Auto Gun = Mix #3 Trigger Cmd, Manual Gun = Mix #3 Manual Trig Flow Switch
8	Auto Gun = Mix #3 Trigger Cmd, Manual Gun = Mix #4 Manual Trig Flow Switch
9	Job Data Binary 1
10	Job Data Binary 2
11	Job Data Binary 4
12	Job Data Binary 8
13	Job Data Binary 16
14	Job Data Binary 32
15	Job Data Binary 64
16	Job Data Binary 128

SLOT 3 (DIGITAL INPUTS)	
3	System Fault Reset Pulse
4	Station 1 Run Pulse
5	Station 1 Halt Pulse
6	Station 2 Run Pulse
7	Station 2 Halt Pulse
8	Reserved
9	Reserved
10	Reserved
11	Reserved
12	User Input #5 (For Pass-Through)
13	User Input #6 (For Pass-Through)
14	User Input #7 (For Pass-Through)
15	User Input #8 (For Pass-Through)
16	User Input #9 (For Pass-Through)
SLOT 4 (DIGITAL OUTPUTS)	
1	Station #1 HV Enable
2	Station #2 HV Enable
6	Station #1 Run Mode
7	Station #2 Run Mode
13	Gun/Mix #1 Pot Life Expired
14	Gun/Mix #2 Pot Life Expired
15	Gun/Mix #3 Pot Life Expired
16	Gun/Mix #4 Pot Life Expired
SLOT 5 (ANALOG INPUTS)	
1+, 2-	Programmable Analog Input #1
3+, 4-	Programmable Analog Input #2
5+, 6-	Programmable Analog Input #3
7+, 8-	Programmable Analog Input #4
9+, 10-	Programmable Analog Input #5
11+, 12-	Programmable Analog Input #6
13+, 14-	Programmable Analog Input #7
15+, 16-	Programmable Analog Input #8
SLOT 6 (HIGH-SPEED COUNTER)	
1-5	Channel #1 Flow Meter
6-10	Channel #2 Flow Meter
SLOT 7 (HIGH-SPEED COUNTER)	
1-5	Channel #3 Flow Meter
6-10	Channel #4 Flow Meter

Analog hardwired inputs

Additionally, the RF2 has eight analog inputs, which can be configured for various system functions, including flow command for a gun or mixer.



The analog input module used by the RF2 will be pre-configured for eight 2-wire 4/20mA signals, but each channel can also be configured as a 0-10V, 1-5V, etc. input type. Changing the configuration of the input itself requires the user to access the onboard webpage for the Turck I/O module. Only qualified personnel should perform this procedure.

Assignment of an analog input to a given function is done through the following procedure:

1. Log in as an administrator.
2. Navigate to Setup -> System Configuration.
3. Press "Next" until reaching the fourth page, which contains the assignments for analog inputs.
4. Assign each analog input as desired. See screenshot to the right.
5. Press "Finish" to store the configuration—the system will reboot.




Analog Types available are:

- Inlet Pressure (Channel 1 to Channel 4)—used by gear-pump (future addition) channels to read inlet pressure.
- Outlet Pressure (Channel 1 to Channel 4)—used by gear-pump (future addition) channels to read outlet pressure.
- Flow Command (Gun/Mix 1 to 4)—used as the overall flow command for the indicated gun or mixer.
- Flow Feedback (Channel 1 to 4)—analog flow feedback sensor if used instead of a pulsing sensor (future addition)
- Solvent Flow Meter (Station 1 or 2)—used as a solvent flow meter for verification of a flush, etc.


Wiring for the analog signals is done on slot 5, pins (1+, 2- for input 1, 3+, 4- for input 2...). See schematics for more details.

To modify the type of analog input:


1. Connect a laptop to the open RJ45 port on the Turck I/O Block.
2. Set the laptop IP address to 101.1.1.99
3. Open a web browser, such as Google Chrome, and type 101.1.1.25 in the URL.
4. Log in with the password = "password".
5. Select the analog input module: Slot 5 – BL20-E-8AI-U/I-4PT/NI



6. Modify the channels as necessary. Consult Turck BL20 IO manual for more details.



7. Press the "Submit" button.



Analog In 8 - Data format

Analog In 8 - Deactivate diagnostics

NOTE

For analog current inputs, both 2-wire and 4-wire styles are possible, but note that if using 4-wire channels, it eliminates another input channel, reducing the number of inputs available. It is recommended to use only two wire current inputs or voltage inputs with the RF2.

Fieldbus Communications: Ethernet

The RF2 can communicate via fieldbus through its RJ-45 plant ethernet connector.

The RF2 uses Ethernet / IP communications protocol in its most basic configuration. The plant or supervisory PLC can utilize CIP Data Transfer Read or Write commands via a Message instruction (MSG - Rockwell) or equivalent to get status information or give commands.

If desired, the RF2 can be configured to use a gateway module that establishes an implicit communications path between the RF2 and some other industrial protocol, such as ProfiNet, Modbus TCP, CC-Link, etc.

Sample codes are available from Carlisle Fluid Technologies. They can be imported into the supervisory PLC to facilitate communications more quickly with the RF2 and provide data structures for the communicated information.

Signal lists and more detailed information to establish communications with the RF2 are given at the end of this manual.

Fieldbus Communications IP Address Setting (without gateway)

Series 1 RF2 control units use an Allen Bradley–Compact Logix PLC with two separate ethernet networks as the primary controller. Network A1 is used for local communications to RF2 devices such as I/O and solenoid manifolds. Network A2 is used for communications to a plant.

To prepare the RF2 control:

1. Plug an RJ-45 ethernet cable into an open port on a local ethernet switch (ESW128).
2. Set the Allen Bradley PLC to "PROG" mode.

To set the IP address, download RSLinx Classic software from Rockwell Automation (found online). There is a free version (Lite) available. **RSLinx Classic version 4.30 or higher must be used.**

Use the following procedure for setting the IP address for Network A2 on Series 1 RF2 units:

1. Set the IP address of the user's laptop or PC to 101.1.1.99, subnet Mask 255.255.255.0
2. Open RSLinx software.
3. Select Communications - > "RSWho."
4. Select the ethernet IP driver and scan the network (Most likely this will be named AB_ETHIP1). Refer to the configuration note* if the protocol is not present.
5. Find the RF2 controller at IP address 101.1.1.20—right click and select module configuration.
6. Select "Port Configuration Tab."
7. Select Network A2.
WARNING: Do not modify anything in Network A1. The system can be rendered inoperable.
8. Set the IP address as desired to communicate to the Plant controller and click "OK."
9. With these steps completed, set the PLC/IP address back to Run or remote mode.

***Configuration note:** If RSLinx is not configured to have an ethernet IP driver, do the following:

- A. Select Communications -> "Configure Driver."
- B. In the "Available Driver Types" pulldown, select Ethernet/IP Driver, click "Add New."
- C. Click "OK"—the new driver will be added.

Fieldbus Communications IP Address Setting (with gateway)

When the AnyBus communications gateway is installed in the system, the RF2 will already be configured to communicate with it. The gateway itself must be configured on the plant side to talk to the plant.

To configure the plant side of the gateway, download and install HMS IPconfig Software from:

www.AnyBus.com/support

Connect the PC with HMS IPconfig software loaded to the plant side network ports of the gateway device. Set the IP address of the laptop to the network that you wish to place the gateway on. Start HMS IPconfig software.

When HMS IPconfig is started it will automatically scan for compatible and active HMS devices. To change the IP configuration for a device, click on the device in the list.

Pressing "refresh" in the IPconfig software will cause the software to rescan the network. When selecting a device, pressing the "wink" button will cause the device LEDs to flash, verifying that the correct device has been chosen.



IP and DNS settings can be configured manually or dynamically using DHCP by modifying them in the right hand section of the page and pressing apply See the User Manual for HMS IPconfig software for more detailed information.

Configure High-Speed Counter I/O (non-quadrature flow meters)

In some installations, the standard flow meter may not be used. Some pulsing flow meters do not have quadrature output.

If this is the case, the channel must be modified in order to accept a single pulse input. To do this:

1. Connect a laptop PC to the open RJ45 connector on the Turck I/O block. Set the laptop IP address to 101.1.1.99
2. Using a web browser, enter 101.1.1.25 into the URL.
3. In the Login field, enter "password".
4. Click "Parameters" for the slot you wish to modify. Channels 1 and 2 are connected to slot 6, channels 3 and 4 are connected to slot 7.
5. Find Counter 1 or Counter 2—Mode CNT. Counter 1 will be for the first channel connected to the slot, Counter 2 is for the second—for example Slot 7, Counter 1 is for channel 3.
6. The default setting for this field is "AB Mode—4 samples", for a single pulse—change this to "pulse-direction, single sample."
7. Click "Submit." The counter is now configured.



NOTE


In this mode, for the count direction to be positive, the D2 pin for the channel (pin 2 or 7) must be connected to 24VDC. If the flow meter has directional output, this can be used for direction; otherwise, connect a 24V jumper to the direction pin.

DISPOSAL INFORMATION


Prior to disposal of this equipment at the end of its life cycle, all components containing electronic printed circuit boards (PCBs), sensors, and any wetted parts that may contain hazardous materials should be separated from the unit and recycled/disposed of according to local regulations.

RF2 CLOUD SETUP


1. Login to 'admin' user.
2. Select Menu > Setup > Exor Internal Menu.



3. Select > Show system settings.



4. Select "Network."




5. Select "Edit."



6. Enter Network and network password. Click "Save."



7. Click "Menu" at the top left. Select "Services."



- 8. Enable these three (3) services:
 - a) VNC Service,
 - b) Router/NAT/Port Forwarding
 - c) Cloud/VPN Service



- 9. In "Cloud/VPN" verify the following settings:
 - Server: us.corvinacloud.com
 - Username: RF2-machine/serialnumber/organization
 - Example: RF2-1234/CFTLiquid
 - Password: paint123\$



OPERATION

POWERING UP THE SYSTEM

Before system start-up, make sure the main power has been correctly installed. See the section on electric installation for more details.

To start-up:

1. On the right hand side of the control module enclosure, turn the rotary disconnect switch clockwise. The system will go through a boot-up sequence. When ready, a button will show on the screen to access the "Main Menu."
2. On the start-up menu, along the bottom, change the language of the display by pressing the "flag" icons for the appropriate country/language.
3. On the bottom-right-hand side of the start-up menu, press the "config summary" button to access the configuration summary page—which briefly describes how the system hardware has been configured.
4. Pressing the Main Menu button will:
 - a. Open the main "Run" menu if the system has been configured and the user-preference to "show configuration summary on startup" is not set.
 - b. Open the "Configuration Summary Menu" if the system has been configured and the user-preference to "show configuration summary on startup" is set.


NOTE

If the system is not configured, refer to the configuration section of this manual to proceed.

- c. Open the "System Configuration Menu" if the system is not configured.

NAVIGATION BAR

Except on certain menus that have special purposes, the navigation bar shown below will be visible in the upper section of the screen. Each section will be discussed separately in this manual.



Press the "Menu" button to open a drop-down menu to access other menus.


Press "User" to open a dialog menu to log-in, log-out, and access other functionality available to the administrator.

Press "Alarm" to open the alarm status/history menu.

Press "Log" to open the main data-logging menu.

Drop-Down Menu

Available options on the drop-down menu are shown below. Access to specific functions is limited by the administrator for designated users.



LANGUAGE SETTINGS

System Languages can be chosen by selecting the "Language" icon (a) at the bottom of the menu drop down, and selecting the user's language from the list (b) to the right.

NOTE

Some objects are not part of this run-time project. These include, for example, user-editable fields: station, gun, channel, and output names, as well as some menus like Exor's internal HMI menus. These cannot be translated in run-time and will remain the same regardless of the selected user's language.




RUNNING THE SYSTEM

Loading Recipes

For each station, up to 250 user recipes may be stored. It is recommended that each material being used will have a dedicated recipe. Recipes may be loaded from the operator interface of the RF2, or through commands from a supervisory control process.

To load a recipe from the operator interface, perform the following steps in order:

1. Navigate to the "Run" menu using the drop-down menu.
2. Make sure all faults are reset.
3. The "Run" menu will show a brief list of active alarms if any exist. If not, press the "Reset" button to clear any alarms, or try further troubleshooting as necessary.
4. If the RF2 has been configured for two stations, select the applicable station.
5. Press the "Start" button to place the station in run-state. The text will change to show "Running."
6. Select the appropriate recipes from the dialog.
7. Press the "Load" button to start the load sequence.



When the load sequence starts, the station will determine if a flush is needed before it runs the load sequence. Then it runs the appropriate sequences to load material. When this happens, the bottom of the Run menu will show the load sequence. All Start/Stop/Reset and recipe-select functionality will be unavailable during this time.

When the load sequence is complete, the material is loaded, and the station is in run-state, the system will respond to trigger and flow commands for any configured Guns/Mixers for the station and control.

Editing Recipes

Select "Recipe" from the drop-down menu to view or change recipe parameters.

The "Materials" section of the recipe menus will open. At the top of this other recipe menu, "Mix/Guns" will be available if configured in the selected station or greyed out if they are not configured.


Access to channel-recipe data is located at the bottom of the "Mix/Gun" recipe menus. It will be available based on the number of channels configured for the selected Gun/Mixer. Channel A, B, or C will navigate to the settings page for the physical channels 1-4, but depends on which channel is configured for each Gun/Mix channel.

To select a recipe to change, press the field that shows the "Recipe to Edit" (a). It will open a pop-up dialog to show selections from the list of recipes. Use the arrow buttons to scroll through the list. There are 250 recipes available per station.

To change the selected recipe's description, press the "Write" (b) icon next to the current recipe description to open the dialog.

Screens will show differently when the materials, guns/mixers, or channels within a recipe are changed.

Material Editing Screen:



Gun/Mixer Editing Screen



a

Select material options

Copy and Backup buttons (discussed later)

Select gun options

Recipe parameters

Select channel options

Channel Editing Screen

The screenshot shows the 'Recipe Configuration - Channel' screen. At the top, it displays 'Recipe To Edit: 1 - red' and 'Gun #1 Hardware Channel Channel A'. Below this is a 'Flow Control' section with a table of parameters:

Parameter	Value
Flow Calibration	54000 pulses/L
Flow Control PID - Kp	8000
Flow Control PID - Ki	800
Minimum Control Pressure	10 psi
Flow Control PID - C band	0.0
Flow Control PID - I band	0.0

Below the table is an 'MVR Enable' checkbox (unchecked) with a note: 'When enabled, color water associated with this channel will flow off when not triggered, unless a different channel connected to the same stack is triggered.' Underneath is an 'Inlet Pressure' section with another table:

Parameter	Value
Inlet Pressure Control	40 psi
Minimum Inlet Pressure	0 psi
Maximum Inlet Pressure	100 psi

At the bottom left is a 'Previous' button. Callouts include: 'a' pointing to 'Recipe To Edit'; 'Selected channel information' pointing to 'Gun #1 Hardware Channel Channel A'; 'Recipe parameters' pointing to the 'Flow Control' table; 'Copy and Backup buttons (discussed later)' pointing to the copy and backup icons; and 'Return to previous menu' pointing to the 'Previous' button.

NOTE

Access to the calibration settings for the flow meter opens the calibration dialog and lets the calibration process occur.

Copying Recipes

Press the "Copy" icon near the top of the recipe edit menu to open the copy dialog. From this menu, choose the "Source" recipe and the destination locations (1-250) that represent the available 250 recipe data registers in the selected channel. Multiple destinations can be chosen at the same time but can cause longer process times.

When the source and destination fields are set, press the "Copy" button to make a copy of all data from the source recipe to each destination location in the range. Make sure to add a "#" to each description.

Operate the System (manually or locally)

Though the RF2 will most commonly be put into a process that receives automatic commands, such as trigger, flow rates, and load recipes/materials, it can also be operated from the local interface.

To operate the RF2 from the main panel after the material has been loaded:

1. Navigate to the Run Menu.
2. Select the station you wish to control if the RF2 is configured as a multi-station controller.
3. Press the "Gun/Mix" panel for the unit you wish to control. A popup dialog box will show the details of the selected gun or mixer.



- If the logged-in user has permission, the active setpoints from the selected recipe will be editable. If not then the settings will be in view-only mode.

Gun / Mix Details
Gun #1
Station #1

Flow (cc/min)

05:52:45 05:57:45

Active Job Settings:

Default Flow	Cylinder	250	(Actual) 250.00
Min. Flow		0	
Max. Flow		1000	
Flow Tolerance (%)		5	
Flow To Time (sec.)		3	
Pot Life Time (min.)		10.00	0:03
Trigger-On Delay (ms)		0	
Trigger-Off Delay (ms)		0	
Ratio A		4.0	4.04
Ratio B		1.0	1.00
Ratio Tolerance (%)		10	
Ratio To Volume		125	

Flow Test 5.000

Volume Check

A:	395.9
B:	99.7
C:	N/A
Total:	495.6

Clear
Ratio Check

Close

Note: One of these positions is the default flow rate for the recipe. If operated from the interface, it is recommended to press the override button to let this position take precedence over auxiliary positions. Those auxiliary positions can come to the RF2 from a discrete analog signal or via a fieldbus command. The active flow rate command is shown to the right of the default flow setpoint.

- On the right side of the panels are "Trigger" buttons that start the applicators assigned to the gun/mixer. Press the trigger button to toggle the trigger between active and inactive. If multiple triggers are on during the same time, the flow rate for the gun/mixer will be the command multiplied by the number of triggers currently on.
- When the "Flow Test" button is pressed, it can start and set "Trigger 1" for a given period.
- The status information for the gun/mixer is shown throughout the display.

NOTE

Only assigned triggers to the gun/mixer will be visible on this menu.
In most cases only one will be configured.

The volume check shows the run totals for all materials in cc or mL. Press the "Clear" button to reset the totals when not triggered.

The "Ratio Check" button will cause the material to be moved from the gun trigger to the calibration test ports for all configured materials. It lets the user position beakers under the ports to catch the material, do a quick flow check on all materials, and compare them to the calculated volumes.

Channel Menu

From the Run Menu, press any of the "Channel" panels shown to open a pop-up dialog with status and active settings for that channel.

If the user has permission, they can change the active recipe parameters. Without permission, the values will be view-only.

Status information is shown throughout the display.

The screenshot shows the 'Channel Details' interface for 'Channel #1'. It features three trend graphs: 'Flow (cc/min)', 'Flow Pilot (psi)', and 'Inlet Pressure (psi)'. Below these is the 'Active Job Settings' section with fields for Density (2000), Viscosity (150), Yield (6.0), Yield2 (8.0), Max Pressure (60), Min Flow (0), and Max Hot Prc (0). A 'Calibrate' button is highlighted in blue, and a 'Close' button is at the bottom right. Three red callout boxes with arrows point to the graphs, the settings section, and the Calibrate button.


Trend of Flow Rate, Pilot PSI, and Inlet Pressure

Active job settings relevant to the channel

Calibration Menu

Alarms Menu

On the main navigation bar, the alarm icon (a) will change color and show an alarm count if an alarm exists.



Press the icon to open the following menu.

On the Alarm menu, the top list shows active alarms, and the bottom list shows historical alarms.

For more alarm details:

1. The right side of any row in the active alarms list that contains an alarm is a button under the "Action" column (b).
2. Press this button to open a pop-up dialog that explains the condition and gives some actions.
3. Active Alarms: If an alarm is active, it will be listed in the top list on the Alarm Menu.
4. Historical Alarms: In the historical alarms list, the duration of the list can be selected through the drop-down combo box. Press the "Backward" and "Forward" buttons to scroll up and down through the list.

To reset an active alarm:

1. Press "Reset Alarms" (c) above and to the left of the active alarms list, or press "Reset" on the Run Menu. If the alarm condition has been cleared, the alarm will clear from the list and be shown only in the historical alarm list.

- 2. In the alarm detail pop-up menu, press "Close" (d) to exit the menu, "Condition" (e) to see the list of conditions that may cause the indicated alarm, and "Action" (f) to see a list of potential corrective actions.



Audit Log

On the top-right of the Alarm menu, the "Audit Log" button will open a menu and show the events that have been captured by the system.

The audit log menu can be filtered (g) by user, and duration.



CALIBRATION

Flow Meter Calibration

Calibration of the flow meter is recommended for each individual material that is run. This is because materials of different viscosities may cause the gears within a flow meter to turn more or less than others.

Further, at low flow rates (less than 100 cc/min) flow meter operation can depend on the flow rate. Therefore, it is also recommended to calibrate material at close to the nominal flow rate for the process.

Calibration data is stored in recipe data. The calibration menu may be accessed from the recipe-edit menu or from the channel detail pop-up menu, accessed from the Run menu.

To calibrate a square wave flow meter:

1. Load a recipe/material into the system.
2. Access the calibration menu, by going through the channel detail popup, or through the recipe edit screen.

NOTE

A different calibration dialog may open based on the flow meter type (square wave, or 4-20mA).

3. Place a cup under the calibration port for the channel being calibrated.
4. Set a flow pilot command (a)—this will be the command given to the flow-control device during the calibration process. 100-200 cc/min is the recommended start number.
5. Set a delay time (b) (if desired) and a trigger time (c).
6. Press Start. The delay time will occur (in case this time is needed to position the beaker under the calibration port), then the calibration port will open for the set amount of time. The volume of material will be calculated (based on current calibration settings).
7. When complete, enter the measured amount of material into the "Actual Volume" field (d). A suggested calibration will be calculated based on the amount of flow-meter pulses that were counted, and the actual volume entered.
8. Press "Accept" (e) to accept the suggested calibration as the Calibration Value.

The screenshot shows a 'Calibration' dialog box with the following fields and controls:

- Channel:
- Recipe:
- Position cup to catch material (blue button)
- Current Count: 31585
- Test Count: Clear
- Calibration Value: PPL
- Flow Command: cc/min
- Delay (sec): Start Time (sec)
- Calculated Volume: 0.00 cc
- Actual Volume: cc
- Suggested Calibration: Accept
- Close (button)

Red circles with letters a-e point to the following elements:

- a: Flow Command input field
- b: Delay (sec) input field
- c: Time (sec) input field
- d: Actual Volume input field
- e: Accept button

Alternatively, the calibration value can be directly entered from this menu if desired.

Changes made to the calibration are stored to the recipe parameters for the recipe loaded.

MANUAL OVERRIDE/LOCAL FLUID CONTROL


The manual-override menu can be accessed from the main dropdown menu or when the mode icon button (a) at the top of the menu bar is pressed. This function is not available from every menu.

The Local Fluid Control menu (shown below) lets individual functions and outputs operate for maintenance and troubleshooting purposes.



To operate functions manually, press the "Manual Override" (b) button. The button will turn yellow and the icon at the top of the menu (c) will change states to indicate manual override is active.


Press the button (d) to the right of any listed function and its corresponding output will activate as if the function is activated in sequence. The output status is shown to the right of the page (e).



NOTE
Output interlocks that have been configured will continue to work in this mode. It is not possible to turn on two incompatible solenoids at one time from this menu.

When the manual override is active, material A, B, and C color valves (CCVs) can be selected. When a function activates that lets the "load color" system output to be active, the selected material valves will activate. When "load color" is unlatched, it will shut all color valves off.

From this menu, when manual override is not active, it is possible to run fluid sequences directly when their associated buttons near the bottom of the menu (f) are pressed. When active, functions and outputs will indicate their status and let a sequence be viewed in operation from this menu.




Press the "Pressure Regulators" button (g) on the Local Fluid Control menu to open the menu shown below.

From this menu, manual override mode can be activated and deactivated, and all configured pressure regulators can be operated manually.

Press the "Previous" button (h) to return to the Local Fluid Control Menu

Press the "Solenoid Forcing" button (i) from the Local Fluid Control Menu to open the menu shown on the right. This menu is only available if manual override is selected.

From this menu, each installed solenoid is forced on or off when the button (j) to the right of the output descriptions is pressed.



⚠ WARNING
Output interlocks are not observed in this mode.

SHUTTING DOWN THE SYSTEM

Before shutting down, it is desirable to purge any material that is in tubing to prevent it from clogging fluid tubing, etc.


All recipes have a "Purge All" sequence designated and when the supervisory controller calls a purge command, the system will run that sequence.

To purge from the HMI – press the triangle (a) button on the bottom right of the start panel on the main run page.

All sequences that have been configured for the selected station will be shown (b) in place of the recipe selection information in the run panel. To run a sequence, the RF2 must be in "Run" mode, and all interlocks from other systems must be ok. Press the button for the sequence that is desired, and it will run.

For the shutdown purge, press the button corresponding to the sequence that has been programmed to purge all material. "Purge All" for example.

After the purge sequence has been completed, you can proceed to shutdown the system using the power switch on the right of the system's enclosure.



ADMINISTRATOR FUNCTIONS


Users that are members of the "admin" group can access functions not available to other users and to modify access for other users.

User Options


To access the user options page, log in as an administrator and then press the "user" (a) menu key to open the user actions dialog.



A dialog box will open and the administrator will see an option called "User Options" (b).



From the user options menu you can Edit users (c), Add users (d), Delete users (e), or change User permissions (f).



Edit User

To edit a user, press the Edit Users menu.

Select the user you want to edit (g)


Modify the user's parameters (h). This includes user-group assignment.

Add User

The operator interface supports up to fifty individual users.

To add a user, enter the Add User menu.

Fill in the parameters (i) including user name, group assignment and initial password.



Delete User

To delete a user, enter the Delete User menu.


Select the user (j) you want to delete.

Click on delete (k).



User Permissions

Various functions within the operator interface can have their access controlled depending on their group assignment. See more details about this in the "Security" section in the "Process Configuration" chapter. To assign rights to different user groups, enter the "User Permissions" menu from the User Options menu, and select or deselect access for each function (l) by user level (m).




Disabling Cloud Access

Although the cloud access feature of the RF2 is an appropriate manner to allow diagnosis, troubleshooting and updates to the equipment, some customers may not want to use this type of service.


Access to the RF2 via Exor's Corvina Cloud service can be disabled in two ways:

1. Disconnecting the RF2's physical "Cloud" RJ-25 port from a network connection.
2. Through the Exor's internal menu:



From the settings menu (when logged in as an administrator), press "Exor Internal Menu" and select "Show system settings" in the dialog box that opens (n).

In the settings menu that opens, press "Services" and then "Cloud Service" to access the menu shown below.



In the Cloud Service menu, press "Edit" (o) at the top right, and then click the "Enabled" slider to disable the service (p). Press "Save."

Press Back, Menu, Exit to return to the runtime environment.

WARNING

Though unlikely, a malicious actor having access to the RF2 via the cloud service would have the ability to activate the unit remotely. The greatest hazard in this case is the potential for the release of chemicals while no personnel are present. However, this hazard is mitigated if the air and fluid supplies to the RF2 are deactivated when no personnel are to be present as recommended in the safety section.

If it is suspected that someone has unauthorized access to your RF2. Contact your Corvina Cloud organization's administrator. This could be the distributor of your equipment. If this information is not known, contact Carlisle Fluid Technologies.

SETUP

To access the main setup menu, select "Setup" from the main pull-down menu.


On the main setup page, the top two selections are available only to administrators. These are "Exor Internal Menu" (a) that opens a popup dialog to allow internal settings for the Exor operator interface to be modified, and "System Configuration" (b) that opens the system configuration menu.

The next group of selections involve setting up the "Fluid System" (c) which involves setting up outputs, functions, and overall sequence definitions and settings.

These selections are access-controlled by the administrator. The "Show Config Summary" (d) button will open a page showing an overview of the system configuration.

The "Fluid Sequences" (e) selection allows individual fluid sequences, including step timing and order of operations to be modified. This menu is access controlled by the administrator.


The final group of menus (f) are for modifying several miscellaneous parameters used by the system that dictate its behavior.



Exor Internal Menu

The dropdown dialog allows access to the root settings for the Exor operator interface's internal settings. Setting IP addresses for the three networks provided with the interface (described in the Installation section above), and setting the date and time displayed on the panel are the only operations that are necessary to operate the RF2.

For more information, consult the user manual for the Exor eX715 operator interface.



System Configuration

System configuration is a group of four menus that are used to define the hardware installed on the RF2:


- Fluid Mix/Guns
- Channels
- Stations and AnyBus Gateways
- Solenoid Manifolds, Pressure/Regulators, and Analog Outputs

Fluid Mix/Guns

The first page allows the Fluid Mix/Guns to be configured.

Definitions for each Gun/Mix include:

1. **Description:** Each unit can be named –this name will be displayed on the main menus and will be what is used for referencing the gun/mixer.
2. **Fluid Type:** Unused, 1, 2, or 3 component fluids.
3. **Control Type:** Auto, Manual Pulse (Future), Manual Analog (Future).
4. **Channel Selections:** Depending on the fluid type selected, Channels A, B, and C may be available. These can be mapped to physical channels 1-4.



NOTE

Since only four channels are available to the RF2, selections for one of the four gun/mix units will affect the availability of others. For example, if 3k is selected for Gun/Mix 1, then only 1K will be available for the other three units, only one of which will be allowed to use the remaining channel.

NOTE

A physical channel can only be mapped to one channel of one gun/mixer. When one is already selected elsewhere, it will be deselected in the other location.

Channels

Press "Next" to open the next system configuration menu, for configuration of channels.

Channels that have been selected for use by a gun/mixer in the first system configuration menu will be available for configuration on this page.

Definitions for each channel include:

- a. Description: Each unit can be named—this name will be displayed on the main menus and will be what is used for referencing the channel.
- b. Flow Control: The type of flow-actuation device that is used by the channel.
 - MVR: A Material Volume Regulator is used to control flow.
 - Pulse: Fluid flow is controlled by a pulsing valve. This option is only available for secondary (B or C) channels in a gun/mixer.
 - Feedback Only: Flow is not controlled by the RF2 such as with a manual gun. This option is only available for manual systems on the master channel (A).
- c. Inlet Pressure Regulation: Select if a pressure regulator is to be used with a flow control device.
- d. Feedback Type:
 - Square Wave: Flow feedback is given by the flow meter pulse connected to a High-Speed-Counter input on the I/O block.



Stations and AnyBus Gateways

Press the "Next" button to open the next system configuration menu, for further configuration.

Station definitions include:

- Station assignments: Each gun/mixer configured can be assigned to either panel #1 or 2.
- Description: Description of each station that is used to reference stations throughout the operator interface.
- Material Counts: For each channel, the amount of solenoid valves available for materials.
- Manual Gun Enable: Enables manual gun for either station #1 or 2.

System Config 3 of 4

System Configuration

Station Configuration

Station Assignment

	1	2
Panel 1	<input checked="" type="checkbox"/>	<input type="checkbox"/>
Panel 2	<input type="checkbox"/>	<input checked="" type="checkbox"/>

Manual Gun Enable

1	<input type="checkbox"/>
2	<input type="checkbox"/>

Material Counts

	Color / Mat. A Count	Cat. / Mat. B Count	Mat. C Count
Panel 1	1	1	0
Panel 2	1	1	0

Mixer Accessories

	Air Cutoff Installed	Flush Box Count
Panel 1	<input type="checkbox"/>	0
Panel 2	<input type="checkbox"/>	0

Anybus Gateway

This system may employ an optional Anybus gateway to facilitate fieldbus communications between the Ramflow 2 and the master controller.

Anybus Gateway Installed:

Previous Next

Current User: admin

e. Mixer Accessories: Enables the configuration of two new options:

1) Air Cutoff Installed–Check this box when an air cut-off box is installed on a mixer that does not use one or more flush boxes. When enabled, the trigger 1 (one) and trigger 2 (two) outputs of the corresponding mixer will be turned on and off when the assigned station is started or stopped. The trigger outputs are plumbed to the air cut-off box solenoids to disable the atomization air for each gun. When a flush box is installed, the flush box controls the air cut-off. When the Flush box is set, the count to a value greater than 0 will disable this option. This option does not affect mixers configured for auto mode.

2) Flush Box Count–Set this field to match the number of flush boxes connected to a mixer. This option does not affect mixers configured for auto mode.

f. AnyBus Gateway: If the HMS AnyBus gateway is used for communications with supervisory processes, this box (f) must be selected.



e

f

Solenoid Manifolds, Pressure/Regulators, and Analog Outputs

Press the "Next" button to open the next system configuration menu, for further configuration.

- Solenoid Manifolds: Up to four solenoid manifolds may be used by the RF2 (each having up to 16 2-solenoid modules). Manifold #1 is always enabled and must be used.
- Pressure Outputs: The RF2 can control up to eight pressure regulators. In this section, define the amount of regulators that the RF2 will control, and the assignment for each regulator.
 - Regulator assignments include:
 - Channel 1-4 Inlet Pressure Control Pilot: Pilot signal (0-100psi) to a DR1 or equivalent pressure regulation device.
 - Channel 1-4 Flow Pilot: Pilot signal (0-100psi) to an MVR or DR1 that is used for controlling flow.
- Analog Inputs: The RF2 has eight Analog Inputs that can be utilized for different purposes:
 - Unused: The analog input is not used by the RF2.
 - Gun/Mix 1-4 Flow Command: Used as the flow command from an external/supervisory process (PLC or Robot, etc.).
 - Channel 1-4 Inlet Pressure: For gear-pump flow actuators, the inlet pressure feedback from an installed sensor.
 - Channel 1-4 Outlet Pressure: For gear-pump flow actuators, the outlet pressure feedback from an installed sensor.
 - Channel 1-4 Analog Feedback: Analog input is connected to an analog type flow meter for the channel.
 - Station 1-2 Solvent Flow Meter Feedback: Analog input is connected to a solvent flow meter which is used to verify that enough solvent was used per sequence.

System Config 4 of 4

EXIT System Configuration Restore From File

Solenoid Manifolds

	Enable	Number Of Modules
Manifold #1	<input checked="" type="checkbox"/>	16
Manifold #2	<input type="checkbox"/>	0
Manifold #3	<input type="checkbox"/>	0
Manifold #4	<input type="checkbox"/>	0

Pressure Outputs

Number of Regulators in Manifold: 8

Regulator #1 Assignment: Channel #1 Inlet

Regulator #2 Assignment: Channel #1 Flow Control Pilot

Regulator #3 Assignment: Channel #2 Inlet

Regulator #4 Assignment: Channel #2 Flow Control Pilot

Regulator #5 Assignment: Unused

Regulator #6 Assignment: Channel #3 Flow Control Pilot

Regulator #7 Assignment: Unused

Regulator #8 Assignment: Unused

Analog Inputs

1	Unused	5	Unused
2	Unused	6	Unused
3	Unused	7	Unused
4	Unused	8	Unused


Previous Finish

Current User: admin

Press the "Finish" button to save the system configuration parameters and reboot the RF2.

Function Configuration

To access this menu, press the "Function Configuration" button (1) in the Setup Main Menu.




In this menu, the functions can be selected along the left side of the menu. There are fifty functions available per station, pressing the arrow keys toward the bottom of the function list will page up and down.

When a function is selected, its configuration information is shown on the right-hand side of the menu. These parameters can be modified by changing the parameters

Parameters that can get changed are:

- a. Description: Description of the function selected—often this mirrors the output it works on.
- b. Type: Type of function. For more information, consult the section System Configuration—Terminology—Functions
- c. Output 1:
 - For simple, latch, unlatch and pulse types—this is the output that is acted on when the function becomes active.
 - For chop type functions, this is the first output that is active when the two outputs are toggled.
- d. Active in Sequences: Select all sequences for the selected function to be used.




System Outputs

System outputs are predefined outputs used internally to the system to activate certain features, etc. Just like configured outputs, these are called by functions.

Options available are:

- A. Station "x" Load—when active, the material valve (s) for the selected recipe for the station will be active.
- B. Stn "x" Max Flow—when active (to be used during a load sequence), the flow command for the Gun/Mixer will be the recipe defined "Sequence High Flow Rate." Materials will mix on ratio at this rate instead of the "Default Flow Rate"
- C. Stn "x" A,B, or C Fill—when active the A, B, or C channel for the station will be forced to 100% open. This is typically used by purging operations or for quickly loading material to the flow meter.



Function Configuration



To access this menu, press the “Function Configuration” button (1) in the Setup Main Menu.

In this menu, the functions can be selected along the left side of the menu. There are fifty functions available per station, pressing the arrow keys toward the bottom of the function list will page up and down.

When a function is selected, its configuration information is shown on the right-hand side of the menu. These parameters can be modified by changing the parameters

Parameters that can get changed are:

- a. Description: Description of the function selected—often this mirrors the output it works on.
- b. Type: Type of function. For more information, consult the section System Configuration—Terminology—Functions
- c. Output 1:
 - For simple, latch, unlatch and pulse types—this is the output that is acted on when the function becomes active.
 - For chop type functions, this is the first output that is active when the two outputs are toggled.
- d. Active in Sequences: Select all sequences for the selected function to be used.



NOTE

System outputs that can be interlocked to the S1 or S2 load identify a material valve set to on and—for example—interlocked with solvent or air signals. As a result, it is not necessary to interlock various CCV outputs from one to the other because the RF2 can only operate one CCV output number at a time.

Output Configuration

To access this menu, press the “Output Configuration” button (1) in the Setup Main Menu.

Along the top of this menu, the various solenoid manifolds that are installed in the system, and the discrete (hardwired) outputs can be selected (a). Only manifolds that are installed will be visible for selection.

Selecting a manifold causes the list of solenoids in the manifold (b) to be updated. Each Output on the manifold (0-31) can be selected. Note, the outputs are arranged in two columns (Port 4 and Port 2) and their orientation represents the view of the back of the solenoid manifold, looking at the air connections.

Selecting one of the outputs will cause the Selection Details (c) to the right side of the menu to be updated, and the interlocks (d) to be updated.

Output Interlocks prevent two incompatible outputs from being active at any given time. Up to twenty interlocks can be programmed for any individual output. To select or deselect an output as an interlock, simply press the button representing the interlocked output.

If you want to swap outputs, press the “Swap Outputs” button (e). This process is explained later.

To modify the output details, press the area showing the selection details—this will open a popup dialog menu (see on next page).

Parameters to be modified in the “Configure Output” popup menu are:

- a. Description: Description of the output—it is recommended that each output be labeled the same as any tubing labels that are connected to the solenoid valve.
- b. Output Type Selection: See more about different output types in the section—System Configuration-Terminology—Outputs in page 17.



- Dump—output acts as a trigger and flow will be expected when this output is on.
- In-Booth: Alarm indicator “Wink-Eye” for in booth controller accessory.

- c. Output ID: Depending on the type selection, different values will be asked for:
- Station Number: For Sequence Output or Material CCV output types, this represents the station that the output is assigned to.
 - Mix/Gun Number: For Trigger output types, this represents the gun or mixer that the output is assigned to.
 - Channel Number: For "Flow Test" output types, this is the channel that the output is assigned to.
 - Input Number: For "Pass Through" output types, this is the input ID that will affect the output.

System Outputs


System outputs are predefined outputs used internally to the system to activate certain features, etc. Just like configured outputs, these are called by functions. Options available are:

- Station "x" Load—when active, the material valve (s) for the selected recipe for the station will be active.
- Station "x" Max Flow—when active (to be used during a load sequence), the flow command for the Gun/Mixer will be the recipe defined, "Sequence High Flow Rate." Materials will mix on ratio at this rate instead of the "Default Flow Rate"
- Station "x" A, B, or C Fill—when active the A, B, or C channel for the station will be forced to 100% open. This is typically used by purging operations or for quickly loading material to the flow meter.

Sequence Definitions

On the Sequence Definitions Setup Menu (1), up to sixteen programmable sequences can be given names (a), and enabled or disabled (b) depending on whether they are necessary for the user's process. If a solvent flow meter is used for the station, enter a "solvent-check" value (c) which will be compared to the actual solvent used during a fluid sequence do generate an alarm if not met.

Additionally, global values for chop timing (air and solvent on times) (d) are programmed here.




Fluid Sequences

The Fluid Sequence Setup menu allows individual sequences of valve operation to be programmed. Sequences may be used for loading or purging of materials, as well as for other operations, such as bell cup wash, etc. When a sequence is called from the main menu, or from a supervisory process, the sequence will operate. To open this menu, press "Fluid Sequences" (a) in the Setup Main Menu.



To change a sequence:

1. Select the panel by pressing "Panel 1" or "Panel 2" buttons. The selected panel will be highlighted.
2. Select the Sequence to edit by pressing the "Seq" button or the description to its right. This will open a popup dialog which will allow the sequence to be selected from the list of available sequence definitions.
3. When the panel or sequence is changed, or when the refresh (b) button is pressed, the stored parameters will be loaded into the edit fields below.
4. Chop Override: If global timing values for chop air and solvent are not desired, enabling this feature allows these times to be entered in the fields below.
5. Set step times for 12 steps. If a step is not required, enter 0 seconds.
6. Step Volume: The minimum volume that must flow during each step before the next step. The step volume is measured as the total sum of all mixers configured for the current station; configure the sequence to ensure the calculated volume follows the desired flow path. For the sequence to progress to the next step, both the Step Time AND the Step Volume values must be met. The system will wait until enough volume has flowed through the system or until the Step time has passed, whichever takes longer.



- 7. The list of functions (c) that are used in the selected sequence will be shown.
- 8. Each function represents a row in the sequence and pressing the buttons (d) in each column will enable or disable the function in the given step. Buttons are highlighted blue when selected and white when not.
- 9. The total sequence time (e) is shown near the bottom of the page.
- 10. When finished with edits, press "Save Edits" (f) to store them in memory so that they can be used.
- 11. Edit Sequence Text: Opens the sequence step description editor window.



12. Sequence Descriptions: The sequence description editor lets the user add user-defined text that is displayed for each step of a sequence. Each sequence has its own set of 12 user-defined strings. The default values (g) are shown below.

The text fields on the sequence description editor page are the same as the field on the sequence run window. The text entered on this page will also appear on the sequence run window.

The sequence descriptions are not enabled until the user enters the sequence descriptions window and saves their changes.

NOTE

The user text entered on this page will not be translated when the system language is changed.

The screenshot displays the 'Sequence Descriptions' editor in the CARLISLE system. At the top, the CARLISLE logo is centered, and the date 'Mar 24 2023' and time '19:44 PM' are in the top right corner. Below the title, there are 12 rows, each representing a step. Each row consists of a label on the left (e.g., 'Step 1') and a text input field on the right containing the default text 'Step 1'. The steps are numbered from 1 to 12. At the bottom left, there is a 'Previous' button with a left-pointing arrow.

Global Setup

To modify several parameters that affect system behavior regardless of the recipe that is loaded, press "Global Parameters" (1) on the Main Setup Menu.

Parameters that are not relevant based on the system configuration will not be shown.

More information about the various parameters is given in "Process Configuration"–Global parameters.



Default flow

Inlet pressure

Outlet pressure



Alarm Masking

You can setup various system alarms to cause the system to shut down spray or, if deselected, they will provide a warning while the system keeps running. To do this, press "Alarm Masking" (1) in the Main Setup Menu.

Not all available alarms are shown here, as some alarms will always result in spray shutdowns or warnings. Selecting "Disable Audible Alarm" (a) disables the alarm horn from chirping when an alarm is activated.




Display Preferences

The display preferences menu allows various items to be changed that do not affect system performance, but affect the way that data is displayed to the user, to include language and unit of measure selections.



1



Select to display configuration summary on startup

Choose default units

Set scaling options for trends when opening Mix/Gun or Channel pop-up menus

Choose system language

BACK-UP/RESTORE

All stored settings, including recipe data, global setup data, fluid system configuration and sequences, etc. can be backed up to a USB stick or restored from USB or other media.

Additionally, this data is automatically backed up to SD card daily, with each daily archive being stored for one year before being deleted.

This functionality allows the entire system configuration (or individual parts of it) to be passed from one RF2 to another or restored in the event of a system failure resulting in the loss of data.

To access the backup and restore menu, navigate to the Main Setup Menu, and click on the "Backup/Restore" (1) icon on the lower right of the page.

When clicked, the system will display the screen below.



Back-Up Data

To backup to USB, first connect a USB flash drive into the USB port provided on the front of the control enclosure (a). The system will indicate that a device is found (b). To eject the USB drive, press the "Eject USB" button (c) and follow the prompts.

When a USB stick is detected, each row will have a "Store to USB" (d) file available. When pressed, any of these stored .CSV file with the contained information is selected. The "All System Data" row (e) will store ALL system information.

It is possible to open and view the above file with software capable of viewing .CSV files such as Microsoft Excel.



Restore Data



Press the "Restore" button (f) on any row to open a file dialog to access the operator interface's file system (including the USB drive and SD Card), etc. to look for the appropriate .CSV file.

The file restore dialog can be resized.

Within the operator interface file system, which is Linux based, the following paths are commonly used, and may contain file information.

- /mnt/sdcard (contents of SD card inserted in the slot).
- /mnt/usbmemory (contents of USB card inserted).

Once the file is found in the navigation menu, opening the file will restore the row selected. Note, if an invalid file is selected, the data will not be restored, and a warning message will be displayed.




DIAGNOSTICS

The diagnostics menu contains miscellaneous functions for further diagnosing the RF2. Navigate to the diagnostics menu by pressing the "Diagnostics" pushbutton on the main dropdown menu.

Audit Log Actions

The operator interface audits specific events such as user logged in, etc. From the diagnostics menu, it is possible to export the audit log to USB (in .CSV format), or to delete the audit log if desired.



NOTE

The RF2 web browser does not support all functionality for some of the pages. In special cases, a laptop may be needed to browse to those pages to perform certain tasks.

Hardware Browser

Some of the ethernet-enabled devices that are used by the RF2 have built-in web pages that allow for further diagnosis. The Exor operator interface that is used by the RF2 has a browser that allows viewing of those pages.

The home screen of the device browser shows the RF2s PLC web page. Hyperlinks along the top of the menu access the web pages of the other available devices.



Auxiliary Input Status

To check the functionality of inputs coming from auxiliary devices or some of the sensors that may be connected to the RF2, the Auxiliary Input Status menu allows the viewing of the input states.



Restart HMI

The HMI can be rebooted from the Main Diagnostics Menu showcased in the previous page by pressing the button Restart HMI (a).



DATA LOG/REPORTING

The RF2 stores flow total data and in the future, more detailed runtime data will be tracked. To access the main menu for data logging, press the "Log" button (1) on the right of the upper menu bar.



After pressing the button, the system will display the following screen,



Flow Totals

The RF2 stores basic material flow data for viewing.

Data is organized by gun/mixer (a), time range (yearly, monthly, weekly, daily, hourly, grand) (b)–or by recipe (c)–or by all recipes. Data can be shown in liters or gallons (d).

If more detailed data is needed for storage—it is best to connect the RF2 to a SCADA or supervisory PLC, and routinely poll the grand total, and other identifiers to store the changes in a database.


More information about connecting the RF2 to fieldbus can be found earlier in this manual starting on page 49 and in the Appendix starting on page 127.



File Access Via FTP

Files stored on the operator interface, including daily archives of system settings, alarm logs, etc. can be accessed via FTP if a computer is connected to one of its three networks.

An FTP access program such as WinSCP may be used for this type of access. Use the following configuration to access the RF2 data.



To Log in—press the login button (a) and enter the credentials for any administrator user account configured.

NOTE

File transfer is allowed in both directions, but it is highly recommended not to overwrite any files that are stored on the system.

MULTI-COLOR STACK LIGHT FUNCTIONS

The status/stack light is found on the top of the exterior of the RF2 control panel. The light will change color and/or flash depending on the status of the RF2. Each light function is defined below.

LIGHT	FUNCTION
Green—Solid	Machine is in "RUN" state, and no trigger signal is present on any stations
Green—Flashing	Machine is in "RUN" state, and trigger signal is present on one or more stations
Red—Solid	Machine fault is present
Yellow—Solid	Warning indication, No fault is currently present
Blue—Solid	Pot life is nearing expiration
White—Solid	Machine stopped idle state, no system warnings or faults
White—Flashing	Exor (HMI) Communication Timeout, no system warnings or faults
Light Cyan—Solid	Machine is running in an active sequence state

Page intentionally left blank

MAINTENANCE

REGULAR MAINTENANCE PROCEDURES AND RECOMMENDATIONS

Material Purge

After a job is completed, remember to thoroughly purge the system. Failure to do so can cause clogs, leaks, or cross-contamination of colors and material when the system is disassembled.


Regular Inspection

Continuous use or lack of use of the system can cause a system malfunction. Do regular interval system inspections as shown at the table below.

FREQUENCY	DESCRIPTION	INSPECTION METHOD
Daily	System flushed with solvent	Visual
Daily	Check for leaks	Visual
Daily	Clean spray guns	Visual
Daily	Check alarm history	Visual
Daily	Check for material supply	Visual
Monthly	Check static mixer for clogs	Visual
Monthly	Check all hoses for kinks and wear	Visual
Monthly	Perform flow meter calibration check	Test with beaker
Monthly	Check CCV operation	Trigger manually or from HMI
Monthly	Clean mix manifold and check valves	Disassemble
Monthly	Check fluid hoses for material buildup	Disassemble
As needed	Clean flow meter	Disassemble
As needed	Rebuild color change valves	Disassemble
As needed	Rebuild MVR valve	Disassemble
As needed	Replace static mixer assembly	Disassemble


TOP LEVEL PART NUMBERING

310 - C # # - # # #




COMPONENT VIEWS & SPARE PARTS

RF2 CONTROLLER




RF2 CONTROLLER-TOP LEVEL			
Item	QTY	Part No.	Description
1	1	310-5000	Control Enclosure
1CD	*See 1CD	-	Flow meter cables for different channel counts
3	*See Table 3	310-3940	Pressure Regulator
4	*See Table 4	310-3960	Solenoids
5	-	310-2010	Mounting Bracket
6	-	-	Cover-Pressure Regulators
7	-	-	Cover-Solenoids
FLOW METER OPTIONS (DIFFERENT CHANNEL COUNTS)			
Code-Top Level Columns CD	QTY	Part No.	Description
0	-	-	-
02	2	310-4138	M12-M12, 5PIN, 1M, SHIELDED
04	4	310-4138	M12-M12, 5PIN, 1M, SHIELDED
06	6	310-4138	M12-M12, 5PIN, 1M, SHIELDED
08	8	310-4138	M12-M12, 5PIN, 1M, SHIELDED
Z	2	310-4138	M12-M12, 5PIN, 1M, SHIELDED
22	4	310-4138	M12-M12, 5PIN, 1M, SHIELDED
24	6	310-4138	M12-M12, 5PIN, 1M, SHIELDED
26	8	310-4138	M12-M12, 5PIN, 1M, SHIELDED
40	4	310-4138	M12-M12, 5PIN, 1M, SHIELDED
42	6	310-4138	M12-M12, 5PIN, 1M, SHIELDED
44	8	310-4138	M12-M12, 5PIN, 1M, SHIELDED
60	6	310-4138	M12-M12, 5PIN, 1M, SHIELDED
62	8	310-4138	M12-M12, 5PIN, 1M, SHIELDED
80	8	310-4138	M12-M12, 5PIN, 1M, SHIELDED
COMMUNICATIONS MODULE			
Code-Top Level Column A	QTY	Part No.	Description
0	-	-	-
1	1	310-4142	GATEWAY, EIP-EIP
2	1	310-4143	GATEWAY, PROFINET-EIP
3	1	310-4144	GATEWAY, DEVICENET-EIP
4	1	310-4145	GATEWAY, CCLINK-EIP
5	1	310-4146	GATEWAY, ETHERCAT-EIP
WIRELESS COMMUNICATION OPTION			
Code-Top Level Column B	QTY	Part No.	Description
0	-	-	-
1, 3	-	310-4170	USB Wifi Module
2, 3	-	310-4171	Exor Cellular Module
2, 3	-	310-4172	Cellular Antenna
2, 3	-	310-4173	Antenna Cable

OUTER ENCLOSURE






OUTER ENCLOSURE			
Item	Qty	Part No.	Description
101	1	-	Control Enclosure Door Frame
102	1	-	Control Enclosure Thermoform
103	1	-	Slotted Door Latch
104	1	-	E-Stop Decal
105	1	310-4127	USB WATERPROOF COVER
106	1	310-4128	CABLE, USB, PANEL MOUNT, 1M CABLE
107	4	310-4129	ETHERNET BULKHEAD, RJ45 FEMALE TO FEMALE
108	6	-	CONNECTOR, BULKHEAD, M12, 5PIN, FEMALE TO LEAD, 1M
109	1	-	BULKHEAD CONNECTOR, 7/8" 5 POLE, FEMALE TO LEAD
110	1	-	LIGHT INDICATOR W/ HORN, 7 COLOR, 10-30VDC,
111	1	240-5159	LOAD SWITCH, 16A, FRONT/DOOR, W/ ACTUATOR
112	1	EX715-CARLISLE	HMI, EX SERIES, 15", W/ CODESYS
113	1	-	SD CARD, 32GB, CDW P/N 3052120, MFG P/N SDSDB-032G-A46
114	1	240-5166	Non-Illuminated Mushroom Operators, Twist to Release, 40 mm,
115	1	240-5167	800F Latch, Plastic Latch, Standard Pack
116	2	310-4103	22.5mm PB No Latch, Screw Contact Block, 1 N.C. Self-monitoring
117	4	-	FERRITE (EMI TOROID 12.2OD x 7x1ID x 12.7MM)

CONTROL BACKPANEL




CONTROL BACKPANEL			
Item	QTY	Part No.	Description
201	1	-	Electronics Back Panel
202	1	310-4116	SAFETY RELAY
203	1	310-4104	ELEC CIRC PROT, 4CH, CLASS 2
204	1	310-4105	ETH SWITCH, UNMANAGED, 8PRT
205	1	-	PLC, 2MB
206	1	-	TERMINAL, SCREW, KIT, 5069 CPU
207	1	310-4147	POWER SUPPLY, 24VDC, 240W, 10A
208	1	240-5176	CIRC. BREAKER, 2 POLE, 5A
209	19	-	BOLT, MOUNTING
210	1	310-4126	LINE FILTER, 6A, 2STAGE
211	41	-	TERMINAL BLOCK
	5	-	GROUND TERMINAL BLOCK
	2	-	TERMINAL BLOCK END
	3	-	TERMINAL BLOCK END - YELLOW
	1	-	JUMPER 2-pole
	1	-	JUMPER 4-pole
	1	-	JUMPER 6-pole
	12	-	END RETAINER
212	1	310-4115	REMOTE I/O, ADAPTER, ETHERNET
213	3	310-4111	REMOTE I/O, 16 PT. DIG. INPUT
214	1	310-4112	REMOTE I/O, 16 PT. DIG. OUTPUT
215	1	310-4114	REMOTE I/O, 8 CH. ANLG INPUT
216	2	310-4113	REMOTE I/O, 2 CH HIGH SPEED IN
217	-	-	-
218	4	-	SPACER FOR BACK PANEL
219	1	-	GROUND STRAP FOR BACK PANEL
220	4	310-4134	CABLE,ETHERNET,5FT
221	4	310-4135	CABLE, ETHERNET, 3FT
222	4 ft	-	Panduit 1 x 4", Gray
223	4 ft	-	Panduit Cover, 1" Gray
224	3 ft	-	DIN Rail, Perforated

PRESSURE REGULATOR MODULES





301.4





304

313






301.8




PRESSURE REGULATOR MODULES				
Code-Top Level Column C	Item	QTY	Part No	Description
0		-	-	-
2	301.4	1	310-3910	PRESSURE MANIFOLD ASSEMBLY, 4 REGULATORS (VTEM-S1-27-E1-B1-Q10-U-Q6-CC-BAP-2PD)
	302	Included w/ manifold	-	COMM MODULE, FOR FESTO VTEM REGULATORS (50E-F36GCQP-P)
	303	1	310-4136	CBL, ETHERNET, RJ45-M12-90, 1M
	304	1	310-4140	CBL, MINI (7/8"), 5P, 2M, F-M
	305	Included w/ 310-3911	UC-3/8	Pneumatic muffler (comes with 310-3911)
	306	1	20-7023	G3/8 - 3/8" Tube VTEM inlet
	307	2	20-7024	G1/8 - 1/4" Tube VTEM to MVR
	308	16	20-7022	G1/8 - 4 mm Tube VTEM to HGB
	309	6	20-7028	VTUG Mounting Bolts
	310	6	20-7026	VTUG Mounting Washers
	311	6	20-7027	VTUG Mounting ToothWashers
	313	1	310-2801	VTEM Mounting Bracket
	4	301.8	1	310-3911
302		Included w/ manifold	-	COMM MODULE, FOR FESTO VTEM REGULATORS (50E-F36GCQP-P)
303		1	310-4136	CBL, ETHERNET, RJ45-M12-90, 1M
304		1	310-4140	CBL, MINI (7/8), 5P, 2M, F-M
305		Included w/ manifold	UC-3/8	Pneumatic muffler (comes with 310-3911)
306		1	20-7023	G3/8 - 3/8" Tube VTEM inlet
307		2	20-7024	G1/8 - 1/4" Tube VTEM to MVR
308		16	20-7022	G1/8 - 4 mm Tube VTEM to HGB
309		6	20-7028	VTUG Mounting Bolts
310		6	20-7026	VTUG Mounting Washers
311		6	20-7027	VTUG Mounting ToothWashers
313		1	310-2801	VTEM Mounting Bracket



PRESSURE REGULATOR MODULES (cont.)




301.4



313







301.8





PRESSURE REGULATOR MODULES (cont.)				
Code-Top Level Column C	Item	QTY	Part No	Description
6	301.4	1	310-3910	PRESSURE MANIFOLD ASSEMBLY, 4 REGULATORS (VTEM-S1-27-E1-B1-Q10-U-Q6-CC-BAP-2PD)
	301.8	1	310-3911	PRESSURE MANIFOLD ASSEMBLY, 8 REGULATORS (VTEM-S1-27-E1-B1-Q10-U-Q6-4C-BAP-4PD)
	302	incl. w/ manifold		COMM MODULE, FOR FESTO VTEM REGULATORS (50E-F36GCQP-P)
	303	1	310-4136	CBL, ETHERNET, RJ45-M12-90, 1M
	304	2	310-4140	CBL, MINI (7/8"), 5P, 2M, F-M
	305	incl. w/ manifold	UC-3/8	Pneumatic muffler (comes with 310-3911)
	306	2	20-7023	G3/8 - 3/8" Tube VTEM inlet
	307	3	20-7024	G1/8 - 1/4" Tube VTEM to MVR
	308	32	20-7022	G1/8 - 4 mm Tube VTEM to HGB
	309	12	20-7028	VTUG Mounting Bolts
	310	12	20-7026	VTUG Mounting Washers
	311	12	20-7027	VTUG Mounting ToothWashers
	312	1	310-4133	CABLE, CAT 5E, M12, 1M
	313	2	310-2801	VTEM Mounting Bracket
8	301.8	2	310-3911	PRESSURE MANIFOLD ASSEMBLY, 8 REGULATORS (VTEM-S1-27-E1-B1-Q10-U-Q6-4C-BAP-4PD)
	302	incl. w/ manifold		COMM MODULE, FOR FESTO VTEM REGULATORS (50E-F36GCQP-P)
	303	1	310-4136	CBL, ETHERNET, RJ45-M12-90, 1M
	304	2	310-4140	CBL, MINI (7/8"), 5P, 2M, F-M
	305	incl. w/ manifold	UC-3/8	Pneumatic muffler (comes with 310-3911)
	306	2	20-7023	G3/8 - 3/8" Tube VTEM inlet
	307	3	20-7024	G1/8 - 1/4" Tube VTEM to MVR
	308	32	20-7022	G1/8 - 4 mm Tube VTEM to HGB
	309	12	20-7028	VTUG Mounting Bolts
	310	12	20-7026	VTUG Mounting Washers
	311	12	20-7027	VTUG Mounting ToothWashers
	312	1	310-4133	CABLE, CAT 5E, M12, 1M
	313	2	310-2801	VTEM Mounting Bracket

SOLENOID MANIFOLDS



408






SOLENOID MANIFOLDS						
Item	QTY				Part No.	Description
-	E=1	E=2	E=3	E=4	-	-
401	1	2	3	4	310-3921	VALVE COMM MODULE, EIP
402	1	2	3	4	310-3920	VALVE, PNEUMATIC MANIFOLD 16PORT-16 DUAL SOLENOIDS (VTUG-10-VRPT-B1T-T516B-UB-QH4SU-16K)
403	1	2	3	4	UC-3/8	Pneumatic muffler (comes with 310-3920)
404	2	4	6	8	20-7022	G1/8 - 4 mm Tube
405	4	8	12	16	20-7028	VTUG Mounting Bolts (M4 20 mm)
406	4	8	12	16	20-7026	VTUG Mounting Washers
407	4	8	12	16	20-7027	VTUG Mounting ToothWashers
408	0	1	2	3	310-4133	CABLE, CAT 5E, M12, 1M
409	1	1	1	1	310-4136	CBL, ETHERNET, RJ45-M12-90, 1M
410	1	2	3	4	310-4148	CBL, M12, 5PIN, 0.3M, 0-90DEG
411	1	2	3	4	310-2800	VTUG Mounting Bracket

FLUID MODULE

WEEPING

(See manual No. LN-9112-00 for additional details)






FLUID MODULE- WEEPING			
Item	QTY	Part No.	Description
1	1	310-3301	FLUID CONTROL PANEL
2	-	TR-SSMM-147	02 WEEPING MVR
2	-	TR-SSMM-148	03 WEEPING MVR
2	-	TR-SSMM-225	04 WEEPING MVR
3	3	4-6JIC	FITTING, 1/4" NPS (M) x 3/8" JIC (F)
4	1	4SN-6JIC	FITTING, 1/4" NPS (F) x 3/8" JIC (M)
5	1	310-2806	MOUNTING BRACKET
6	-	310-9000	GEAR FLOW METER, DUAL PROBE
6	-	310-9001	GEAR FLOW METER, FIBER OPTIC
6	-	A13296	PISTON FLOW METER
7	1	4-6B	FITTING, 1/4" NPS (M) x 3/8" NPS (M)
8	1	4SN-6B	FITTING, 1/4" NPS (M) x 3/8" NPS (M)
9	2	TR-110952	SEAL
10	1	6T-4-90	FITTING, ELBOW, 3/8" NPS (M) x 1/4" NPS (M)
11	1	310-2802	MVR MOUNTING BRACKET
12	1	GA-338	1/8" NPT BACK MOUNT GAUGE (0-160 PSI), 1 1/2" DIA
13	1	JML-14-2T	ELBOW 1/8" NPT (M) x 1/4" ODT
14	1	310-8200	CALIBRATION BLOCK
15	1	CCV-503-SS	CCV VALVE
16	1	JML-532-2T	ELBOW 1/8" NPT (M) x 1/4" ODT
17	1	4T-4T	FITTING, 1/4" NPT (M) x 1/4" NPT (M)
18	1	SSP-6443	FITTING, ELBOW, 1/4" NPT (M) x 3/8" ODT
19	1	LSMM0059-01	CALIBRATION TUBE

FLUID MODULE

WEEPLESS



(See manual No. LN-9225-00 for additional details)





FLUID MODULE - WEEPLESS			
Item	QTY	Part No.	Description
1	1	310-3301	FLUID CONTROL PANEL
2	-	76624-02	02 WEEPING MVR
2	-	76624-03	03 WEEPING MVR
2	-	76624-04	04 WEEPING MVR
3	1	4SN-6JIC	FITTING, 1/4" NPS (F) x 3/8" JIC (F)
4	4	4-6JIC	FITTING, 1/4" NPS (M) x 3/8" JIC (M)
5	1	310-2806	MOUNTING BRACKET
6	-	310-9000	GEAR FLOW METER, DUAL PROBE
6	-	310-9001	GEAR FLOW METER, FIBER OPTIC
6	-	A13296	PISTON FLOW METER
7	1	310-2802	MVR MOUNTING BRACKET
8	1	GA-338	1/8" NPT BACK MOUNT GAUGE (0-160 PSI), 1 1/2" DIA
9	1	JML-14-2T	ELBOW 1/8" NPT (M) x 1/4" ODT
10	1	310-8200	CALIBRATION BLOCK
11	1	CCV-503-SS	CCV VALVE
12	1	JML-532-2T	ELBOW 1/8" NPT (M) x 1/4" ODT
13	1	4T-4T	FITTING, 1/4" NPT (M) x 1/4" NPT (M)
14	1	SSP-6443	FITTING, ELBOW, 1/4" NPT (M) x 3/8" ODT
15	1	LSMM0059-01	CALIBRATION TUBE

FLUID MIX PANEL

2K Low Pressure: Flushable/Non-Flushable



2K LOW PRESSURE FLUSHABLE (-11)







2K LOW PRESSURE NON-FLUSHABLE (-12)

FLUID MIX PANEL-2K LOW PRESSURE: FLUSHABLE/NON-FLUSHABLE						
Item	Part No.	Description	2K Low Pressure Flushable (-11)	2K Low Pressure Non-Flushable (-11)	3K Low Pressure Flushable (-13)	2K High Pressure (-22)
1	310-3807	FLUID MIX PANEL WELDMENT	1	1	1	1
2	78015	2K MIX BLOCK	1	1	2	-
3	22-280	CHECK VALVE ASSEMBLY	2	2	4	-
4	22-285	SEAL	2	2	4	-
5	LSMM0056-00	3/8" ID x 18 ELEMENT MIXER	1	1	2	1
6	LSMM0057-00	MIX TUBE RETAINING KIT	1	1	2	-
7	20-7047	FITTING, 1/2" ODT x 3/8" NPT (F), ACETAL	1	1	2	-
8	6T-4RB	FITTING, 3/9" NPT (M) x 1/4" NPS (M), BULKHEAD	1	1	2	-
9	CCV-503-SS	VALVE ASSEMBLY	1	-	2	-
10	41-FTP-1006	1/8" NPT (M) x 5/32" TUBE ELBOW	1	-	2	-
11	KK-4370	PLUG KIT	-	1	-	-
12	4SN-4-90	FITTING, ELBOW, 1/4" NPS (M) x 1/4" NPS (F)	2	2	4	-
13	20-7016	SPACER, 1/2" OD, 1/4" ID, 3/4" LG	2	2	4	2
14	-	SHCS, 1/4"-20, 1-7/8" LG, 18-8	2	2	4	2
15	-	WASHER, LOCK, 1/4", 18-8	2	2	4	2
16	-	WASHER, FLT, 1/4", 18-8	2	2	4	2
17	310-3808	MIXER MOUNT BRACKET	1	1	2	1
18	-	WASHER, M6, 18-8	2	2	4	2
19	-	WASHER, LOCK, 18-8	2	2	4	2
20	-	SHCS, M6 x 1, 14MM LG, 18-8	2	2	4	2

FLUID MIX PANEL

2K High Pressure & 3K Low Pressure: Flushable Staged Mixing



FLUID MIX PANEL - 2K LOW PRESSURE (FLUSHABLE/NON-FLUSHABLE)						
Item	Part No.	Description	2K Low Pressure Flushable (-11)	2K Low Pressure Non-Flushable (-11)	3K Low Pressure Flushable (-13)	2K High Pressure (-22)
1	310-3807	FLUID MIX PANEL WELDMENT	1	1	1	1
2	78015	2K MIX BLOCK	1	1	2	-
3	22-280	CHECK VALVE ASSEMBLY	2	2	4	-
4	22-285	SEAL	2	2	4	-
5	LSMM0056-00	3/8" ID x 18 ELEMENT MIXER	1	1	2	1
6	LSMM0057-00	MIX TUBE RETAINING KIT	1	1	2	-
7	20-7047	FITTING, 1/2" ODT x 3/8" NPT (F), ACETAL	1	1	2	-
8	6T-4RB	FITTING, 3/9" NPT (M) x 1/4" NPS (M), BULKHEAD	1	1	2	-
9	CCV-503-SS	VALVE ASSEMBLY	1	-	2	-
10	41-FTP-1006	1/8" NPT (M) x 5/32" TUBE ELBOW	1	-	2	-
11	KK-4370	PLUG KIT	-	1	-	-
12	4SN-4-90	FITTING, ELBOW, 1/4" NPS (M) x 1/4" NPS (F)	2	2	4	-
13	20-7016	SPACER, 1/2" OD, 1/4" ID, 3/4" LG	2	2	4	2
14	-	SHCS, 1/4"-20, 1-7/8" LG, 18-8	2	2	4	2
15	-	WASHER, LOCK, 1/4", 18-8	2	2	4	2
16	-	WASHER, FLT, 1/4", 18-8	2	2	4	2
17	310-3808	MIXER MOUNT BRACKET	1	1	2	1
18	-	WASHER, M6, 18-8	2	2	4	2
19	-	WASHER, LOCK, 18-8	2	2	4	2
20	-	SHCS, M6 x 1, 14MM LG, 18-8	2	2	4	2
21	LBAL0016-00	"Y"-BLOCK, 2K	-	-	-	1
22	LBAL0022-00	JACKET, HIGH PRESSURE, FOR DISPOSABLE MIXER	-	-	-	1
23	-		-	-	-	1
24	LBAL0023-00	ADAPTER, FLUID HOSE, HIGH PRESSURE	-	-	-	1
25	240-3133	FITTING, 1/4" NPT (M) x 1/4" NPT (F)	-	-	-	1
26	4T-4RB	FITTING, 1/4" NPT (M) x 1/4" NPS (M), BULKHEAD	-	-	-	1
27	6GTX	FITTING, 1/4" NPT (F) x 3/8" JIC (M)	-	-	-	2
28	SSV-809	CHECK VALVE	-	-	-	2
29	4-4T (F)	FITTING, 1/4" NPS (M) x 1/4" NPT (F)	-	-	-	2

REPAIR KITS (WEAR ITEMS)

REPAIR KITS (WEAR ITEMS)						
PN	Description	Category	Auto LP qty.	MAN LP qty.	Auto HP qty.	MAN HP qty.
KK-4841	CCV Repair Kit, LP	Fluid Panel	5	5	0	0
240-2048	HP CCV Seal Kit, Internal	Fluid Panel	0	0	5	5
240-2048	HP CCV Seal Kit, External	Fluid Panel	0	0	5	5
310-9017-K5	Flow meter Seal Kit, 5 Pack	Fluid Panel	1	1	1	1
77052-00	MVR Repair Kit, Weepless	Fluid Panel	2	0	2	0
TR-SSMM-151	Air Diaphragm, MVR Assembly (Weeping Only)	Fluid Panel	3	0	0	0
78783-00	Compression Spring, MVR (Weeping Only)	Fluid Panel	1	0	0	0
SSG-8125	O-Ring, PTFE (Weeping Only)	Fluid Panel	1	0	0	0
76623-02	#2 MVR Needle, Weepless	Fluid Panel	A/R	0	A/R	0
76623-03	#3 MVR Needle, Weepless	Fluid Panel	A/R	0	A/R	0
76623-04	#4 MVR Needle, Weepless	Fluid Panel	A/R	0	A/R	0
TR-SSMM-149	#2 MVR Needle, Weeping	Fluid Panel	A/R	0	0	0
TR-SSMM-150	#3 MVR Needle, Weeping	Fluid Panel	A/R	0	0	0
TR-SSMM-226	#4 MVR Needle, Weeping	Fluid Panel	A/R	0	0	0
22-280	Check Valve	Fluid Panel	4	4	2	2
SSV-809	Check Valve	Fluid Panel	2	2	4	4
240-2062	Pulse Valve Repair Kit	Fluid Panel	0	2	0	2
6-1306	Repair Kit, HP Fluid Regulator, Manually-Operated	Fluid Panel	0	0	2	2
LSMM0056-00	Static Mixer	Fluid Panel	2	2	2	2
310-3915	Pressure Regulator, Individual Replacement	Fluid Panel	1	1	0	0
310-3925	Solenoid Valve, Individual Replacement	Controller	2	2	2	2

SPARE ASSEMBLIES (RECOMMENDED)

SPARE ASSEMBLIES (RECOMMENDED)						
PN	Description	Category	Auto LP qty.	MAN LP qty.	Auto HP qty.	MAN HP qty.
CCV-503-SS	CCV Valve, LP	Fluid Panel	2	2	0	0
240-2012	CCV Valve, HP	Fluid Panel	0	0	2	2
310-9010	Flow meter Body	Fluid Panel	1	1	1	1
310-9011	Flow meter Dual Probe Pickup	Fluid Panel	1	1	1	1
240-2061	Pulse Valve Assembly	Fluid Panel	0	1	0	1
HGB-510-R1-CO	HGB Fluid Regulator, Air-Piloted	Fluid Panel	1	0	0	0
HGB-609-9-R38	HGB Fluid Regulator, Manually-Operated	Fluid Panel	0	1	0	0
84-420	Manual Fluid Regulator, HP	Fluid Panel	0	0	1	1
76624-02	MVR Assembly, #2 Weepless	Fluid Panel	A/R	0	A/R	0
76624-03	MVR Assembly, #3 Weepless	Fluid Panel	A/R	0	A/R	0
76624-04	MVR Assembly, #4 Weepless	Fluid Panel	A/R	0	A/R	0
TR-SSMM-147	MVR Assembly, #2 Weeping	Fluid Panel	A/R	0	0	0
TR-SSMM-148	MVR Assembly, #3 Weeping	Fluid Panel	A/R	0	0	0
TR-SSMM-225	MVR Assembly, #4 Weeping	Fluid Panel	A/R	0	0	0
78015-00	Mix Manifold Assembly, LP, With Solvent Flush	Fluid Panel	1	1	0	0
LBAL0016-00	Mix Manifold Assembly, HP	Fluid Panel	0	0	1	1

TROUBLESHOOTING

Although the RF2 is a complex machine, troubleshooting the unit is straightforward, with a few basic steps.

ALARM LIST

The alarm dialog is the first indication that something may be wrong with the RF2 control processes. Below is a list of alarms and troubleshooting steps.

ALARM DESCRIPTION	DETAILS & TROUBLESHOOTING TIPS
Safety Fault	<p>The safety circuit for the RF2 is open, operation is not possible</p> <p>This fault most occurs in conjunction with other alarms, such as an E-Stop pressed, fire-detect, etc. Address any of these faults before troubleshooting further.</p> <p>If no other fault is present with this one, check the wiring of the safety relay. See schematics for more details.</p>
E-Stop PB Pressed	<p>The E-Stop on the front of the RF2 control enclosure has been pressed.</p> <p>Pull the emergency stop pushbutton to reset the alarm</p>
Festo VTEM Pressure Regulator Module (x) Fault	<p>The indicated module (x) has on the Festo pressure regulator manifold has a fault.</p> <p>Most often, this alarm will occur at the same time as all other pressure regulator modules. This is most often caused by a lack of input air pressure being fed to the manifold.</p> <p>Make sure main air pressure is turned on.</p> <p>Press "Reset" button on the main HMI.</p> <p>If the fault persists, see section on troubleshooting the pressure regulator manifold further.</p>
Comm Loss with Master Controller	<p>After having been established, communications between the supervisory (master) PLC and the RF2 has been interrupted.</p> <p>Check master process controller for proper operation.</p> <p>Power cycle the RF2</p> <p>Check cabling between master controller and RF2 unit.</p>
Comm Loss with Aux. Communications Gateway	<p>The AnyBus gateway installed, and communications between it and the RF2 controller have been interrupted.</p> <p>Power cycle the RF2</p> <p>Check cabling between the RF2 and the AnyBus gateway.</p>
Station (x)-Recipe Update Failed	<p>The indicated station (x) has had a failure in loading a recipe (timeout occurred).</p> <p>Try loading the recipe again.</p> <p>Power cycle the RF2</p> <p>Contact Technical Support</p>

ALARM DESCRIPTION	DETAILS & TROUBLESHOOTING TIPS
Station (x)-Fluid Sequence Failed	The indicated station (x) has experienced a failed (incomplete) fluid sequence. Material may not be properly loaded or purged from the system.
	This occurs when an interlock is lost during a sequence. Check all wired interlocks to make sure these are not turning on at inappropriate times.
	Check other alarms that may have occurred in conjunction with this for more detailed cause analysis. Retry running the fluid sequence
Station (x)-Solvent Flow Low	The indicated station (x) has run a sequence, and detected not enough solvent flow in comparison to the solvent check settings.
	Make sure solvent supply is adequate and not restricted. Check Solvent Flow Meter
	Check timing of fluid sequence to make sure that solvent flow occurs for enough time to flush the system.
Pot Life Expired	The material pot life for the indicated Gun/Mixer has elapsed.
	If safe to do so, trigger the gun/mixer in order to allow fresh material into the system-OR flush the system.
Ratio Out Of Tolerance	The RF2 has calculated that the ratio of mixtures A:B or %C has deviated by more than the allowed tolerance.
	Determine if fluid delivery is ok, fluid pressures are correctly set, etc.
	Check for restrictions in any of the fluid channels.
	Check material viscosity for abnormalities Check recipe settings for ratio tolerance.
Flow Rate Out Of Tolerance	The RF2 has calculated that the overall flow rate is out of tolerance.
	Determine if fluid delivery is ok, fluid pressures are correctly set, etc.
	Check for restrictions in any of the fluid channels.
	Check material viscosity for abnormalities Check recipe settings for flow tolerance
Ratio Shutdown	A Ratio Out Of Tolerance fault has been generated, shutting down the station.
	Determine if fluid delivery is ok, fluid pressures are correctly set, etc.
	Check for restrictions in any of the fluid channels.
	Check material viscosity for abnormalities
	Check recipe settings for ratio tolerance. See the alarm-masking instructions to disable the shutdown of the system for this fault.

ALARM DESCRIPTION	DETAILS & TROUBLESHOOTING TIPS
Flow Rate Shutdown	<p>A Flow Rate Out Of Tolerance Fault has occurred, shutting down the station.</p> <p>Determine if fluid delivery is ok, fluid pressures are correctly set, etc.</p> <p>Check for restrictions in any of the fluid channels.</p> <p>Check material viscosity for abnormalities</p> <p>Check recipe settings for flow tolerance</p> <p>See the alarm-masking instructions to disable the shutdown of the system for this fault.</p>
Channel (x)-Outlet Underpressure	<p>The indicated channel (x) has detected low pressure on its outlet pressure sensor (applicable only for gear-pump controlled channels).</p> <p>Determine if fluid delivery is ok, fluid pressures are correctly set, etc.</p> <p>Check for restrictions in the tubing feeding this channel.</p> <p>Check material viscosity for abnormalities</p> <p>Check settings for low pressure.</p> <p>Check pressure sensor scaling/operation.</p>
Channel (x)-Outlet Overpressure	<p>The indicated channel (x) has detected high pressure on its outlet pressure sensor (applicable only for gear-pump controlled channels). This event will cause a spray-shutdown.</p> <p>The indicated channel (x) has detected low pressure on its outlet pressure sensor (applicable only for gear-pump controlled channels).</p> <p>Determine if fluid delivery is ok, fluid pressures are correctly set, etc.</p> <p>Check for restrictions in the tubing downstream from this channel.</p> <p>Check material viscosity for abnormalities</p> <p>Check settings for high pressure.</p> <p>Check settings for trigger timing</p> <p>Check pressure sensor scaling / operation.</p>
Channel (x)-Inlet Underpressure	<p>The indicated channel (x) has detected low pressure on its inlet pressure sensor (applies only to the gear-pump controlled channels).</p> <p>Determine if fluid delivery is ok, fluid pressures are correctly set, etc.</p> <p>Check for restrictions in the tubing feeding this channel.</p> <p>Check material viscosity for abnormalities</p> <p>Check settings for low pressure.</p> <p>Check pressure sensor scaling/operation.</p>
Channel (x)-Inlet Overpressure	<p>The indicated channel (x) has detected high pressure on its inlet pressure sensor (applicable only for gear-pump controlled channels).</p> <p>Determine if fluid delivery is ok, fluid pressures are correctly set, etc.</p> <p>Check for restrictions in the tubing feeding this channel.</p> <p>Check material viscosity for abnormalities</p> <p>Check settings for high pressure.</p> <p>Check pressure sensor scaling/operation.</p>


ALARM DESCRIPTION	DETAILS & TROUBLESHOOTING TIPS
Channel (x)-Low Flow	<p>RF2 has determined flow rate for this channel is low.</p> <p>Determine if fluid delivery is ok, fluid pressures are correctly set, etc.</p> <p>Check for restrictions in any of the fluid channels.</p> <p>Check material viscosity for abnormalities</p> <p>Check recipe settings for flow tolerance</p> <p>Check Flow Sensor Calibration/Operation</p>
Channel (x)-High Flow	<p>RF2 has determined flow rate for this channel is high.</p> <p>Determine if fluid delivery is ok, fluid pressures are correctly set, etc.</p> <p>Check for restrictions in any of the fluid channels.</p> <p>Check material viscosity for abnormalities</p> <p>Check recipe settings for flow tolerance</p> <p>Check Flow Sensor Calibration/Operation</p>
Channel (x)-Flow Feedback Loss	<p>Zero flow is detected by the RF2 for the indicated channel (x)</p> <p>Determine if fluid delivery is ok, fluid pressures are correctly set, etc.</p> <p>Check for restrictions in any of the fluid channels.</p> <p>Check material viscosity for abnormalities</p> <p>Check recipe settings for flow tolerance</p> <p>Check Flow Sensor Calibration/Operation</p>
Channel (x)-Spray Shutdown	<p>The indicated channel (x) has caused a spray shutdown, due to a flow or feedback fault that has been configured to shut down the system.</p> <p>Address other channel faults that occurred in conjunction with this fault.</p> <p>See the alarm-masking instructions to disable the shutdown of the system for this fault.</p>
Channel (x)-Reverse Flow Detected	<p>The RF2 has detected flow in the reverse direction, exceeding the reverse-flow volume setting. This will cause a spray shutdown.</p> <p>Inspect check-valves on mix manifold and color stacks.</p> <p>Check wiring to flow meter</p> <p>Check trigger timing settings</p> <p>Check settings for reverse flow volume. It is normal to detect a small reverse reading when triggering off, as the fluid may create a wave in the reverse direction momentarily. This condition does not indicate fluid has passed beyond the check valve.</p>
Channel (x)-Inlet Pressure Loss of Feedback	<p>If an inlet pressure sensor is configured (gear-pump systems only), the RF2 has detected no feedback from the inlet pressure sensor.</p> <p>Check pressure sensor scaling/operation.</p>
Channel (x)-Outlet Pressure Loss of Feedback	<p>If an outlet pressure sensor is configured (gear-pump systems only), the RF2 has detected no feedback from the outlet pressure sensor.</p> <p>Check pressure sensor scaling/operation.</p>

ALARM DESCRIPTION	DETAILS & TROUBLESHOOTING TIPS
Channel (x)-Flow Out Of Range	The flow actuator (MVR or DR1) is operating at its maximum pilot pressure signal, but flow rate is low. Check that the desired flow rate is attainable given the system flow restrictions (gun tip settings, tubing size and lengths, etc.) Check material viscosity for abnormalities
Channel (x)-Unconfigured Inlet Pressure Pilot	The indicated channel has been configured with inlet pressure control, but no pressure regulator has been assigned for this purpose. Check System Configuration Settings
Channel (x)-Unconfigured Flow Pressure Pilot	No flow rate pilot signal has been assigned to a regulator. Check System Configuration Settings

TROUBLESHOOTING—FESTO VTEM PRESSURE REGULATOR MANIFOLD

If an issue with the Festo VTEM Pressure regulator manifold occurs, the unit can access more detailed troubleshooting.


First locate the RJ45 port (1) used to configure the VTEM module, then connect a PC to this port.



Set the IP address of the connected PC to 101.1.1.99.

Open a web browser and enter 101.1.1.38 (a)

To troubleshoot a module, click the configuration tab (b).




Click on any module to select it (c).

Select the monitor tab (d) to show a list of malfunctions (e).


The example below shows that the supply pressure is too low (f).

If the fluid panels for the RF2 are installed too far from the unit, tune the pressure regulators. To do this, press the login key (g) and enter the password (h) to log into the VTEM unit.

The factory default password is "vtem." DO NOT change this password.




Once logged in, select the overview tab (i) and the module (j) to edit. It is necessary to "Take Write Permissions from the PLC" (k) to make any changes. Changes are not permitted when the PLC is in communication with the VTEM manifold, so the M12 Ethernet cable at the front of the manifold must be unplugged to select the box below.



To change the tune, determine the labeled module port (4 or 2) to be connected to the tube type. Select the small, medium, or large volume setting from the dropdown menu to change the "Characteristic" (m) parameter. Additionally, the regulator can be custom tuned.

When edits are made, select "Accept values for configuration" (n), then press "Save Configurations" (o). If the configuration is not saved, the unit will revert to its earlier settings upon start-up.




TROUBLESHOOTING—FESTO VTUG SOLENOID MANIFOLD

To replace a defective pressure regulator module, loosen the bolts on the module, then pull the module directly out. Make sure the new module's gasket is correctly located in its channel, and press it down and into the open slot. Tighten the bolts, but do not tightly squeeze the gasket.

Consult Festo VTEM operations manual for more details.

WARNING

Make sure the air is disconnected before attempting to remove a solenoid module.



- The RF2 can control up to four solenoid modules. These modules can be installed later in the field if not initially installed in the purchased configuration. Each manifold (1-4) must be set to a specific IP address as listed below:
- Manifold #1: 101.1.1.30
- Manifold #2: 101.1.1.31
- Manifold #3: 101.1.1.32
- Manifold #4: 101.1.1.33
- Subnet mask for all manifolds is 255.255.255.0

To set the IP address—do the following:

1. Remove the cover to access the dip switches on the front of the CTEU-EP communications module on the solenoid manifold.
2. Set the dip switches for the last octet of the IP address.
3. Connect a PC to the ethernet port of the CTEU, or connect through an ethernet switch. Set the laptop to IP address 192.168.1.99




From left to right.

1-1 = least significant bit.


2-2 = most significant bit

Leave 2-3 – 2-6 at zero.

- 4. Open "Festo Field Device Tool" software. This can be downloaded from Festo's website.
- 5. Scan (a) the network and find the module (b) you wish to modify. Highlight it and select "Network" (c).



- 6. Change the IP settings (d) to 101.1.1.x (from list specified in the previous page).



- 7. Click OK
- 8. Return PC IP Address to normal, re-cover the dip-switches.

APPENDIX


FIELDBUS I/O

There are two methods for communicating to the RF2 over fieldbus.


- Direct CIP access to tag arrays given below. No gateway is used.
 - RF2 Input Array (PLC -> RF2):
 - AuxInArr (SINT 496)
 - RF2 Output Arrays (RF2 -> PLC):
 - AuxOutArr1 (SINT 496)
 - AuxOutArr2 (SINT 496)
- Access through AnyBus gateway (if purchased).
 - In this method, the communications protocol is converted from the customer’s side to Ethernet/IP on the RF2 side. Tag registers within the RF2 are overwritten by the tags communicated through the gateway.

Carlisle can provide sample or importable code for Rockwell software solutions for both methods above.

Datatypes that are in the form of BOOL, integer (INT), double integer (DINT), or Floating Point (REAL), are represented by varying amounts of bytes. The code used in the master controller must take this into account – for example:



The above code copies a real value into 4 bytes.



The above code copies 4 bytes into a real value.

NOTE

The examples shown above are Allen Bradley software. Other PLC software can have different methods to accomplish datatype conversions.

Communications Handshake: The RF2 will fault if it detects a connection has been lost between its master controller and itself after communications has been established. It detects communications through a handshaking word which it increments after the master controller has echoed it back. The master controller communicating must set its output byte #1 equal to its input byte #1 continuously.

Direct Access/CIP Communications

If an Allen Bradley Logix PLC is used, or another controller where direct access to the RF2 input and output arrays (AuxInArr, AuxOutArr1, AuxOutArr2) is possible, no gateway or special hardware is needed to communicate to the RF2. All the RF2 communications arrays are in the form of 496 SINT Data types.

CIP Message Setup

To make the RF2 as flexible as possible in being able to communicate to as many devices as possible, with different IP address configurations, etc. All communications are handled by the master controller, and the RF2 simply contains the tag arrays used for the transfer. Examples of Allen Bradley message setups are shown below.

Note: The code examples below will be put into the master PLC. Other PLCs or systems can use different methods to get the data into the RF2's tag arrays.



RF2 Node Setup in an Allen Bradley PLC.

IP Address: Set to IP assigned to the A2 port of the RF2s Compact Logix PLC. See "Setting the IP Address for Fieldbus Communications (No Gateway)" in the Installation Chapter for more details.


The image shows a software interface for configuring a message. On the left, a dialog box titled "Message Configuration - cftRF2Write" is open. It has three tabs: "Configuration", "Communication", and "Tag". The "Configuration" tab is active, showing the following settings: Message Type: CIP Data Table Write; Source Element: cftWriteArr; Number Of Elements: 496; Destination Element: AuxInArr. Below these are radio buttons for "Enable", "Enable Waiting", "Start", and "Done", with "Done Length: 0" and "Timed Out" checkbox. The "Communication" tab is also visible, showing "Path: RF2", "Broadcast" dropdown, and "Communication Method" with "CIP" selected and "Channel: 'A'".

On the right, a portion of a ladder logic diagram is visible. A red circle with the letter 'a' points to a blue box labeled "MSG" containing "Message Control cftRF2Write [...]". To its right are three output lines labeled (EN), (DN), and (ER). Below this is a "MOV" instruction with "Source cftRF2Read1Arr[495]" and "Dest cftWriteArr[495]".

RF2 Input Array (Master PLC Write) (a)



RF2 Output Array 1 (Master PLC Read) (b)



RF2 Output Array 2 (Master PLC Read) (c)

Message Polling: It is recommended to poll the messages on a periodic interval. In the example code the RF2 Inputs and Outputs are offset by 20 milliseconds. Note—it is not always necessary to receive both RF2 Output Arrays—the second array is used only if active recipe data is being communicated, which is not required for running the RF2.

The RF2 Communications arrays represent the following data:

RF2 INPUT ARRAY - SINT 496			
Address	Length	Datatype	Description
0	1 Byte	SINT	System Control Byte 0-See Detail Below
1	1 Byte	SINT	Handshake Word
2	1 Byte	SINT	Station 1 Control Byte 0-See Detail Below
3	1 Byte	SINT	Station 1 Control Byte 1-See Detail Below
4, 5	2 Byte	INT	Station 1 Job Select (1-250). This job will be loaded when the Station Job Strobe bit is activated.
6	1 Byte	SINT	Station 2 Control Byte 0-See Detail Below
7	1 Byte	SINT	Station 2 Control Byte 1-See Detail Below
8, 9	2 Byte	INT	Station 2 Job Select (1-250). This job will be loaded when the Station Job Strobe bit is activated.
10	1 Byte	SINT	Station 3 Control Byte 0-See Detail Below
11	1 Byte	SINT	Station 3 Control Byte 1-See Detail Below
12, 13	2 Byte	INT	Station 3 Job Select (1-250). This job will be loaded when the Station Job Strobe bit is activated.
14	1 Byte	SINT	Station 4 Control Byte 0-See Detail Below
15	1 Byte	SINT	Station 4 Control Byte 1-See Detail Below
16, 17	2 Byte	INT	Station 4 Job Select (1-250). This job will be loaded when the Station Job Strobe bit is activated.
19, 39		SINT	RESERVED
40	1 Byte	SINT	Gun/Mix 1 Trigger
41	1 Byte	SINT	RESERVED FOR ADDL MIX CTRL
42, 43	2 Byte	INT	Gun/Mix 1 Flow Command (0-3500 cc)
44	1 Byte	SINT	Gun/Mix 2 Trigger
45	1 Byte	SINT	RESERVED FOR ADDL MIX CTRL
46, 47	2 Byte	INT	Gun/Mix 2 Flow Command (0-3500 cc)
48	1 Byte	SINT	Gun/Mix 3 Trigger
49	1 Byte	SINT	RESERVED FOR ADDL MIX CTRL

RF2 INPUT ARRAY - SINT 496 (cont.)

Address	Length	Datatype	Description
50, 51	2 Byte	INT	Gun/Mix 3 Flow Command (0-3500 cc)
52	1 Byte	SINT	Gun/Mix 4 Trigger
53	1 Byte	SINT	RESERVED FOR ADDL MIX CTRL
54, 55	2 Byte	INT	Gun/Mix 4 Flow Command (0-3500 cc)
56	1 Byte	SINT	Gun/Mix 5 Trigger
57	1 Byte	SINT	RESERVED FOR ADDL MIX CTRL
58, 59	2 Byte	INT	Gun/Mix 5 Flow Command (0-3500 cc)
60	1 Byte	SINT	Gun/Mix 6 Trigger
61	1 Byte	SINT	RESERVED FOR ADDL MIX CTRL
62, 63	2 Byte	INT	Gun/Mix 6 Flow Command (0-3500 cc)
64	1 Byte	SINT	Gun/Mix 7 Trigger
65	1 Byte	SINT	RESERVED FOR ADDL MIX CTRL
66, 67	2 Byte	INT	Gun/Mix 7 Flow Command (0-3500 cc)
68	1 Byte	SINT	Gun/Mix 8 Trigger
69	1 Byte	SINT	RESERVED FOR ADDL MIX CTRL
70, 71	2 Byte	INT	Gun/Mix 8 Flow Command (0-3500 cc)
72	1 Byte	SINT	Request Totals-Gun/Mix (1-8=View Totals for Gun/Mix 1-8)
73	1 Byte	SINT	Request Totals-Time Range (0 = Grand, 1 = Yearly, 2 = Monthly, 3 = Weekly, 4 = Daily, 5 = Hourly)
74, 75	2 Byte	INT	Request Totals-Job (0 = All Jobs, 1-250 = Job 1-250)

RF2 INPUT ARRAY -SINT 496 (cont.)

Address	Length	Datatype	Description
76, 99	-	SINT	Reserved
100, 101	2 Byte	INT	Read Register #1 Tag ID
102, 103	2 Byte	INT	Read Register #2 Tag ID
104, 105	2 Byte	INT	Read Register #3 Tag ID
106, 107	2 Byte	INT	Read Register #4 Tag ID
108, 109	2 Byte	INT	Read Register #5 Tag ID
110, 111	2 Byte	INT	Read Register #6 Tag ID
112, 113	2 Byte	INT	Read Register #7 Tag ID
114, 115	2 Byte	INT	Read Register #8 Tag ID
116, 117	2 Byte	INT	Read Register #9 Tag ID
118, 119	2 Byte	INT	Read Register #10 Tag ID
120, 139	-	Byte	RESERVED
140, 141	2 Byte	INT	Write Register #1 Tag ID
142, 143	2 Byte	INT	Write Register #2 Tag ID
144, 145	2 Byte	INT	Write Register #3 Tag ID
146, 147	2 Byte	INT	Write Register #4 Tag ID
148, 149	2 Byte	INT	Write Register #5 Tag ID
150, 151	2 Byte	INT	Write Register #6 Tag ID
152, 153	2 Byte	INT	Write Register #7 Tag ID
154, 155	2 Byte	INT	Write Register #8 Tag ID
156, 157	2 Byte	INT	Write Register #9 Tag ID
158, 159	2 Byte	INT	Write Register #10 Tag ID
160, 179	-	Byte	RESERVED
180, 183	4 Byte	DINT/REAL	Write Register #1 Data (Real or DINT) format

RF2 INPUT ARRAY - SINT 496 (cont.)

Address	Length	Datatype	Description
184, 187	4 Byte	DINT/REAL	Write Register #2 Data (Real or DINT) format
188, 191	4 Byte	DINT/REAL	Write Register #3 Data (Real or DINT) format
192, 195	4 Byte	DINT/REAL	Write Register #4 Data (Real or DINT) format
196, 199	4 Byte	DINT/REAL	Write Register #5 Data (Real or DINT) format
200, 203	4 Byte	DINT/REAL	Write Register #6 Data (Real or DINT) format
204, 207	4 Byte	DINT/REAL	Write Register #7 Data (Real or DINT) format
208, 211	4 Byte	DINT/REAL	Write Register #8 Data (Real or DINT) format
212, 215	4 Byte	DINT/REAL	Write Register #9 Data (Real or DINT) format
216, 219	4 Byte	DINT/REAL	Write Register #10 Data (Real or DINT) format
220, 259	-	Byte	RESERVED
260	1 Byte	SINT	User Input Bits (0..7 = Input 1-8)
261	1 Byte	SINT	User Input Bits (0..7 = Input 9-16)
262	1 Byte	SINT	User Input Bits (0..7 = Input 17-24)
263	1 Byte	SINT	User Input Bits (0..7 = Input 25-32)
264, 495	-	-	Reserved

SYSTEM CONTROL BYTE 0

Address	Length	Datatype	Description
0.0	1 Bit	Bool	Fault Reset
0.1	1 Bit	Bool	Spare
0.2	1 Bit	Bool	Spare
0.3	1 Bit	Bool	Spare
0.4	1 Bit	Bool	Spare
0.5	1 Bit	Bool	Spare
0.6	1 Bit	Bool	Spare
0.7	1 Bit	Bool	Spare

SYSTEM CONTROL BYTE 0

Address	Length	Datatype	Description
x.0	1 Bit	Bool	Strobe Job
x.1	1 Bit	Bool	Purge
x.2	1 Bit	Bool	Spare
x.3	1 Bit	Bool	Seq Run Bit *
x.4	1 Bit	Bool	Seq Select Bit 0 *
x.5	1 Bit	Bool	Seq Select Bit 1 *
x.6	1 Bit	Bool	Seq Select Bit 2 *
x.7	1 Bit	Bool	Seq Select Bit 3 *

*When Seq Run Bit is active, the selected sequence is the binary representation of the Seq Select Bits. A value of 0-15 will call sequence 1-16 in the sequence list.

SYSTEM CONTROL BYTE 1

Address	Length	Datatype	Description
x.0	1 Bit	Bool	Run Mode Pulse
x.1	1 Bit	Bool	Halt Pulse
x.2	1 Bit	Bool	Spare
x.3	1 Bit	Bool	Spare
x.4	1 Bit	Bool	Spare
x.5	1 Bit	Bool	Spare
x.6	1 Bit	Bool	Spare
x.7	1 Bit	Bool	Spare

GUN/MIX TRIGGER WORD

Address	Length	Datatype	Description
x.0	1 Bit	Bool	Trigger 1
x.1	1 Bit	Bool	Trigger 2
x.2	1 Bit	Bool	Trigger 3
x.3	1 Bit	Bool	Trigger 4
x.4	1 Bit	Bool	Spare
x.5	1 Bit	Bool	Spare
x.6	1 Bit	Bool	Spare
x.7	1 Bit	Bool	Spare

RF2 OUTPUT ARRAY 1-SINT 496			
Address	Length	Datatype	Description
0	1 Byte	SINT	System Status Byte 0-See Detail Below
1	1 Byte	SINT	Handshake word
2	1 Byte	SINT	Station 1 Status Byte 0-See Detail Below
3	1 Byte	SINT	Reserved
4, 5	2 Byte	INT	Station 1 Active Recipe (1-250), 0 = No Recipe Loaded
6	1 Byte	SINT	Station 2 Status Byte 0-See Detail Below
7	1 Byte	SINT	Reserved
8, 9	2 Byte	INT	Station 2 Active Recipe (1-250), 0 = No Recipe Loaded
10	1 Byte	SINT	Station 3 Status Byte 0-See Detail Below
11	1 Byte	SINT	Reserved
12, 13	2 Byte	INT	Station 3 Active Recipe (1-250), 0 = No Recipe Loaded
14	1 Byte	SINT	Station 4 Status Byte 0-See Detail Below
15	1 Byte	SINT	Reserved
16, 17	2 Byte	INT	Station 4 Active Recipe (1-250), 0 = No Recipe Loaded
18, 19	-	-	Reserved
20	1 Byte	SINT	Gun/Mix ID (Status Data cycled)
21	1 Byte	SINT	Selected Gun/Mix Status Byte (See Below)
22	1 Byte	SINT	Reserved
23, 26	4 Byte	REAL	Selected Gun/Mix Total Flow
27, 30	4 Byte	REAL	Selected Gun/Mix Component A Flow
31, 34	4 Byte	REAL	Selected Gun/Mix Component B Flow
35, 38	4 Byte	REAL	Selected Gun/Mix Component C Flow
39, 42	4 Byte	REAL	Selected Gun/Mix Actual Ratio A
43, 46	4 Byte	REAL	Selected Gun/Mix Actual Ratio B
47, 50	4 Byte	REAL	Selected Gun/Mix Actual Ratio C
51, 79	-	-	Reserved
80	1 Byte	SINT	Channel ID (Status Data cycled)
82	1 Byte	SINT	Selected Channel Status Word 1 (see table below)
83	1 Byte	SINT	Selected Channel Status Word 2 (see table below)
84, 87	4 Byte	REAL	Selected Channel Inlet Pressure
88, 91	4 Byte	REAL	Selected Channel Outlet Pressure
92, 95	4 Byte	REAL	Selected Channel Actual Flow
96, 99	4 Byte	REAL	Selected Channel Flow Command
100, 103	4 Byte	REAL	Selected Channel Inlet Pressure Pilot
104, 107	4 Byte	REAL	Selected Channel Flow Pilot Signal
108, 111	4 Byte	REAL	Selected Channel Motor RPM (Future)

RF2 OUTPUT ARRAY 1-SINT 496 (cont.)

Address	Length	Datatype	Description
112, 115	4 Byte	REAL	Selected Channel Pulse Rate (Future)
116, 159	-	-	Reserved
160, 161	2 Byte	INT	Read Data Register #1-ID Echo
162, 163	2 Byte	INT	Read Data Register #2-ID Echo
164, 165	2 Byte	INT	Read Data Register #3-ID Echo
166, 167	2 Byte	INT	Read Data Register #4-ID Echo
168, 169	2 Byte	INT	Read Data Register #5-ID Echo
170, 171	2 Byte	INT	Read Data Register #6-ID Echo
172, 173	2 Byte	INT	Read Data Register #7-ID Echo
174, 175	2 Byte	INT	Read Data Register #8-ID Echo
176, 177	2 Byte	INT	Read Data Register #9-ID Echo
178, 179	2 Byte	INT	Read Data Register #10-ID Echo
180, 199	-	-	Reserved
200, 203	4 Byte	DINT/REAL	Read Data Register #1
204, 207	4 Byte	DINT/REAL	Read Data Register #2
208, 211	4 Byte	DINT/REAL	Read Data Register #3
212, 215	4 Byte	DINT/REAL	Read Data Register #4
216, 219	4 Byte	DINT/REAL	Read Data Register #5
220, 223	4 Byte	DINT/REAL	Read Data Register #6
224, 227	4 Byte	DINT/REAL	Read Data Register #7
228, 231	4 Byte	DINT/REAL	Read Data Register #8
232, 235	4 Byte	DINT/REAL	Read Data Register #9
236, 239	4 Byte	DINT/REAL	Read Data Register #10
240, 279	-	-	Reserved
280	1 Byte	SINT	Alarm Word 0-Byte 0
281	1 Byte	SINT	Alarm Word 0-Byte 1
282	1 Byte	SINT	Alarm Word 0-Byte 2
283	1 Byte	SINT	Alarm Word 0-Byte 3
284	1 Byte	SINT	Alarm Word 1-Byte 0
285	1 Byte	SINT	Alarm Word 1-Byte 1
286	1 Byte	SINT	Alarm Word 1-Byte 2
287	1 Byte	SINT	Alarm Word 1-Byte 3
288	1 Byte	SINT	Alarm Word 2-Byte 0
289	1 Byte	SINT	Alarm Word 2-Byte 1
290	1 Byte	SINT	Alarm Word 2-Byte 2
291	1 Byte	SINT	Alarm Word 2-Byte 3

RF2 OUTPUT ARRAY 1-SINT 496 (cont.)

Address	Length	Datatype	Description
292	1 Byte	SINT	Alarm Word 3-Byte 0
293	1 Byte	SINT	Alarm Word 3-Byte 1
294	1 Byte	SINT	Alarm Word 3-Byte 2
295	1 Byte	SINT	Alarm Word 3-Byte 3
296	1 Byte	SINT	Alarm Word 4-Byte 0
297	1 Byte	SINT	Alarm Word 4-Byte 1
298	1 Byte	SINT	Alarm Word 4-Byte 2
299	1 Byte	SINT	Alarm Word 4-Byte 3
300	1 Byte	SINT	Alarm Word 5-Byte 0
301	1 Byte	SINT	Alarm Word 5-Byte 1
302	1 Byte	SINT	Alarm Word 5-Byte 2
303	1 Byte	SINT	Alarm Word 5-Byte 3
304	1 Byte	SINT	Alarm Word 6-Byte 0
305	1 Byte	SINT	Alarm Word 6-Byte 1
306	1 Byte	SINT	Alarm Word 6-Byte 2
307	1 Byte	SINT	Alarm Word 6-Byte 3
308	1 Byte	SINT	Alarm Word 7-Byte 0
309	1 Byte	SINT	Alarm Word 7-Byte 1
310	1 Byte	SINT	Alarm Word 7-Byte 2
311	1 Byte	SINT	Alarm Word 7-Byte 3
312	1 Byte	SINT	Alarm Word 8-Byte 0
313	1 Byte	SINT	Alarm Word 8-Byte 1
314	1 Byte	SINT	Alarm Word 8-Byte 2
315	1 Byte	SINT	Alarm Word 8-Byte 3
316	1 Byte	SINT	Alarm Word 9-Byte 0
317	1 Byte	SINT	Alarm Word 9-Byte 1
318	1 Byte	SINT	Alarm Word 9-Byte 2
319	1 Byte	SINT	Alarm Word 9-Byte 3
320..336	-	-	Reserved
337	1 Byte	SINT	Fluid Usage Data-Gun Selected Echo
338	1 Byte	SINT	Fluid Usage Data-Time Range Echo
339, 340	2 Byte	INT	Fluid Usage Data-Job Select Echo
341..344	4 Byte	Real	Fluid Usage Data-Selected Data-Mat. A
345..348	4 Byte	Real	Fluid Usage Data-Selected Data-Mat. B

RF2 OUTPUT ARRAY 1-SINT 496 (cont.)

Address	Length	Datatype	Description
349..352	4 Byte	Real	Fluid Usage Data-Selected Data-Mat. C
353..356	4 Byte	Real	Fluid Usage Data-Selected Data-Mat. Total
357..360	4 Byte	Real	Fluid Usage Data-Selected Data-Clean
361..495	133 Byte	-	Reserved

SYSTEM STATUS BYTE 0 (WORD 0)

Address	Length	Datatype	Description
0.0	1 Bit	Bool	Comm Heartbeat
0.1	1 Bit	Bool	Fault Exists
0.2	1 Bit	Bool	Data Stable (Mix/Channel Status Data Stable)
0.3	1 Bit	Bool	Spare
0.4	1 Bit	Bool	Spare
0.5	1 Bit	Bool	Spare
0.6	1 Bit	Bool	Spare
0.7	1 Bit	Bool	Spare

SYSTEM STATUS BYTE 0 (WORD 2,6,10,14)

Address	Length	Datatype	Description
0.0	1 Bit	Bool	Run Mode
0.1	1 Bit	Bool	Spare
0.2	1 Bit	Bool	Fluid Sequence Active
0.3	1 Bit	Bool	HV Enable
0.4	1 Bit	Bool	Spare
0.5	1 Bit	Bool	Spare
0.6	1 Bit	Bool	Spare
0.7	1 Bit	Bool	Spare

GUN/MIXER STATUS BYTE (WORD 21-MIXER DATA FROM WORD 20)

Address	Length	Datatype	Description
0.0	1 Bit	Bool	Trigger 1
0.1	1 Bit	Bool	Trigger 2
0.2	1 Bit	Bool	Trigger 3
0.3	1 Bit	Bool	Trigger 4
0.4	1 Bit	Bool	Spare
0.5	1 Bit	Bool	Pot Life Expired
0.6	1 Bit	Bool	Warning
0.7	1 Bit	Bool	Spray Shutdown

CHANNEL STATUS BYTE 0 (WORD 82- CHANNEL DATA FROM WORD 80)			
Address	Length	Datatype	Description
0.0	1 Bit	Bool	Flow Started
0.1	1 Bit	Bool	Calibration Active
0.2	1 Bit	Bool	Manual Override Active
0.3	1 Bit	Bool	Spare
0.4	1 Bit	Bool	Spare
0.5	1 Bit	Bool	Spare
0.6	1 Bit	Bool	Spare
0.7	1 Bit	Bool	Spare

The RF2 Communications arrays represent the following Data

Communications via AnyBus gateway

If purchased, the RF2 may come equipped with an AnyBus gateway which uses Ethernet/IP on the RF2 network, and a protocol of the customer's choosing on its secondary network. It is also possible to add the gateway at a later time. This gateway connects implicitly to both networks and transfers 496 bytes of input data and 496 bytes of output data between the networks. When using the gateway, the arrays listed in the section below are mapped into the AnyBus tag addresses.

Programming must be done on the side of the customer to copy the data into the correct registers. The input and output sizes in the customer's network must be 496 bytes each. See user manual for the specific model of AnyBus gateway provided for more information on programming it.

SCHEMATICS

TABLE OF CONTENTS


INTELLIFLOW RF2 MAIN CONTROL	
Drawing #	Description
0	Cover Sheet/Table of Contents
Preliminary 1	Schematic Legend Descriptions
Preliminary 2	Wire Colors
Preliminary 3	Wire Gauges and Ampacity
Preliminary 4	Reserved for IEC Notes
Preliminary 5	Cables
1	Power, PLC, HMI
2	Safety I/O Cards
3	Digital Input Card 1
4	Digital Input Card 2
5	Digital Input Card 3
6	Digital Output Card 1
7	Analog Input Card
8	High Speed Analog Input/Output Card
8B	High Speed Analog Input/Output Card Using a Coriolis or Fiber Optic Gear Meter
8C	High Speed Analog Input/Output Card Using a Piston Meter
9	Spare
10	Spare
11	Voltage to Pressure Air Control
12	Air Solenoid Controls
13-20	Unused
21	Exor Detail
22	Ethernet Switch Detail
23	Solenoid Manifold Detail
24	Voltage to Pressure Manifold Detail
25	Spare
26	AnyBus Ethernet Communications Module
26B	AnyBus DeviceNet Communications Module
26C	AnyBus CC-Link Communications Module
26D	AnyBus ProfiNet Communications Module
26E	AnyBus EtherCat Communications Module

REVISION LIST

REVISION LIST			
Version	Engineer	Date	Description
A	SA	06/01/2020	DESIGN
B	JV	12/10/2020	AS BUILT-ALPHA
C	JV	01/25/2021	DESIGN UPDATES
D	JV	05/26/2021	PRE-PRODUCTION UPDATES
E	JV	07/27/2021	UPDATES AFTER EMC TESTING
F	JV	08/23/2021	AFTER FIRST BETA TEST
1	JV	02/03/2022	PRODUCTION RELEASE
J	RDH	02/13/2023	UPDATES

PRELIMINARY 1


LEGEND DESCRIPTIONS
 NUMBERING CODE
 XX???? = COMPONENT TYPE
 ??XX?? = SHEET
 ?????XX = COLUMN



WIRE CROSS

CABLE NUMBER
CORE IDENTIFIER

CBLXXXX / COLOR




WIRE CONNECTION

CIRCUIT BREAKER
WITH RATING

CBXXXX


??A



TERMINAL BLOCK
WIRE NUMBER


XXXX

TB???




CONTROL
RELAY COIL

CRXXXX



PUSHBUTTON
NORMALLY OPEN


PBXXXX



CONTROL
RELAY COIL


CRXXXX

?



PUSHBUTTON
NORMALLY CLOSED

PBXXXX



CONTROL
RELAY COIL

CRXXXX


?



FUSE WITH
RATING

FUXXXX

??A



SOLENOID

SOLXXXX



FUSED DISCONNECT
WITH RATING


DSXXXX

??A



NORMALLY CLOSED
LIMIT SWITCH


LSXXXX



NORMALLY OPEN
SELECTOR SWITCH

SSXXXX





OX




NORMALLY OPEN
PRESSURE SWITCH

PSXXXX

PRELIMINARY 1 (cont.)



CONNECTIONS OUTSIDE THE ELECTRICAL ENCLOSURE



PRELIMINARY 2

WIRE COLORS	
Wire Reference	Color
BLK	BLACK
WHT	WHITE
BLU	BLUE
RED	RED
GRN	GREEN
ORG	ORANGE
BRN	BROWN
YLW	YELLOW

FERRULES TO BE USED ON ALL WIRES (UNLESS NOTED)	
Wire Reference	Description
BLACK	UNGROUNDING LINE VOLTAGE
WHITE	UNGROUNDING DC VOLTAGE
WHITE/BLUE	GROUNDING DC COMMON
GREEN/YELLOW	GROUND

WIRE COLORS	
Wire Reference	Color
RED_GRY	RED w/GRAY STRIPE
GRY_RED	GRAY w/RED STRIPE
WHT_BRN	WHITE w/BROWN STRIPE
BRN_WHT	BROWN w/WHITE STRIP
WHT_GRY	WHITE w/GRAY STRIPE
GRY_WHT	GRAY w/WHITE STRIPE
RED_BLU	RED w/BLUE STRIPE
BLU_RED	BLUE w/RED STRIPE
RED_ORG	RED w/ORANGE STRIPE
ORG_RED	ORANGE w/RED STRIPE
RED_GRN	RED w/GREEN STRIPE
GRN_RED	GREEN w/RED STRIPE
BRN_RED	BROWN w/RED STRIPE
RED_BRN	RED w/BROWN STRIPE
WHT_GRN	WHITE w/GREEN STRIPE
GRN_WHT	GREEN w/WHITE STRIPE
WHT_BLU	WHITE w/BLUE STRIPE
BLU_WHT	BLUE w/ WHITE STRIPE

PRELIMINARY 2 (cont.)

WIRE COLORS (CONT.)	
Wire Reference	Color
WHT_ORG	WHITE w/ORANGE STRIPE
ORG_WHT	ORANGE w/WHITE STRIPE
GRN_YLW	GREEN w/YELLOW STRIPE

PRELIMINARY 3

WIRE GAUGE (UNLESS NOTED) USE MIN 75 DEGREE C COPPER WIRE			
American Wire Gauge (AWG)	Diameter (Inches)	Cross Sectional Area (mm²)	Ampacity (75° C Copper)
3	0.2292	26.65	100
4	0.2043	21.14	85
6	0.162	13.29	65
8	0.1285	8.36	52
10	0.1019	5.26	30
12	0.0808	3.31	20
14	0.0641	2.08	15
16	0.0508	1.31	10
18	0.0403	0.82	7

PRELIMINARY 4

RESERVED FOR IEC DOCUMENTATION


PRELIMINARY 5

CABLE LIST			
Cable	Cable Type	Part	Location
CBL 128A	ETHERNET 3FT	310-4135	ETHERNET SWITCH X1 TO BULKHEAD
CBL 128A-1	ETHERNET RJ45-M11-90, 1M	310-4136	BULKHEAD CP128 TO E/P PRESSURE MANIFOLD X1
CBL 128B	ETHERNET 3FT	310-4135	ETHERNET SWITCH X2 TO PLC A1
CBL 128C	ETHERNET 5FT	310-3134	ETHERNET SWITCH X3 TO HMI E1
CBL 128F	ETHERNET 3FT	310-4135	ETHERNET SWITCH X6 TO RIO230 (TURCK I/O) ETH1
CBL 128G	ETHERNET 3FT	310-4135	ETHERNET SWITCH TO ANYBUS GATEWAY X1.1
CBL 128H	ETHERNET 5FT	310-4134	ETHERNET SWITCH X8 TO BULKHEAD CP128H
CBL 128H-1	ETHERNET RJ45-M11-90, 1M	310-4136	BULKHEAD CP128H YO PRESSURE REGULATOR X1
CBL 134	ETHERNET 3FT	310-4135	HMI E0 TO BULKHEAD CP134
CBL 137	DUAL PORT USB, 1.5M	09454521952	HMI USB TO BULKHEAD/PLUG CP 137
CBL 150	ETHERNET 5FT	310-4134	PLC A2 TO BULKHEAD CP150
CBL 629	7 COLOR STACK LIGHT w/AUDIB	240-5160	RIO234 SLOT 4 TO STACK LIGHT
CBL 1105	BULKHEAD CONN; 7/8", 5 POLE	310-4132	BULKHEAD TO SOLM 1102 POWER
CBL 1203	CAT 5E, M12, 1M	310-4133	SOLM 1203 TP2 TO SOLM 1207 TP1 (OPTIONAL)
CBL 1205-1	M12 5 PIN, 0.3M, 90°	310-4148	BULKHEAD CP1205 TO SOLM 1203 X0
CBL 1207	CAT 5E, M12, 1M	310-4133	SOLM 1207 TP2 TO SOLM 1212 TP1 (OPTIONAL)
CBL 1209-1	BULKHEAD M12 5 PIN	310-4130	BULKHEAD 1204 TO SOLM 1207 X0 (OPTIONAL)
CBL 1212	CAT 5E, M12, 1M	310-4133	SOLM 1212 TP2 TO SOLM 1217 TP1 (OPTIONAL)
CBL 1214-1	BULKHEAD M12 5 PIN	310-4130	BULKHEAD 1214 TO SOLM 1212 X0 (OPTIONAL)
CBL 1219-1	BULKHEAD M12 5 PIN	310-4130	BULKHEAD 1219 TO SOLM 1207 X0 (OPTIONAL)
CBL 2405-1	MIN (7/8"), 5P, 2M, F-M	310-4140	BULKHEAD CP1105 TO SOLM 1102 P2405
CBL 2609	ETHERNET 3FT	310-4135	ANYBUS X2.1 TO BULKHEAD CP 2609


DRAWING 1

100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125


120/240VAC, 60/50Hz
10AMP
SUPPLY BY OTHERS




DRAWING 1 (cont.)




DRAWING 2




DRAWING 2 (cont.)




DRAWING 3




DRAWING 3 (cont.)




DRAWING 4




DRAWING 4 (cont.)




DRAWING 5




DRAWING 5 (cont.)




DRAWING 6




DRAWING 6 (cont.)




DRAWING 7




DRAWING 7 (cont.)




DRAWING 8




DRAWING 8 (cont.)




DRAWING 8B




DRAWING 8B (cont.)



DRAWING 8C




DRAWING 8C (cont.)




DRAWING 9


+ 24 VDC -




DRAWING 9 (cont.)




DRAWING 10




DRAWING 10 (cont.)



DRAWING 11




DRAWING 11 (cont.)




DRAWING 12

+ 24 VDC -




Left Upper Mast Location

DRAWING 12 (cont.)





DRAWING 21




DRAWING 21 (cont.)

2126
2127
2128
2129
2130
2131
2132
2133
2134
2135
2136
2137
2138
2139
2140
2141
2142
2143
2144
2145
2146
2147
2148
2149
2150






DRAWING 22

2201
2202
2203
2204
2205
2206
2207
2208
2209
2210
2211
2212
2213
2214
2215
2216
2217
2218
2219
2220
2221
2222
2223
2224
2225




DRAWING 22 (cont.)


2201
2202
2203
2204
2205
2206
2207
2208
2209
2210
2211
2212
2213
2214
2215
2216
2217
2218
2219
2220
2221
2222
2223
2224
2225




DRAWING 23



DRAWING 23 (cont.)



DRAWING 24



RIGHT UPPER MAST LOCATION

2401
2402
2403
2404
2405
2406
2407
2408
2409
2410
2411
2412
2413
2414
2415
2416
2417
2418
2419
2420
2421
2422
2423
2424
2425

DRAWING 24 (cont.)

2426

2427

2428

CPX-FB36

2429

2430

2431

2432

2433

2434

2435

2436

2437

2438

2439

2440

2441

2442

2443

2444

2445


2446

2447


2448

2449


2450



DRAWING 25





DRAWING 25 (cont.)




DRAWING 26

2600
2601
2602
2603
2604
2605
2606
2607
2608
2609
2610
2611
2612
2613
2614
2615
2616
2617
2618
2619
2620
2621
2622
2623
2624
2625



DRAWING 26 (cont.)



DRAWING 26B

2600

2601

TERMINAL TORQUE
1.4NM = 12 lb-in


2602

2603

2604

2605

2606



2607

2608

X2


2609

2610

2611

2612

2613



*SEE NOTE

2614

2615

2616

2617

2618

2619

2620

2621

2622

2623

2624

2625



DRAWING 26B (cont.)

2626

2627

2628

2629

2630

2631

2632

2633

2634

2635

2636

2637

2638

2639

2640



2641

2642

2643


2644

2645

2646

2647

X2 DeviceNet Connector



Pin	Signal
1	V -
2	CAN L
3	Shield
4	CAN H
5	V +

2648

2649

2650

2651

NOTE: A termination resistor of 121 Ohms, 1%, 1/4W must be attached at each end of the DeviceNet cable.
The resistors must be connected to pins 2 (Can L) and pins 5 (V+).

DRAWING 26C

2600

2601

TERMINAL TORQUE
1.4NM = 12 lb-in

2602

DV2603

24VDC

0VDC

X1.1

X1.2

from 114

1141

from 125

1092

from 131

CBL128G

2606

2607

1 DA

2608

2 DB

2609

3 DG

2610

4 SHIELD

2611

5 FG/PE (FRAME GROUND)

GND2611

DV2603

CBL 2609

CUSTOMER SUPPLIED

'PLANT'

2612

2613

2614

2615

2616

2617

2618

2619

2620

2621

2622

2623

2624

2625



DRAWING 26C (cont.)

2626

2627

2628

2629

2630

2631

2632

2633

2634

2635

2636

2637



2638

2639

2640

2641

2642

2643

2644

2645

2646

2647


2648

2649

2650

2651

X2 CC-Link Connector



Pin	Signal
1	DA (Communication signal)
2	DB (Communication signal)
3	DG (Digital Ground)
4	Shield (Cable shield)
5	FG/PE (Frame Ground)

DRAWING 26D

2600

2601

TERMINAL TORQUE
1.4NM = 12 lb-in


2602

2603

2604

2605

2606




2607

2608

2609

2610



2611

DV2603

2612

2613

2614

2615

2616

2617

2618

2619

2620

2621

2622


2623

2624

2625



DRAWING 26D (cont.)



DRAWING 26E

2600

2601

2602

2603

2604

2605

2606

2607

2608

2609

2610

2611

2612

2613

2614

2615

2616

2617

2618

2619

2620



2621

2622

2623

2624


2625



DV2603



DRAWING 26E (cont.)



Date	Changes	Version
10/12/2021	1st Draft	R1
12/20/2022	Added Rev. H electrical schematics (Appendix section)	R1
03/13/2023	Added Rev. J electrical schematics (Appendix section)	R2
03/23/2023	Added pulse valve adjustment and Cloud/Internet connection pages	R2
05/22/2023	Added pressure limitations due to Coriolis.	R3

Page intentionally left blank

WARRANTY POLICY

This product is covered by Carlisle Fluid Technologies' materials and workmanship limited warranty. The use of any parts or accessories, from a source other than Carlisle Fluid Technologies, will void all warranties. Failure to reasonably follow any maintenance guidance provided, may invalidate any warranty.

For specific warranty information please contact Carlisle Fluid Technologies.

For technical assistance or to locate an authorized distributor, contact one of our international sales and customer support locations.

Region	Industrial/Automotive	Automotive Refinishing
Americas	Tel: 1-800-992-4657 Fax: 1-888-246-5732	Tel: 1-800-445-3988 Fax: 1-800-445-6643
Europe, Africa Middle East, India		Tel: +44 (0)1202 571 111 Fax: +44 (0)1202 573 488
China		Tel: +8621-3373 0108 Fax: +8621-3373 0308
Japan		Tel: +81 45 785 6421 Fax: +81 45 785 6517
Australia		Tel: +61 (0) 2 8525 7555 Fax: +61 (0) 2 8525 7575

For the latest information about our products, visit www.carlisleleft.com

Carlisle Fluid Technologies is a global leader in innovative finishing technologies. Carlisle Fluid Technologies reserves the right to modify equipment specifications without prior notice.

BGK™, Binks®, DeVilbiss®, Hosco®, MS®, and Ransburg® are all registered trademarks of Carlisle Fluid Technologies, LLC.

©2023 Carlisle Fluid Technologies, LLC.
All rights reserved.



16430 North Scottsdale Road
Scottsdale, AZ 85254 USA