


Ransburg

SERVICE MANUAL
LN-9252-06.4
(Replaces LN-9252-06.3)
March - 2013

RMA™-303 ROBOT MOUNTED ROTARY ATOMIZER INDIRECT CHARGE



MODEL: A11600

IMPORTANT: Before using this equipment, carefully read **SAFETY PRECAUTIONS**, starting on page 1, and all instructions in this manual. Keep this Service Manual for future reference.

Service Manual Price: \$50.00 (U.S.)

NOTE: This manual has been changed from revision **LN-9252-06.3** to revision **LN-9252-06.4**. Reasons for this change are noted under “Manual Change Summary” page 98 of this manual.

CONTENTS

	PAGE
SAFETY:	1-5
SAFETY PRECAUTIONS	1
HAZARDS / SAFEGUARDS	2-5
INTRODUCTION:	6-22
FEATURES	6
GENERAL DESCRIPTION	7
SPECIFICATIONS	8
IMPORTANT NUMBERS	9
GRAPHICAL INFORMATION	10-19
RMA-303 TOOL POINT, CENTER OF GRAVITY, AND ENVELOPE DIMENSIONS	20
CIRCUIT DIAGRAM	21
VALVE SCHEMATIC	22
INSTALLATION:	23-31
AIR FILTER INSTALLATION	23
TUBE SIZE / AIR PRESSURE REQUIREMENTS	23-25
AIR HEATER REQUIREMENTS	25-26
AIR FILTRATION REQUIREMENTS	27
MOUNTING	28
ELECTRICAL AND FIBER OPTIC CONNECTIONS	28
FLUID CONNECTIONS	28
TYPICAL INSTALLATION	28
AIR HEATER	28
TYPICAL INSTALLATION OF RMA-303	29
TUBING BUNDLE INSTALLATION	30
BUNDLE LUBRICANT	30
INTERLOCKS	30-31
OPERATION:	32-38
FLUID FLOW RATE CONTROL	32
FLUID VALVE CONTROL (Trigger, Dump, and Solvent)	33
TURBINE SPEED	33
BEARING AIR ADJUSTMENT	34
SHAPING AIR #1 (SAI) (Pattern Control Air)	34
SHAPING AIR #2 (Cut-In Control Air)	35
BRAKE AIR	35
ELECTROSTATIC VOLTAGE	35
TARGET DISTANCE	36
GENERAL OPERATING SEQUENCE	36-37
PROTECTIVE COVERS	38

(Continued On Next Page)

CONTENTS (Cont.)

	PAGE
MAINTENANCE:	39-72
O-RINGS	39
CLEANING PROCEDURES	39-40
VIBRATION NOISE	41
TURBINE MAINTENANCE	41
AIR FILTERS / ELEMENT REPLACEMENT	41
GENERAL MAINTENANCE	42
PREVENTIVE MAINTENANCE	42-44
BELL CUP PREVENTIVE MAINTENANCE	44
BELL CUP CLEANING	45
CLEANING SHAPING AIR HOLES	46
RMA-303PREVENTIVE MAINTENANCE SCHEDULE	47-48
DISASSEMBLY PROCEDURES	49-51
HIGH VOLTAGE CONNECTIONS FOR SHIELDED / NON-METALLIC CORE CABLE A10560-XX	52-64
QUICK RELEASE COLLET REMOVAL AND REPLACEMENT	64-65
CHECKING PROBES	66
ELECTRODE RESISTANCE TEST	66-67
OPERATOR / MAINTENANCE "WARNINGS"	68
TROUBLESHOOTING GUIDE	69-72
PARTS IDENTIFICATION:	73-96
RMA-303 INDIRECT CHARGE ROTARY ATOMIZER MODEL IDENTIFICATION	73-74
RMA-303 ASSEMBLY / PARTS LIST	75-77
TYPICAL BELL CUP PARTS BREAKDOWN	78
A11693 REAR PLATE ASSEMBLY / PARTS LIST	79
A11699 TURBINE MANIFOLD ASSEMBLY / PARTS LIST	80
A11692 VALVE MANIFOLD ASSEMBLY / PARTS LIST	81
A11351-03/04 CUP WASH LINE ASSEMBLIES / PARTS LIST	82
A12089-08 AND A12089-11 SHAPING AIR KITS	82
A11678-XXXXX TUBING BUNDLE ASSEMBLY / PARTS LIST	83-85
A11678-XXXXX TUBING BUNDLE ASSEMBLY MODEL IDENTIFICATION	86-88
RECOMMENDED SPARE PARTS	89-91
ASSEMBLY TOOLS / PARTS LIST	92
A11536-00 HIGH VOLTAGE RING KIT / PARTS LIST	93
LUBRICANTS AND SEALERS	94
ACCESSORIES	94
SERVICE KITS	95
REPLACEMENT HARDWARE	96
WARRANTY POLICIES:	97
LIMITED WARRANTY	97

SAFETY

SAFETY PRECAUTIONS

Before operating, maintaining or servicing any Ransburg electrostatic coating system, read and understand all of the technical and safety literature for your Ransburg products. This manual contains information that is important for you to know and understand. This information relates to USER SAFETY and PREVENTING EQUIPMENT PROBLEMS. To help you recognize this information, we use the following symbols. Please pay particular attention to these sections.

A WARNING! states information to alert you to a situation that might cause serious injury if instructions are not followed.

A CAUTION! states information that tells how to prevent damage to equipment or how to avoid a situation that might cause minor injury.

A NOTE is information relevant to the procedure in progress.

While this manual lists standard specifications and service procedures, some minor deviations may be found between this literature and your equipment. Differences in local codes and plant requirements, material delivery requirements, etc., make such variations inevitable. Compare this manual with your system installation drawings and appropriate Ransburg equipment manuals to reconcile such differences.

Careful study and continued use of this manual will provide a better understanding of the equipment and process, resulting in more efficient operation, longer trouble-free service and faster, easier troubleshooting. If you do not have the manuals and safety literature for your Ransburg system, contact your local Ransburg representative or Ransburg.




WARNING



- The user **MUST** read and be familiar with the Safety Section in this manual and the Ransburg safety literature therein identified.
- This manual **MUST** be read and thoroughly understood by **ALL** personnel who operate, clean or maintain this equipment! Special care should be taken to ensure that the **WARNINGS** and safety requirements for operating and servicing the equipment are followed. The user should be aware of and adhere to ALL local building and fire codes and ordinances as well as **NFPA-33 SAFETY STANDARD, LATEST EDITION**, prior to installing, operating, and/or servicing this equipment.







WARNING

- The hazards shown on the following pages may occur during the normal use of this equipment. Please read the hazard chart beginning on page 2.

AREA Tells where hazards may occur.	HAZARD Tells what the hazard is.	SAFEGUARDS Tells how to avoid the hazard.
<p>Spray Area</p> 	<p>Fire Hazard</p> <p>Improper or inadequate operation and maintenance procedures will cause a fire hazard.</p> <p>Protection against inadvertent arcing that is capable of causing fire or explosion is lost if any safety interlocks are disabled during operation. Frequent Power Supply or Controller shutdown indicates a problem in the system requiring correction.</p>	<p>Fire extinguishing equipment must be present in the spray area and tested periodically.</p> <p>Spray areas must be kept clean to prevent the accumulation of combustible residues.</p> <p>Smoking must never be allowed in the spray area.</p> <p>The high voltage supplied to the atomizer must be turned off prior to cleaning, flushing or maintenance.</p> <p>When using solvents for cleaning:</p> <ul style="list-style-type: none"> • Those used for equipment flushing should have flash points equal to or higher than those of the coating material. • Those used for general cleaning must have flash points above 100°F (37.8°C). <p>Spray booth ventilation must be kept at the rates required by NFPA-33, OSHA, country, and local codes. In addition, ventilation must be maintained during cleaning operations using flammable or combustible solvents.</p> <p>Electrostatic arcing must be prevented. Safe sparking distance must be maintained between the parts being coated and the applicator. A distance of 1 inch for every 10KV of output voltage is required at all times.</p> <p>Test only in areas free of combustible material. Testing may require high voltage to be on, but only as instructed.</p> <p>Non-factory replacement parts or unauthorized equipment modifications may cause fire or injury.</p> <p>If used, the key switch bypass is intended for use only during setup operations. Production should never be done with safety interlocks disabled.</p> <p>Never use equipment intended for use in waterborne installations to spray solvent based materials.</p> <p>The paint process and equipment should be set up and operated in accordance with NFPA-33, NEC, OSHA, local, country, and European Health and Safety Norms.</p>

<p>AREA Tells where hazards may occur.</p>	<p>HAZARD Tells what the hazard is.</p>	<p>SAFEGUARDS Tells how to avoid the hazard.</p>
<p>Spray Area</p> 	<p>Explosion Hazard</p> <p>Improper or inadequate operation and maintenance procedures will cause a fire hazard.</p> <p>Protection against inadvertent arcing that is capable of causing fire or explosion is lost if any safety interlocks are disabled during operation.</p> <p>Frequent Power Supply or Controller shutdown indicates a problem in the system requiring correction.</p>	<p>Electrostatic arcing must be prevented. Safe sparking distance must be maintained between the parts being coated and the applicator. A distance of 1 inch for every 10KV of output voltage is required at all times.</p> <p>Unless specifically approved for use in hazardous locations, all electrical equipment must be located outside Class I or II, Division 1 or 2 hazardous areas, in accordance with NFPA-33.</p> <p>Test only in areas free of flammable or combustible materials.</p> <p>The current overload sensitivity (if equipped) MUST be set as described in the corresponding section of the equipment manual. Protection against inadvertent arcing that is capable of causing fire or explosion is lost if the current overload sensitivity is not properly set. Frequent power supply shutdown indicates a problem in the system which requires correction.</p> <p>Always turn the control panel power off prior to flushing, cleaning, or working on spray system equipment.</p> <p>Before turning high voltage on, make sure no objects are within the safe sparking distance.</p> <p>Ensure that the control panel is interlocked with the ventilation system and conveyor in accordance with NFPA-33, EN 50176.</p> <p>Have fire extinguishing equipment readily available and tested periodically.</p>
<p>General Use and Maintenance</p> 	<p>Improper operation or maintenance may create a hazard.</p> <p>Personnel must be properly trained in the use of this equipment.</p>	<p>Personnel must be given training in accordance with the requirements of NFPA-33, EN 60079-0.</p> <p>Instructions and safety precautions must be read and understood prior to using this equipment.</p> <p>Comply with appropriate local, state, and national codes governing ventilation, fire protection, operation maintenance, and housekeeping. Reference OSHA, NFPA-33, EN Norms and your insurance company requirements.</p>

<p>AREA Tells where hazards may occur.</p>	<p>HAZARD Tells what the hazard is.</p>	<p>SAFEGUARDS Tells how to avoid the hazard.</p>
<p>Spray Area / High Voltage Equipment</p> 	<p>Electrical Discharge</p> <p>There is a high voltage device that can induce an electrical charge on ungrounded objects which is capable of igniting coating materials.</p> <p>Inadequate grounding will cause a spark hazard. A spark can ignite many coating materials and cause a fire or explosion.</p>	<p>Parts being sprayed and operators in the spray area must be properly grounded.</p> <p>Parts being sprayed must be supported on conveyors or hangers that are properly grounded. The resistance between the part and earth ground must not exceed 1 meg ohm. (Refer to NFPA-33.)</p> <p>Operators must be grounded. Rubber soled insulating shoes should not be worn. Grounding straps on wrists or legs may be used to assure adequate ground contact.</p> <p>Operators must not be wearing or carrying any ungrounded metal objects.</p> <p>When using an electrostatic handgun, operators must assure contact with the handle of the applicator via conductive gloves or gloves with the palm section cut out.</p> <p>NOTE: REFER TO NFPA-33 OR SPECIFIC COUNTRY SAFETY CODES REGARDING PROPER OPERATOR GROUNDING.</p> <p>All electrically conductive objects in the spray area, with the exception of those objects required by the process to be at high voltage, must be grounded. Grounded conductive flooring must be provided in the spray area.</p> <p>Always turn off the power supply prior to flushing, cleaning, or working on spray system equipment.</p> <p>Unless specifically approved for use in hazardous locations, all electrical equipment must be located outside Class I or II, Division 1 or 2 hazardous areas, in accordance with NFPA-33.</p>

AREA Tells where hazards may occur.	HAZARD Tells what the hazard is.	SAFEGUARDS Tells how to avoid the hazard.
Electrical Equipment 	Electrical Discharge <p>High voltage equipment is utilized in the process. Arcing in the vicinity of flammable or combustible materials may occur. Personnel are exposed to high voltage during operation and maintenance.</p> <p>Protection against inadvertent arcing that may cause a fire or explosion is lost if safety circuits are disabled during operation.</p> <p>Frequent power supply shut-down indicates a problem in the system which requires correction.</p> <p>An electrical arc can ignite coating materials and cause a fire or explosion.</p>	<p>Unless specifically approved for use in hazardous locations, the power supply, control cabinet, and all other electrical equipment must be located outside Class I or II, Division 1 and 2 hazardous areas in accordance with NFPA-33 and EN 50176.</p> <p>Turn the power supply OFF before working on the equipment.</p> <p>Test only in areas free of flammable or combustible material.</p> <p>Testing may require high voltage to be on, but only as instructed.</p> <p>Production should never be done with the safety circuits disabled.</p> <p>Before turning the high voltage on, make sure no objects are within the sparking distance.</p>
Toxic Substances 	<p>Certain material may be harmful if inhaled, or if there is contact with the skin.</p>	<p>Follow the requirements of the Material Safety Data Sheet supplied by coating material manufacturer.</p> <p>Adequate exhaust must be provided to keep the air free of accumulations of toxic materials.</p> <p>Use a mask or respirator whenever there is a chance of inhaling sprayed materials. The mask must be compatible with the material being sprayed and its concentration. Equipment must be as prescribed by an industrial hygienist or safety expert, and be NIOSH approved.</p>
Spray Area 	Explosion Hazard – Incompatible Materials <p>Halogenated hydrocarbon solvents for example: methylene chloride and 1,1,1,-Trichloroethane are not chemically compatible with the aluminum that might be used in many system components. The chemical reaction caused by these solvents reacting with aluminum can become violent and lead to an equipment explosion.</p>	<p>Aluminum is widely used in other spray application equipment - such as material pumps, regulators, triggering valves, etc. Halogenated hydrocarbon solvents must never be used with aluminum equipment during spraying, flushing, or cleaning. Read the label or data sheet for the material you intend to spray. If in doubt as to whether or not a coating or cleaning material is compatible, contact your coating supplier. Any other type of solvent may be used with aluminum equipment.</p>

INTRODUCTION

FEATURES

Features which make the **RMA™-303 Robot Mounted Rotary Atomizer - Indirect Charge** advantageous for use in electrostatic applications include:

- Assembly components made of durable engineered resin material for optimum mechanical strength and solvent resistance.
- Heavy duty design ensures excellent service life even when subjected to the quick motions of robotic applications.
- Proven long life turbine motor capable of speeds up to 70 krpm. (See Specifications" in the "Introduction" section of this manual for bell cup speed ratings.)
- Serrated and non-serrated bell cups are available for application flexibility and color match. All bell cups are made using Titanium material.
- Aerodynamic design for ease of cleaning external surfaces.
- 60° angled body provides more maneuverability and facilitates robotic programming.
- Speed control uses reliable magnetic pickup for fiber optic transmission of rotational speed data.
- Fast color changes are achieved using center feed fluid delivery and the fluid valves which provide for simultaneous paint push out while solvent washes the feed tube and bell cup interior.
- Heated bell wash material is recirculated at the robot plate. Internal solvent and air valves provide for a fast solvent/air chop method to quickly and efficiently clean the interior and exterior of the bell cup.
- Less waste to the spray booth, with the dump valve located internally next to the feed tube.
- Compact high voltage control system. The MicroPak cascade control takes only 1/4 of the space in a 19-inch Euro rack, leaving room for additional control modules.
- Various adapter plates available to match most robotic mounting configurations.
- Large range of fluid tip sizes available.

GENERAL DESCRIPTION

Bell Cup Assembly

All bell cups are made of high strength Titanium. They are available in 65mm serrated, non-serrated for base coat, primer, and clear coat applications.

Air Bearing Turbine Assembly

The air bearing turbine assembly with bell cup is mounted to the air manifold assembly with a turbine retaining ring.

Air Manifold Assembly

The atomizer extension is angled at 60° for robot applications. The fluid feed tube and fiber optic turbine speed emitter are threaded into the front of the manifold. The turbine, fluid, and air manifolds are separated from the bell plate assembly by the atomizer extension.

Bell Plate Assembly

The bell plate assembly is designed to be at ground potential when mounted to the robot plate component within the tubing bundle assembly. The air and fluid ports are compactly oriented for use in robotic applications. The interior air supplies are ported through the color coded tubing directly to the air manifold assembly. On the exterior side of the bell plate, the ports are provided with o-ring seals so that the atomizer can be quickly mated and secured to the robot plate.

Robot Plate

The robot plate is a component of the tubing bundle assembly and intended to be permanently mounted to the robot. A wrist adapter is also available, which matches the robot's mounting configuration. The incoming air lines, fluid lines, and fiber optic cable are connected to the fittings provided on the back of the robot plate. The bell plate of the atomizer assembly is secured to the robot plate with a threaded retaining ring.

Break-Away Feature (Optional)

The RMA-303 can be converted to have a break-away feature. By replacing the six (6) stainless steel screws with six (6) special designed plastic screws (77524-00). This feature minimizes the damage to the atomizer, robot, etc. If a collision occurs, the six (6) plastic break-away screws fail and the atomizer will break free. This will leave the break-away ring and the mounting ring attached to the robot. (The applicator will fall to the booth grate or floor.)

Power Supply and Controls

The high voltage cascade (74793-XX) is located outside the RMA-303 and is controlled by the MicroPak™ control unit. The low voltage output of the MicroPak is multiplied by the cascade to the high voltage level required. The high voltage is supplied to the atomizer by a high voltage cable (A10560-XX). A low voltage cable interconnects the cascade and MicroPak control. The MicroPak Eurocard format is designed to fit in a conventional 19-inch or 10-inch rack and requires a 28 V power input at a maximum 6 amps.

The MicroPak is designed to electronically limit current to provide safe operation in a spray booth. The voltage and current draw of the atomizer are continuously displayed on the MicroPak control panel. Voltage and overcurrent limits are adjustable on the front of the MicroPak. MicroPak internal safety circuits will shut down the system on over-current and cable faults.

With additional control modules, all of the functions of RMA-303 and MicroPak can be controlled by a programmable controller. A Serial Atomizer module pneumatically controls the speed of the rotary atomizer with dynamic feedback through a fiber optic transmitter located on the applicator. An AirTronic module pneumatically controls the atomizer's (pattern control) shaping air. A Serial Digital module pneumatically controls the paint, solvent, and dump valves located on the atomizer. An I/O module provides communication between these modules and the PLC.

The above modules are mounted in one 19 inch rack and interconnected through a common mother board.

SPECIFICATIONS *

Electrical

Power Supply Type:	MicroPak
Charging Method:	Indirect
Output Voltage:	30-70 kV Variable
Output Current:	1000 μ A
Turbine Speed Control:	EurocardAtomizerModule
Internal/External Shaping Air Control:	EurocardAirTronicModule
Part Sprayability:	Determine sprayability of part to be coated using Test Equipment (76652)
(See current Paint, High Voltage & SCI Test Equipment Service Manual).	

Mechanical

Length:	(See Figure 1)
Diameter:	(See Figure 1)
Approximate Weight:	
Atomizer Only:	18.4 lbs. (8.43 Kg)
Total Payload:	21.08 lbs. (9.6 Kg)
Turbine Type:	Air Bearing Impulse Drive
Turbine Air Supply:	Variable
Maximum/Minimum Turbine Speed:	Continuous
All Bell Cups:	70K rpm max./ 20K rpm min.
Bearing Air Supply (Nominal):	90 psig (\pm 10 psi) (621 kPa \pm 69 kPa) 2.9 SCFM (82 slpm)


Mechanical (Cont.)

Maximum Angular Velocity for Turbine (Robot Motion):	:250°/sec.
Shaping Air #1 (SAI) Supply:	Variable (See "Pressure Flow Data Charts" in this section.)
Shaping Air #2 (SAO) Supply:	Variable (See "Pressure Flow Data Charts" in this section.)
Brake Air Supply (Nominal):	60-100 psig (414-689 kPa)
Maximum Fluid Pressure Supply:	
Paint:	200 psi (1379 kPa)
Solvent:	150 psi (1035 kPa)
Fluid Flow Rate:	25-700 cc/min.
Bell Cup Cleaning Time (Internal/External):	2-7 sec. (Approx.)
Color Change Time:	Dependent on system configuration, fluid pressures, fluid viscosity, fluid line lengths, etc.
Speed Readout:	Magnetic pick-up, unidi-rectional fiber optic transmission
Bell Cup Replacement Time:	Less than 2 minutes
Minimum Control Equipment Requirements:(Versions listed or higher)	
MicroPak	LECU5004-17 (V3.83)
Atomizer Module	76011-01 (V3.42)
I/O Module	A11435 (V1.4) (0-10V) (4-20 mA)
* Specifications and ratings based on testing at sea level standard conditions.	

IMPORTANT NUMBERS


Record these numbers in a log book for future reference.
The last digits of the Atomizer serial number are also the Turbine serial numbers.

Turbine Serial Number




TURBINE SERIAL NUMBER LOCATION

High Voltage Serial Number




HIGH VOLTAGE RING SERIAL NUMBER


Atomizer Serial Number




ATOMIZER SERIAL NUMBERS


Bell Cup Part Numbers / Serial Number (cup only, not with splash plate)







Graphical information provided for reference only for all charts. Unless otherwise specified, all pressure data shown was measured 12-inches (305mm) behind the applicator.






BEARING AIR FLOW RATE VS SUPPLY PRESSURE







RMA-303 Spindle Deceleration Times (unloaded 65mm Bell Cup)




RMA-303 Spindle Deceleration Times (unloaded 65mm Bell Cup)



**RMA-303 Dual Flex Air
A12089-09/-10/-11 Series Shape Air
Flow vs Pressure**





Flow vs. Pressure
Mon Flex Shape Air- Dual Supply Source
A12089-06/-07/-08 SHAPING AIR KIT



Fluid Tip Flow Rate Charts

Maximum Flow Rate by Tip Size, Hose Length, and Material Viscosity





65MM RMA-303 INDIRECT TOOL POINT DIMENSIONS		
TD	X	Y
6-Inches (152mm)	22.16-Inches (563mm)	15.81-Inches (401.5mm)
8-Inches (203mm)	23.16-Inches (588.4mm)	17.54-Inches (455.5mm)
10-Inches (254mm)	24.16-Inches (613.8mm)	19.27-Inches (489.4mm)
12-Inches (305mm)	25.16-Inches (663.9mm)	21.00-Inches (533.4mm)

Figure 1: RMA-303 Tool Point, Center of Gravity, and Envelope Dimensions (Single and Dual Swirl)




Figure 2: Circuit Diagram




Figure 3: Valve Schematic

INSTALLATION

AIR FILTER INSTALLATION

The following air filter installation guidelines are essential for optimum performance:

1. 25mm OD (1-inch OD) minimum inbound main air line.
2. Use only recommended pre-filters and bearing air filters as shown in "Air Filtration Requirements" chart in this section. Additional system air filtration (i.e., refrigerated air dryer) may also be used if desired.

3. Mount the bearing air filter as close as possible to the RMA-303. (DO NOT mount further than 30-feet (9.1 meters) away.)

4. **DO NOT** use tape, pipe dope, or other thread sealant downstream of the bearing air filter. Loose flakes of tape or other sealant can break loose and plug the very fine air holes in the turbine air bearings.

5. Air heaters are highly recommended for use in the system to minimize the effect of excessively humid conditions. If the heated air will exceed 120°F (48.9°C), the heater must be located after all filters to prevent damage to the filter media.

TUBE SIZE / AIR PRESSURE REQUIREMENTS		
	Tube Size	Air Pressure Requirements
Bearing Air Supply (BRG)	6 x 4mm OD (Yellow)	90psi +/- 10 (621 +/- 69 kPa)
Bearing Air Return (BRG RTN)	4mm (5/32") OD (Yellow)	80psi +/- 20 (at atomizer card) (552 +/- 138 kPa)
Turbine Air (T.A)	10 X 8mm (Green)	Variable
Pattern Control Air 2 (SAO)	8 X 6mm (Gray)	Variable
Pattern Control Air 1 (SAI)	8 X 6mm (Blue)	Variable
Brake Air (BRK) (if used)	6 X 4mm (Orange)	60-100 psi (414 - 689 kPa)
Paint Valve Control (PT)	4mm (5/32") OD (Natural)	80 psi +/- 10 (552 +/- 70 kPa)
Dump Valve Control (PD)	4mm (5/32") OD (Silver)	80 psi +/- 10 (352 +/- 70 kPa)
Cup Wash Solvent Valve Control (ST)	4mm (5/32") OD (Blue)	80 psi +/- 10 psi (352 +/- 70 kPa)
Cup Wash Air (ATI) Valve Control	4mm (5/32") OD (Orange)	80 psi +/- 10 (352 +/- 70 kPa)
Cup Wash Air (CWA)	6 X 4mm (Green)	80 - 100 psi (551-689 kPa)

NOTE

- Each applicator must have its own filter for bearing air. Recommended: RPM-418 or equivalent.

NOTE

- With the exception of fluid, dump, and bearing air, all other pilot and air supply lines should be bulkheaded and their diameters increased one size. For example: Turbine air should be increased to a 12mm OD from bulkhead plate to the volume booster.

EQUIPMENT GROUNDING & SAFETY RECOMMENDATIONS

In electrostatic coating systems, the flow of high voltage power from the power supply to the atomizer is insulated from ground and isolated from all other functions and equipment. When the voltage reaches the atomizer, it is transferred to the coating material where, by introducing a negative charge, it causes the atomized fluid to seek the nearest positive ground. In a properly constructed and operated system, that ground will be the target object.

The directed conduction of the electric charge through its array of wires, cables, and equipment, is accompanied by a variety of stray electrical charges passing through the air by various means such as: air ionization, charged particles in the air and radiated energy. Such charges may be attracted to any conductive material in the spray area. If the conductive material does not provide a safe drain to electrical ground, which will allow the charge to dissipate as fast as it accumulates, it may store the charge. When its electrical storage limit is reached, or when it is breached by external circumstances (such as the approach of a grounded object or person, or one at lower potential), it may discharge its stored charge to the nearest ground. If there is no safe path to ground (such as a ground wire or braided cable) it may discharge through the air as a spark. A spark may ignite the flammable atmosphere of a spray area. The hazard area extends from the point of origin up to as much as a twenty-foot radius. See the NFPA-33 for definition and limitations of a hazard area.

It is a simple, but vital matter to be sure that all conductive objects within the spray area are grounded. All cabinets, housing, bases, supports and stands, which are not by design, insulated from ground, **MUST be connected directly and INDIVIDUALLY to earth ground. Resting on a concrete floor or being attached to a building column may not always be sufficient ground.** In order to provide the best ground connection possible, always attach a ground wire or insulated braided cable to

the terminal indicated by the ground symbol and then to a proven ground. Always check ground connections for integrity. Some items, such as rotators and paint stands, may be supported on an insulator, but all components of the system up to the insulator **MUST** be grounded.

Where items are mounted directly on structural components such as building columns, the ground

NOTE

- Ransburg recommends that ground connections to earth ground be ¾" insulated copper braided wire. Grounds between assemblies within a machine should be ran to a central point within the machine using #18 insulated stranded copper wire minimum. All connections should be mechanically sound and have less than five (5) ohms of resistance between assemblies and the common point. The resistance between the central point and earth ground should be less than five (5) ohms as well.

connection **MUST** still be made. In many cases the structural component may be painted or coated with an insulated material and in all cases the Ransburg equipment will be painted. These coatings are insulating. The ground connection must be as perfect as possible. The indicated ground terminal on the Ransburg equipment will provide the necessary connection at one end, but the user must be sure that the other end is secured to an earth ground. This may be achieved by the use of a standard ground clamp (properly secured), by brazing or by piercing the structural component enough to assure connection. All ground connections should be made to the most conductive metallic structural ground available.

To be sure that everything is properly grounded, the following steps should be undertaken at least daily:

1. Inspect all ground wires. Look for good, firm joints at all points of connection. Look for breaks in the ground wire. Repair all defects IMMEDIATELY!
2. Inspect the floor or grates for excessive accumulation of dried coating material or other residue. If there is any, remove it!

SAFE GROUNDING IS A MATTER OF PROPER EQUIPMENT MAINTENANCE AND INSTALLATION, CORRECT OPERATION AND GOOD HOUSEKEEPING. Daily inspection of grounding apparatus and conditions, however, will help prevent hazards that are caused by normal operations.

BE SURE THAT:

1. All objects in the spray area are grounded.
2. Personnel in the spray area are properly grounded. (Conductive safety shoes, and coveralls.)
3. That the target object is properly grounded (less than 1 megohm resistance).
4. That the high voltage is off except during normal application.
5. That the high voltage is off and applicators are grounded during maintenance operations.
6. The spray area is kept free of accumulated coating deposits.
7. All combustible liquids in the spray area (outside of automatic delivery systems) are kept to minimum and are kept in fire safe, grounded containers. (See NFPA-30 and chapter 6 of NFPA-33.)
8. Proper ventilation is provided.
9. Personnel must thoroughly understand the equipment, its operation and maintenance, and all safety precautions.

AIR HEATER REQUIREMENTS

Turbine drive air expands as it moves through the turbine wheel cavity and as it exits the turbine from the exhaust port. This expansion will cause cooling of the exhaust air and the surfaces it contacts. This same expansion cooling can occur across the shaping air exit ports. This cooling effect can cause surface temperatures to fall below the dew point of the booth, which will result in condensation on the interior and exterior of the atomizer, machine, and its components. It is even possible that the temperature of the supply air may be below the booth dew point, even without additional expansion cooling.

Condensation is especially probable in waterborne applications when booth temperature and relative humidity levels are typically maintained very high. This condensation will allow sufficient conductivity of the surfaces such that they act as an erratic ground source potential. This can cause damage to the equipment.

It is therefore, a requirement that turbine exhaust air temperature be maintained above the booth dew point to prevent condensation from forming on atomizer surfaces. Doing so will eliminate moisture as a potential defect in painted surfaces as well as extending equipment life. Thus, it is recommended that air heaters be installed into the atomizer air supply lines, i.e. turbine drive air, shaping air, and seal air. The air heaters must be of sufficient capacity, capable of raising the incoming air temperature at least 40°F (4.4°C) at a flow rate of 60 SCFM per applicator.

The actual air heater process setting depends on applicator fluid flow rate load, booth conditions, turbine airflow settings, and incoming air temperature. The heater should be set as low as possible, sufficient to maintain the applicator surface temperatures above the dew point in the booth.

AIR HEATER REQUIREMENTS

Turbine drive air expands as it moves through the turbine wheel cavity and as it exits the turbine from the exhaust port. This expansion will cause cooling of the exhaust air and the surfaces it contacts. This same expansion cooling can occur across the shaping air exit ports. This cooling effect can cause surface temperatures to fall below the dew point of the booth, which will result in condensation on the interior and exterior of the atomizer, machine, and its components. It is even possible that the temperature of the supply air may be below the booth dew point, even without additional expansion cooling.

Condensation is especially probable in waterborne applications when booth temperature and relative humidity levels are typically maintained very high. This condensation will allow sufficient conductivity of the surfaces such that they act as an erratic ground source potential. This can cause damage to the equipment.

It is therefore, a requirement that turbine exhaust air temperature be maintained above the booth dew point to prevent condensation from forming on atomizer surfaces. Doing so will eliminate moisture as a potential defect in painted surfaces as well as extending equipment life. Thus, it is recommended that air heaters be installed into the atomizer air supply lines, i.e. turbine drive air, shaping air, and seal air. The air heaters must be of sufficient capacity, capable of raising the incoming air temperature at least 40°F (4.4°C) at a flow rate of 60 SCFM per applicator.

The actual air heater process setting depends on applicator fluid flow rate load, booth conditions, turbine airflow settings, and incoming air temperature. The heater should be set as low as possible, sufficient to maintain the applicator surface temperatures above the dew point in the booth.

Example: With the incoming air temperature at 72°F (22.2°C), an RMA-303 with 65mm bell cup rotating unloaded at 60 krpm has a turbine outlet temperature drop of approximately 28°F (-2.2°C) (@ 40 krpm unloaded, $\Delta T \sim 14^\circ F (-10^\circ C)$). Referring to the ASHRAE Psychrometric chart, the saturation temperature range (dew point) of a spray booth maintained at 70-75°F / 65-70% RH is 62-68°F (21.1-23.9°C / 65-70° RH is 16.7-20°C). Thus it is almost certain that the surface temperatures of the applicator will fall below the dew point of the booth, and an air heater will be needed in this case.

To prevent condensation, an air heater assembly (A11065-05) should be assembled after the air filters. (Reference the current Air Heater Assembly service manual for further information.)

NOTE

- ▶ Failure to use an air heater may cause damage to equipment or ruin the finished component being processed.

NOTE

- ▶ Connect Air heater to turbine air tubing.




Figure 4: A11065-05 Air Heater

AIR FILTRATION REQUIREMENTS		
Filter Model No.	Description/Specifications	Replacement Element Part No.
HAF-503	Pre-filter, removes coarse amounts of oil, moisture & dirt. Used upstream of RPM-417 pre-filter (used in systems with poor air quality).	HAF-15 Element, One
RPM-417	Pre-filter, coalescing type, 136 SCFM, 98.5% efficiency particulate removal .3 to .6 micron, max. aerosol passed 1.0 micron, max. solid passed .4 micron (dependent upon scfm requirement per applicator, one RPM-417 can be used with up to three RMA-303 assemblies).	RPM-32 Elements, Carton of 4
RPM-418	Bearing air filter, coalescing type, 19 SCFM, 99.995% efficiency particulate removal .3 to .6 micron, max. aerosol passed .6 micron, max. solid passed .2 micron (one per applicator).	RPM-33 Elements, Carton of 8



CAUTION

► Air must be properly filtered to ensure extended turbine life and to prevent contamination of the paint finish. Air which is not adequately filtered will foul the turbine air bearings and cause premature turbine failure. The correct type of filters must be used in an RMA-303 system. The filter elements must be replaced on a regular schedule to assure clean air.

► **It is the end user's responsibility to ensure clean air at all times. Turbine failure resulting from contaminated air will not be covered under warranty.**

Figure 5 shows the pre-filter(s) and bearing air filter which are recommended for use in RMA-303 systems. If other filters are incorporated in the system, the filters to be used must have filtering capacities equal or better than those shown in "Air Filtration Requirements" above.

► **The user must ensure the bearing air supply is not inadvertently turned off while the RMA-303 air motor is turning. This will cause air bearing failure.**

NOTE

► Each applicator must have its own filter for bearing air.
Recommended: RPM-418 or equivalent

MOUNTING

The RMA-303 is equipped with a quick disconnect assembly. The quick disconnect feature consists of a robot plate which is permanently attached to the robot through a wrist adapter plate, and a mating bell plate which is a part of the RMA-303 atomizer assembly. The atomizer is secured to the robot plate with a threaded retaining ring.

ELECTRICAL & FIBER OPTIC CONNECTIONS

The fiber optic connection is made on the back of the atomizer's robot plate. The fiber optic cable comes preassembled with connectors that are secured in place by set screws tightened from the side of the robot plate. An adequate ground must be provided to the mounting plate to ensure that fluid fittings, etc. are at ground potential.

Maximum amount of splices for any length of cable is 3. The speed detection signal may be affected if splices are exceeded. Length in any combination for the fiber optic is 100-feet.

FLUID CONNECTIONS

The paint, solvent, and dump fluid tubing are connected on the back of the robot plate with stainless steel compression fittings and PFA tubing. Fluid tubing requirements are shown in "Fluid Tubing Connection Requirements" below.

TYPICAL INSTALLATION

Figure 3 shows a Typical Installation of the RMA-303 and the wiring installation of the applicator with the MicroPak.

AIR HEATER

Connect air heater to turbine air tubing. Air heater connection to bearing air is not required.

FLUID TUBING CONNECTION REQUIREMENTS		
	Fixed Atomizer	Pressure (Maximum)
Paint Line (P)	6mm ID / PFA	200 psi max. (1379 kPa)
Cup Wash Solvent Line (SOL)	A11283-00 Nylon Recirculation Tube-In-Tube	150 psi max. (1033 kPa)
Dump Line (DL)	10mm ID / PFA	200 psi max. (1379 kPa)




Figure 5: Typical Installation of RMA-303

TUBING BUNDLE INSTALLATION

Typically, the tubing bundle is pulled through the robot arm from the robot wrist side. Keep the bundle taped except for the bundle that will be inside the arm. Pull the tubing through the wrist and arm, leaving about 250mm (10-inch) of tubing sticking out the front of the wrist plate (see Figure 6).

Fasten the cable bundle at the exit of the arm. Push the robot spacer plate and applicator mounting plate to the robot wrist plate aligning the top dead center marks of the spacer plate and robot wrist plate. Fasten using appropriate screws. Installing the tubing bundle in this fashion will increase tubing bundle life significantly.




Figure 6: Tubing Bundle Installation


BUNDLE LUBRICANT

When the tubing bundle is installed, it should be lubricated with a generous amount of lubricant to increase the service life of the tubes. A recommended lubricant is Shell Alvania EP #02. There are other lubricants that are available for use. Prior to using a lubricant, insure it is silicone free, resists heat breakdown, and is compatible with the materials it will contact. It is recommended that tubing bundles be re-greased every six (6) months maximum.

INTERLOCKS

The following system interlocks are required to prevent equipment damage:

1. Bearing air should remain on at all times and should be shut off only by turning off the main air to the pneumatic control cabinet.

 CAUTION	
▶	When the turbine air is turned off, the turbine will continue to operate or "coast down" for about two minutes. Provisions should be made to assure that the operator waits at least three minutes, after shutting off the turbine air and before shutting off the main air supply.
▶	The bell cup must be removed when making flow checks. If the paint is turned on when the bell is mounted and the turbine shaft is not rotating, paint will enter the shaft and possibly damage the air bearing. Material flow checks (flow rate verification) must be made with the bell cup off and the turbine not rotating. Normally pneumatic interlocks will not allow the paint to trigger on when the turbine air is off.

**WARNING**

- ▶ The high voltage and/or coating material must never be turned on unless the bell cup is mounted on the motor shaft and the turbine is rotating.
- ▶ Pneumatic input to the turbine air inlet must be controlled to prevent the turbine from exceeding the maximum rated speed of 70,000 rpm. (See "Specifications" in the "Introduction" section.)
- ▶ High voltage must never be turned on while cleaning solvent is being sprayed either through the applicator supply or the cup wash line. High voltage and both solvent triggers must be interlocked (direct charge only).

6. Any other interlocks required by local national code or international code.

**CAUTION**

- ▶ Bell cup must be rotating at least 30,000 rpm when fluid is triggered. Turning on fluid without the bell cup spinning may flood the turbine and cause damage to components.

2. It should not be possible for the coating material to be sprayed unless the turbine is spinning.
3. Two interconnected bearing air ports are provided, one for supply air and the other to be used as a return signal for measuring bearing air pressure at the atomizer. If bearing air falls below 80 psi (551.6 kPa) at the atomizer, the turbine air should be automatically interlocked to shut off. This interlock is provided by the Serial Atomizer Module. (See current "Serial Atomizer" manual.)
4. High voltage must be interlocked with the solvent valve pilot signal to prevent solvent flow while high voltage is energized (direct charge only).
5. Turbine air and brake air must be interlocked to prevent both from being used simultaneously. This interlock is provided by the Serial Atomizer Module. (See current "Serial Atomizer" manual.)

OPERATION



WARNING

- ▶ Operators must be fully trained in safe operation of electrostatic equipment. Operators must read all instructions and safety precautions prior to using this equipment (see NFPA-33).

As with any spray finishing system, operation of the RMA-303 involves properly setting the operating parameters to obtain the best finish quality for the coating material being sprayed, while maintaining correct operation and reliability of the equipment used. Adjustments to operating parameters, which cover spraying, cleaning, and on/off control, include:

- Coating Materials
- Fluid Flow Rate Control
- Fluid Valve Control
- Turbine Speed
- Bearing Air Adjustment
- Shaping Air #1 (Pattern Control)
- Shaping Air #2 (Pattern Control)
- Brake Air
- Electrostatic Voltage
- Target Distance



WARNING

- ▶ Electrical discharge of a high electrical capacitance fluid/paint system can cause fire or explosion with some materials. If arcing occurs when a specific coating material is used, turn the system off and verify that the fluid is non-flammable. In these conditions the system is capable of releasing sufficient electrical and thermal energy to cause ignition of specific hazardous materials in air.

FLUID FLOW RATE CONTROL

Externally mounted fluid regulators or gear pumps are typically used to control fluid flow. Paint is supplied to the RMA-303 by way of the tubing bundle through the robot arm.

The atomizer assembly is equipped with micro valves which are pneumatically operated to direct the flow of paint to either the feed tube or dump line and to supply an intermittent solvent to clean the interior and exterior of the bell cup.

The feed tube has several sized removeable tips available from .7mm to 1.6mm (.027-inch - .062-inch). The viscosity and volume of the coating material being sprayed determine the correct size of feed tube tip for each installation. (Reference "Fluid Tip Flow Rate" chart in the "Introduction" section.)

Fluid Flow Rate Check

In the test mode, the flow rate can be measured by removing the bell cup from the atomizer, turning the fluid flow on, and capturing the material in a graduated beaker or measuring cup for a fixed period of time (shaping air, high voltage, and turbine air must be off).



WARNING

- ▶ Danger of shock and/or personal injury can occur. Proper grounding procedures must be followed. Personnel must never work around the turbine when the turbine is spinning or when high voltage is turned on.

FLUID VALVE CONTROL (Trigger, Dump, and Solvent)

(See "Figure 2 - Circuit Diagram" in the "Introduction" section.) The fluid valves in the RMA-303 are actuated by an air signal. The air pressure must be greater than 70 psi (482.6 kPa) to assure proper actuation of the valve. Applying air to the valve actuator turns on the fluid or air for that valve.

The paint trigger valve controls the paint flow to the bell. When actuated, paint flows through the valve to the fluid tube, and into the rear of the bell cup. The bell cup must be spinning at least 30,000 rpm when fluid is turned on to enable the fluid to flow through the bell paint passage and be atomized.

The dump valve controls the paint flow through the dump line. When actuated, paint flow is directed to the dump return line. This provides a method of rapidly removing paint from the incoming line for cleaning and/or color change. Normally, the dump valve is not actuated at the same time as the paint trigger valve since the trigger valve is intended to cause the fluid to flow to the bell at the prescribed input pressure.

The solvent valve controls the flow of cup wash solvent. When actuated, solvent flows through a separate fluid tube passage and into the bell cup. This provides cleaning of the inside of the bell cup. The outside of the cup is simultaneously cleaned by a nozzle mounted on the shaping air ring and shroud. The solvent valve should never be triggered at the same time as the paint trigger valve to prevent solvent from flowing backward into the paint line.

The cup wash air valve controls the flow of air. It is recommended that this valve and the solvent

valve be controlled to create an air/solvent chop sequence for superior internal and external cup cleaning.

To color change the applicator, a solvent/air chop must be provided through the main paint line. (See "Figure 5 - Typical Installation" in the "Installation" section.)



WARNING

- The normal fluid flow range is 25-700 cc/min. During a color change or when flushing the system, higher flow rates may be required. However, the maximum flow rate through the bell cup must not exceed 700 cc/min. to avoid solvent or paint from flooding into the internal portion of the air bearing motor assembly or front shroud.

TURBINE SPEED

Turbine speed is determined by the input air pressure/flow at the rear of the atomizer.

Turbine speed is intended to be closed loop controlled using the fiber optic speed transmitter, located on the turbine manifold. A speed input to a remote speed controller, such as the Serial Atomizer module, is required. (See "Speed and Pressure" charts in the "Introduction" section.)

NOTE

- The bell rotational speed determines the quality of atomization and can be varied for various paint flow rates and paint formulations. For optimum transfer efficiency and spray pattern control, the bell rotational speed should be set at the minimum required to achieve proper atomization. **Excessive speed reduces transfer efficiency!**



WARNING

- Never perform the interior/exterior cup clean process with high voltage on (direct charge only).

! WARNING

▶ **DO NOT** exceed the maximum rated operating speed and turbine inlet pressure. Excessive speed may cause air turbine damage or damage to the bell.

BEARING AIR ADJUSTMENT

The nominal bearing air pressure is 90 psi (620.5 kPa), measured at the rear of the atomizer. Minimum pressure is 80 psi (551.6 kPa) and maximum pressure is 100 psi (689.5 kPa). The turbine should never be operated with less than 80 psi (551.6 kPa) bearing air pressure.

Bearing air must be present when turning the turbine on. Bearing air must remain on when the turbine air is turned off until the turbine stops spinning. Never turn off bearing air to cause the

! CAUTION

▶ Bearing air **MUST** be ON and supplied at a minimum of 80 psig (551.6 kPa) whenever the turbine is operated. If not, severe bearing damage will occur. It is recommended that bearing air be left turned on at all times, except during maintenance or disassembly.

▶ Bearing damage (and subsequent turbine failure) caused by running the turbine without bearing air **WILL NOT** be covered under the Ransburg warranty.

turbine to stop spinning. If connected, brake air can be used to slow the turbine. The RMA-303 is equipped with a bearing air return line to monitor bearing air pressure at the turbine manifold. When connected to the remote Serial Atomizer speed controller, operation of the turbine will automatically be shut down whenever the bearing air pressure falls below the dip switch setting of 80 psi (551.6 kPa).

SHAPING AIR #1 (SAI) (Pattern Control Air)

A12089-08 Shaping Air Kit (Mono Flex Air) 65mm Bell Cups Only

As the name implies, the shaping air is supplied so that it is counter to the rotation of the bell cup. This combination will provide a pattern size from 10" - 24" (250mm - 610mm) depending on air flow, fluid flow, and cup rotation speed. Connection is made using the "blue" 8mm tube labeled "SAI" on the tubing bundle. The other 8mm tube labeled "SAO" is "gray" in color and typically plugged. However, if additional air is required, this "SAO" tube can be connected to a secondary controlled air source. Precautions must be taken that one does not have a significantly higher pressure than the other to avoid any back flow. This shaping air combination can be used with any 65mm bell cup. (See "Pressure and Flow Data Charts" in the "Introduction" section.)

NOTE

- ▶ A minimum of 70 slpm (2.6 SCFM) should always be kept flowing in the shaping air passage to keep the face of the applicator clean during manual cleaning breaks.





Figure 7: A12089-08 Shaping Air Kit (Mono Flex Air)

SHAPING AIR #2 (Cut-In Control Air)

A12089-11 Shaping Air Kit (Dual Flex Air) 65mm Bell Cups Only

As the name implies, both shaping air outlets supply air that is counter to the rotation of the bell cup. This combination will provide a pattern size from 3" - 10" (76mm - 254mm) depending on bell rotation speed, fluid flow, and air flow. Each set of shaping air holes are independently controlled. The inner set of holes are supplied by connecting the "blue" tube labeled "SAI" on the tubing bundle to a regulated air source. The outer set of shaping air holes are supplied by connecting the "gray" tube labeled "SAO" on the tubing bundle to a regulated source. The air supplies work in combination with each other to provide desired results. This combination of shaping air can be used with any 65mm bell cup.



**Figure 8: A12089-11 Shaping Air Kit
(Dual Flex Shape Air)**

BRAKE AIR

Brake air is used to slow the turbine speed in a minimum length of time. It is advantageous for short cycle times during color change, or may be used to reduce speed or stop the turbine. Never operate brake air with the turbine air on.

Approximate brake times to reduce the turbine speed are shown in "Deceleration Time Chart" in the "Introduction" section. These times are based on 60 psi (413.7 kPa) and 100 psi (689 kPa) air pressure at the back of applicator.

ELECTROSTATIC VOLTAGE

The RMA-303 Indirect Applicator receives its high voltage via high voltage cable A10560-XX. The voltage is then passed through eight (8) total resistors located in the A11343-XX electrode assemblies mounted on the A12079-00 high voltage ring. An ionized field is established between the probe tips and the electrically grounded bell cup as well as the electrically grounded workpiece.

Refer to the current MicroPak service manual for detailed operating instructions, safety cautions, and settings.


NOTE

- ▶ If paint defects occur, such as fatty edges or picture framing, reducing the voltage should be a last resort. To correct the problem, lead and lag trigger adjustments should be optimized first.
- ▶ The electrostatic voltage applied to the RMA-303 will affect pattern size, transfer efficiency, wrap and penetration into cavity areas. A setting of 30-70 kV is appropriate for most applications.

TARGET DISTANCE

The distance between the RMA-303 atomizer and the target will affect the finish quality and efficiency. Closer distances give a smaller pattern, wetter finish, and greater efficiency. Greater distance will provide a large pattern size and drier finish. The MicroPak control circuit will enable the applicator bell to be operated to within a few inches of the target without adjusting the voltage setting. The recommended target distance is 6 to 12-inches (152.4-304.8mm). In general, allow 1-inch (25.4mm) target distance for every 10 kV.

GENERAL OPERATING SEQUENCE

 CAUTION
<p>► It is recommended to leave bearing air on, unless the applicator is being serviced or removed for service.</p>

Normally, for painting application, the process sequence should always be:

- Bearing air on (Always on)
- Turbine air on
- Turbine speed to application speed
- Shaping air on
- Start fluid flow off part
- Voltage on

After spraying the object, the sequence should be:

- Voltage lowered to 40-50 kV
- Fluid off
- Shaping air to setback volume
- Turbine speed to set back speed (30,000 rpm recommended)

Recommended sample cup flush sequence is as follows:

1. Turbine speed set to 25-30,000 rpm.
2. Shaping air set to 350-450 slpm (12.4-15.9 SCFM).
3. Point atomizer at a grounded object such as a booth grate. Leave voltage on at 40-50 kV.
4. Assure that solvent solution is heated to 120°F (49°C) at the applicator.
5. Maintain solvent pressure of 100-150 psi (689-1,034 kPa). Maintain air push pressure at 80-100 psi (552-689 kPa).
6. Use an alternating sequence of solvent/air to create a chopping effect. Always insure that the last step in the sequence is an air push.

A typical sequence is .2 seconds solvent, 1.0 second air push, 1.7 seconds solvent, and 2.0 seconds final air push. This sequence may be modified for other paints and applications.

If the atomizer is utilizing an applicator cleaning box, voltage must be turned off.

7. It is recommended that an in-line fluid filter be installed to ensure that no foreign debris enters the fluid tip or the external wash nozzle. The fluid filter must be able to withstand at least 160°F (71°C).

The RMA-303 is versatile in processing the finish of a component. It can be setup as shown in Figures 9 and 10 to process the typical finish of a target.

Recommended sample cup purge sequence is as follows (internal cup cleaning):

1. Turbine speed set to 25,000-30,000 rpm.
2. Increase shaping air to 350-450 slpm (12.4-15.9 SCFM).
3. Paint atomizer at booth grate or insert into bell cleaning station. Reduce high voltage to 40-50 kV.

4. Maintain solvent pressure of 100-150 psi (689-1034 kPa). Maintain air push pressure at 80-100 psi (552-689 kPa).
5. Use an alternating trigger sequence of solvent/air to create a chopping effect. Always insure that the last step in the sequence is an air push.
6. A typical sequence is .3 seconds solvent, 1.7 seconds air push; repeat 3 times. This sequence may be modified for other paint and applications. Sequence Event Explanation:




Figure 9: Typical Paint Sequence

1. **Bell to Speed** - This is accomplished by a set point command from either the PLC, robot, or other input device, through the I/O module.
2. **Shaping Air On** - From a setback amount, a signal is sent to air control to increase direct flow to a desired level to achieve pattern size, film build, transfer efficiency, etc. Shaping air should never be set below 70 slpm (2.6 SCFM) air flow rate.
3. **Voltage On** - The voltage is turned on from a signal to the MicroPak. The lag time to full voltage may be reduced if a setback voltage is used. Recommended setback voltage is between 30kV and 50kV.
4. **Trigger Fluid** - An air signal is sent through the PT line of the tubing bundle. This should occur when the target is 6-12-inches (152.4-304.8mm) from the applicator centerline. (Not to be confused with target distance.)

5. **Voltage Off/Setback Voltage** - Immediately precedes the trigger off. Using a setback voltage shortens the cascade voltage ramp up-time.
6. **Fluid Trigger Off** - This should occur when the target is typically 0 to 6-inches (0-152.4mm) past the applicator.
7. **Shaping Air to Setback** - The setback flow of air should never be below 70 slpm (2.6 SCFM).
8. **Color Change Sequence** - Used when color is changed one to the other. Typical sequence is shown in Figure 7. (**Note: During this sequence, the applicator should be moved to a position to collect the waste material.**) The sequence shown is a starting point for processing, but the final sequence will depend on the material being sprayed and the solvent used to purge the applicator with.




Figure 10: Typical Color Change Sequence

PROTECTIVE COVERS

It is recommended to use covers to reduce the amount of overspray build-up on the shroud and electrodes. Two covers are available, a white lint free stretch cloth for covering the probes and a foam cover (green) for the front shaping air shroud. The white cloth cover should cover all of the electrode except for the last 1-inch (25-4mm). The green foam cover should be installed until just past the radius edge of the shroud. Care is to be taken when installing the white cloth covers over the electrodes, do not bend them. (Devise a fixture to help slide the cover over easier.)

When cleaning, do not get covers wet, it will attract more overspray more quickly. Push them back, clean surface, dry thoroughly, and slide back to original position. Depending on conditions, covers should be replaced after each shift (8 hours).



Covers:

A11565-00 White Stretch, Lint Free Covers

A11564-00 - Foam Elastic Covers (Green)



CAUTION

► Make sure covers **DO NOT** trap moisture. Moisture on covers can inhibit the performance of the applicator. Large amounts of trapped fluids can become floating grounds. These conditions may lead to unwanted sudden discharge of energy in the form of a spark.

MAINTENANCE

O-RINGS

All o-rings in this atomizer are solvent proof except the ones on the air bearing spindle. These o-rings must not be soaked in solvent; if these are exposed or soaked in solvent, they must be replaced. These o-rings are engineered to provide a fit between the air bearing spindle and it's mating parts to reduce or eliminate harmonic resonance (vibration).

Some o-rings are encapsulated. These o-rings have a limited amount of stretch and will not return to their original diameters if over stretched. These o-rings are subject to being distorted more easily than rubber o-rings, so it is important that they be sufficiently lubricated when mating parts are installed onto them. They also will take a square set over time and should be replaced periodically if mating parts are removed repeatedly or if a new mating part is installed onto them.

Any o-ring that is cracked, nicked, or distorted must be replaced.

A suitable lubricant is food grade petroleum jell or A11545-00 Petrolatum Jell.

CLEANING PROCEDURES

WARNING

- ▶ Electrical shock and fire hazards can exist during maintenance. Micro-Pak supply must be turned off before entering the spray area and performing any maintenance procedures on the atomizer. Spray booth fans should re-main on while cleaning with solvents.
- ▶ Never touch the atomizer bell while it is spinning. The front edge of the bell can easily cut into human skin or cut through gloves and other materials. Be sure the atomizer bell has stopped spin-ning before attempting to touch it. Approximate time for the bell to stop spinning after turning off turbine drive air is three minutes.
- ▶ Insure high voltage is off during any manual cleaning procedure.

In addition to the above Warning, which relates to potential safety hazards, the following information must be observed to prevent damage to the equipment.

CAUTION


- ▶ **DO NOT** immerse the RMA-303 turbine in solvent or other liquids. Turbine components will be damaged and warranty will be voided.
- ▶ Bearing air must be on during all cleaning procedures to protect the air bearing components.

 **CAUTION**

► For best operating performance, all surfaces of the applicator must be dry.

Internal Fluid Path Purge Cleaning

Cleaning the incoming paint line (from paint supply source such as color manifold through the fluid manifold and bell assembly): Turn off the high voltage and turn on the color stack trigger valve for solvent supply. With the bell spinning, flush cleaning solvent through the incoming paint line and through the manifold passages, and out through the dump valve. Use restricted bell wash solvent to clean the fluid tube and bell cup. The spinning bell will atomize the solvent and clean out the bell cup. If desired, open the dump valve to flush through the dump line for a faster and contained system flush.

 **CAUTION**

► The maximum flow rate of 700 cc/min. must not be exceeded during a flush routine. Use of an in-line fluid restricter is recommended. (Example: P/N RIL-6-AJ or similar)


External Atomizer Surface Cleaning

- Verify that the high voltage is turned off.
- All external surfaces may be cleaned using a mild solvent and lint free rags to hand wipe the RMA-303 Turbine drive air must be off, but leave bearing air on. The inner and outer shaping air should have approximately 70 slpm air flow through each to prevent the solvent from entering these passages.
- Always final wipe all parts with a non-polar solvent and wipe dry (high flash Naphtha, etc.).
- Do not spray the RMA-303 unit with a solvent applicator used for cleaning. The cleaning fluid under pressure may aid conductive materials to work into hard to clean areas or may allow fluids to be forced into the turbine assembly.

- Do not reuse an atomizer bell cup that shows any sign of damage such as nicks, heavy scratches, dents, or excessive wear.
- For best operating conditions, the atomizer surfaces must be dry.

 **WARNING**

► **NEVER** wrap the applicator in plastic to keep it clean. A surface charge may build up on the plastic surface and discharge to the nearest grounded object. Efficiency of the applicator will also be reduced and damage or failure of the applicator components may occur. **WRAPPING THE APPLICATOR IN PLASTIC WILL VOID WARRANTY.**

 **WARNING**

► To reduce the risk of fire or explosion, OSHA and NFPA-33 require that solvents used for exterior cleaning, including bell cleaning and soaking, be nonflammable (flash points higher than 100°F/37.8°C). Since electrostatic equipment is involved, these solvents should also be non-polar. Examples of non-flammable, non-polar solvents for cleaning are: Amyl acetate, methyl amyl acetate, high flash naphtha, and mineral spirits.

► Do not use conductive solvents such as MEK to clean the external surfaces of the RMA-303 without a second cleaning with a non-polar solvent.

► When using a rag to hand wipe the RMA-303, the turbine air should be off, but leave both the shaping air and bearing air turned on. Insure that rotation has come to a complete stop.

VIBRATION NOISE

If the RMA-303 is vibrating or making an unusually loud noise, it usually means there is an imbalance situation. The atomizer bell cup may have dried paint on it or the bell may be physically damaged, or there may be paint trapped between the bell cup and shaft preventing the bell cup from properly seating. If any of these conditions exist, they **MUST** be corrected. Excessive imbalance caused by one of these conditions may result in bearing damage and turbine failure. Warranty **DOES NOT** cover failure caused by imbalanced loading conditions.

To determine if the bell is dirty or damaged, remove the bell cup and turn the turbine ON. If the noise is eliminated, the bell cup is the problem. If the noise continues, the turbine may be damaged and should be inspected. Excessive air required to achieve same speed may indicate a faulty or contaminated turbine. **DO NOT** continue to operate a noisy turbine.

⚠ WARNING

► If a bell cup comes off a rotating shaft because of motor seizing or any other reason, the Atomizer and bell cup must be returned to Ransburg for inspection and evaluation to determine if the bell can be used in operation.

TURBINE MAINTENANCE

DO NOT attempt to rebuild the turbine. Any endeavor to disassemble a turbine during the warranty period will void the warranty. The turbine is non-field serviceable. Contact your authorized distributor or Ransburg for instructions.




Figure 11: Applicator Removal from Robot

AIR FILTERS/ELEMENT REPLACEMENT		
Part #	Qty. Elements Per Carton	Used On
RPM-32	4	RPM-417, Pre-Filter
RPM-33	8	RPM-418, Bearing Air Filter

GENERAL MAINTENANCE

Verify daily that the operating parameters have not varied significantly from the normal. A drastic change in high voltage, operating current, turbine air, or shaping air, can be an early indicator of potential component failure.

A laminated poster entitled "Rotary Atomizer Checklist" (AER0075) is included with the assembly in the Literature Kit to be posted near the station as a handy reference.

Due to the close proximity of high voltage to ground potential, a schedule must be developed for equipment maintenance (cleanliness).

PREVENTIVE MAINTENANCE

Daily Maintenance

(During Each Preventive Maintenance Break)

1. Verify that high voltage is OFF and that both inner and outer shaping air, bearing air, and turbine drive air are ON.
2. Open the dump valve, flushing all paint from the supply lines and valve module.
3. Open the solvent valve, flushing all paint from the fluid tube and through the atomizer bell assembly.
4. Re-verify that high voltage is OFF, turbine drive air is OFF, and that the bell cup has stopped spinning. The bearing air and shaping air should remain ON.
5. Clean all external surfaces of the applicator using a lint-free rag dampened with solvent.
6. After cleaning, all conductive residue must be removed using a non-conductive solvent. Since electrostatic equipment is involved, these solvents should also be non-polar (Naphtha).

7. Inspect bell cup for nicks, dents, heavy scratches, or excessive wear. Replace if necessary.

8. Check bell cup tightness. Tighten to 50-70 lbs•in (5.65-7.91 Nm) torque.

9. Check the amount of paint build-up on the outer protective cloth covers, if used. If excessive, replace covers as required. If cloths are wet, find source and replace with dry cloth covers.




WARNING


- ▶ The high voltage must be turned **OFF** before entering the spray area and performing any maintenance procedures. Spray booth exhaust fan(s) should remain **ON** while cleaning the equipment with solvents.



WARNING


- ▶ Make sure high voltage is **OFF** before approaching applicator with solvent cloth.
- ▶ **DO NOT** use reclaim solvent containing d-Limonene. This can cause damage to certain plastic components.
- ▶ **DO NOT** stop bell rotation by using a rag or gloved hand against the bell cup edge.

 CAUTION
<p>▶ Maximum flow rate should not exceed 700 cc/min.</p> <p>▶ Daily removal and soaking of the bell cup may not be required if the bell cup is properly flushed. However, the frequency of the feed tube and internal motor shaft inspection indicated below under weekly maintenance can be done daily and later adjusted to weekly or as required depending on the results of the inspection.</p>

 WARNING
<p>▶ In the event the bell cup comes in contact with a part, that cup should be checked for damage and replaced if necessary before continuing to spray.</p>

NOTE

▶ Normally the cloth covers will not need replacement daily and could last about one week depending on application. (See "Weekly Maintenance" in the "Maintenance" section.)

 CAUTION
<p>▶ Maximum flow rate should not exceed 700 cc/min.</p>

- Paint residue found in the shaping air holes is not acceptable and must be removed prior to applicator use (see "Cleaning Shaping Air Holes" in the "Maintenance" section).
- Remove protective cover from outer housing and discard. Clean any paint on outer surface of front and rear housing with soft cloth dampened with solvent. (See "Warning" on previous page, on avoiding the use of cleaning solvent containing d-Limonene.)
- Remove the front shroud and check for any signs of solvent or paint leakage. Clean as required or repair as required.
- Remove bell cup and soak in solvent for 1-2 hours. Clean with a soft brush as required. Remove from cleaning solution and blow dry before replacing.

NOTE

▶ It may be necessary to remove the bell cups for cleaning more frequently than weekly. (See Note under "Daily Maintenance" in the "Maintenance" section.)

Weekly Maintenance

(Prior to Start or End of Production Week)

- Monitor rotational speed of all bells at the speed control.
- Monitor high voltage and current output indicated on the MicroPak display.
- Check paint flow on all bells at minimum and maximum specified settings by taking beakered readings.
- Check solvent flow by opening solvent valve and taking a beakered reading (should be within approx. 10% of target flow rate).
- With bearing air off, carefully inspect the feed tube tip and clean any paint build-up that has occurred on the feed tube tip. Using a pen light, determine if there is build-up of paint in the motor shaft and/or around the paint feed tube. If so, remove the motor assembly following the disassembly procedures and clean out the inside diameter of the motor shaft using a tube brush and solvent. Clean the outer surfaces of the feed tube.

⚠ WARNING

► Make sure that no solvent or other contamination is allowed to enter the motor assembly (air bearing and outer shaft).

- Recheck bell cup tightness. Torque to 50-70 lbs•in (5.65-7.91 Nm).
- Remove the rear shroud to expose the fluid valve manifold assembly. Visually inspect for signs of fluid leaks around fluid connections and manifold. Correct problem and clean paint from all components, including internal portion of shroud.
- Reinstall rear shroud, bell cup, and front shroud and replace cover on the outer housing (Refer to "Disassembly Procedures" in the "Maintenance" section for definite instructions).

BELL CUP PREVENTIVE MAINTENANCE

It is the user's responsibility to insure proper maintenance of the atomizer bell at all times. Bell cup failure due to inadequate cleaning or handling will not be covered under Warranty. The **"DO NOT"** bullets (see "Operator/Maintenance

Warnings" in the "Maintenance" section) listed are some examples of improper handling which could adversely affect performance or personnel safety and should not be attempted for any reason.

Bell Cup Handling

Always verify that high voltage is turned off and the atomizer bell has stopped spinning before performing any type of handling maintenance.

Bell Cup Replacement

Bell cup wear is dependent on many factors such as bell speed, flow rate, and type of coating being applied.

The bell cups shown in the following photos indicates if a bell cup has some useable life or should be replaced. Photo 1 shows a bell cup that has some usable life. The grooves worn around the splash plate pins are shallow. The general appearance of the cup surface is smooth and uninterrupted. Photo 2 shows a bell cup that needs to be replaced, as well as the splash plate that was installed into the cup. The grooves are deep, a visible groove exists at the outer edge diameter of the splash plate and there are noticeable lateral grooves extending towards the outer edge of the cup.




Photo 1




Photo 2

BELL CUP CLEANING

Always verify that high voltage is in degrade mode of 40-50 kV and that the atomizer bell is spinning before performing any type of color change or bell flush cleaning cycle.

To reduce the risk of fire or explosion, the solvents used for exterior cleaning must have flash points above 100°F (37.8°C). Since electrostatic equipment is involved, these solvents should also be non-polar.

Solvents used for equipment flushing should have flash points equal to or higher than those of the coating material being sprayed.

1. The atomizer bell will normally be fully cleaned during a bell flush cycle. Flushing should be done before any down time or break in production. A bell flush cycle may also be required while spraying batch parts of the same color. Verify that high voltage is in degrade mode of 40-50 kV and that the atomizer bell is spinning before flushing through the bell.

2. If there is any remaining paint build-up on any areas of the bell after flushing, the bell cup should be removed for hand cleaning. The bell's leading edge, splash plate, serration cuts, and rear of cup are some examples of areas for special attention.

Manual Inspection

3. Visually inspect the bell cup edge for signs of abrasion. If the edge is excessively worn or badly chipped as the result of a collision with a part, replace the cup immediately. ("Bell Cup Preventive Maintenance, Photos 1 and 2" in this section.)

4. Remove splash plate. Inspect for wear on the bell cup where the fluid leaves the large diameter of the splash plate. If any undercut in this area, the cup should be replaced. Also, check the three (3) pins between the front and rear splash plate halves. If worn, replace entire assembly.

5. Check the center holes of the splash plate for wear. Hold splash plate up to a light source and

look straight into the holes. If light is clearly seen, splash plate must be replaced.

6. Splash plate assemblies may be soaked for a short time, under 2 hours, to loosen dried material. Clean with a soft bristle brush. Blow out center holes to dislodge material. Never use any kind of pick instrument to clean these holes.

7. Soaking the bell in solvent may aid in loosening or removing paint build-up. It is recommended that the splash plate be removed and cleaned separately.

8. Use a soft bristle brush dipped in solvent to remove paint build-up from the serration cuts, paint feed holes or slots, and external and internal surfaces of the bell.

9. Check the well cavity in the back of the bell cup. This cavity must be cleaned manually. It will not be cleaned during purge cycles or interior or exterior cup flushes.

10. A soft, lint free rag dampened with solvent may be used to remove any paint residue from the external and internal surfaces of the bell.

11. After removing all paint build-up or residue, rinse the bell in clean solvent and blow dry.

12. Before reinstalling the bell on the shaft, check the mating surfaces of the thread and taper for any paint build-up or residue. Also, check the fluid tip, fluid tube outside diameter, and the shaft for any further paint build-up. These surfaces should be cleaned before installing the bell.

13. It is recommended that extra bell cups be purchased. The cups can then be cleaned off line in an automated cup cleaner.

14. Reinstall cups to proper torque 50-70 lbs•in (5.65 - 7.91 Nm).




Figure 12: Inspection of Bell Cups

NOTES

CLEANING SHAPING AIR HOLES

In order to maintain uniform pattern control, the shaping air holes of the inner ring and the shaping air cap must be clean and free of any blockage.

It is best to leave the shaping air supply ON during normal production break cleaning periods. Shaping air can be reduced to 70 slpm during this time. This will help stop material from entering the passage ways.

Periodically (weekly) the outer shaping air cap and the inner shaping air ring should be removed and thoroughly cleaned. Use of an ultrasonic cleaner would make cleaning of hole diameters easier. Inspect all holes for blockage. Blow holes clear with compressed air after some time of soaking in solvent. **DO NOT** use any type of pick to clear the holes. Damage may result to parts and could affect performance of the equipment. If holes are damaged (oversized holes, blockage, gouges) it must be replaced.

RMA-303 PREVENTIVE MAINTENANCE SCHEDULE								
Procedure	Frequency (Maximum)							
	Mid Shift	End of Shift	Weekly	2 Weeks	Monthly	3 Months	6 Months	Yearly
Mid Shift Cleaning • Wipe electrodes • Wipe shroud • Visually inspect cup	X							
End of Shift Cleaning • Wipe electrodes • Wipe shroud • Wipe bell cup down • Change cloth cover		X						
Shaping Air Shroud • Clean inner shape air ring • Clean outer shape air ring • Remove and clean	X	X	X					
Bell cup removal/inspection/ cleaning/tightening		X	X					
Fluid tip inspection/cleaning		X	X					
Inspect Valve and Seat Assembly in valve module for leaking				X				
Replace Valves and Seats in valve module							X	
High Voltage Cable Inspections				X	X			
High Voltage Testing						X		
Regreasing of High Voltage Cables						X		
Check resistance of High Voltage Electrodes						X		
Regreasing electrode cavities of High Voltage Ring and High Voltage Input						X		
Inspect all screws • Replace if broken • Inspect for wear • Tighten per specifications					X			

(Continued On Next Page)

RMA-303 PREVENTIVE MAINTENANCE SCHEDULE (Cont.)								
Procedure	Frequency (Maximum)							
	Mid Shift	End of Shift	Weekly	2 Weeks	Monthly	3 Months	6 Months	Yearly
Inspection of Electrode Tips			X					
Replace Electrodes							X	
Inspection of Tubing Bundle					X			
Regrease Tubing Bundle							X	
Replace Tubing Bundle								X
Replace High Voltage Cable								X
Inspect Turbine Spindle Taper and Threads		X	X					
Replace Bell Cups Replace Splash Plates						X X	X X	X
Inspect and clean Spindle Bore and Fluid Tube OD		X	X					
Check High Voltage Contact area for damage/arcing		X						
Inspect for Fluid Leaks	Daily							
Check exterior of High Voltage Ports for degradation	X							
Check External Cup Flush Carbide Tip for blockage	X	X						

NOTE

- ▶ The outer protective cover may have to be replaced more frequently than weekly. Daily inspection of the amount of paint buildup on the cover will determine the frequency of replacement.

DISASSEMBLY PROCEDURES**NOTE**

- ▶ For re-assembly instructions, use the reverse of the following disassembly procedures.

NOTE

- ▶ To facilitate atomizer removal from hose manifold, a robot program should be made that purges all paints and solvents from the RMA-303. Ideally it would then position the bell assembly in a bell removal position where the bell cup is pointed downward at a 30° angle. Any residual solvents would be contained in the "J bend" of the robot wrist.

NOTE


- ▶ All o-rings described in the "Maintenance" section of this manual should be lubricated with a food grade petroleum jelly or with A11545 lubricant.

Atomizer Removal/Replacement**WARNING**

- ▶ Prior to removing applicator from the robot, the following tasks must be completed:
 - Robot put into E-stop mode, locked, and tagged-out.
 - All fluid passages are cleaned, purged out, and depressurized.
 - Air turned off.

**WARNING**

- ▶ Carefully remove the quick disconnect ring to insure any residual line pressure has been relieved to atmosphere.

**Figure 13: Atomizer Removal from Robot**

Atomizer Removal (See Figure13)

Remove rear split shroud by loosening the flat head retaining screws and pulling the shroud halves away from the atomizer extension. Loosen the high voltage nut (78441-00) that holds the high voltage cable into the curved high voltage tube. Remove the high voltage nut and ferrules from the high voltage cable. Loosen the quick disconnect ring (A11201-00) with the adjustable spanner wrench (76772-00) in a counter-clockwise direction. Pull atomizer away from robot plate while taking care to feed the high voltage cable back through the atomizer.

Atomizer Reassembly

Rear shroud halves must be removed for atomizer reassembly. Insert the high voltage cable through the center hole of the atomizer and feed the banana jack end through the hole in the atomizer extension. Once the cable is through, slide the applicator towards the robot plate and align the two guide pins with the holes in the robot plate. Push the atomizer to the robot plate until both plates are flush. Engage the mounting ring and tighten securely. Remove the curved high voltage tube from the high voltage ring. Slide the high voltage nut and ferrules onto the high voltage cable, then slide the curved tube over the high voltage cable. Leave assembly loose. Insert the banana jack end of the cable into the rear opening in the high voltage ring until it seats firmly. Slide the curved tube towards the high voltage ring and secure in place by tightening the large locknut (A11318-00) by hand. Insure high voltage cable is in place before tightening high voltage nut and ferrule (78441-00) by pushing high voltage cable towards the high voltage ring. Tighten nut and ferrule securely by hand. Reinstall rear shroud halves. Tighten screws 3-5 lbs•in (.34-56 Nm) torque.

Proper high voltage cable installation may be verified by checking probe resistance from electrodes to the end of the high voltage cable per the use of a Yakogawa megohm meter or equivalent. Attach one lead to the end of the high voltage cable and touch the other end to the wire at the tip of each electrode, one at a time. The reading should be per "Chart A". If not, recheck connection in the high voltage ring.

High Voltage Ring Removal/Re- placement

Loosen the high voltage locknut (A11318-00) and pull curved tube from back of high voltage ring. Grasp the high voltage ring and turn counter-clockwise approximately 10-15° until locking pins disengage. Pull ring forward to remove.

To reassemble, insure o-ring on inside diameter of the high voltage ring and on face of atomizer extension are seated properly in their grooves. Lightly lubricate both o-rings with A11545-00 petrolatum jell. Slide high voltage ring onto atomizer body making sure high voltage input is located at the top of the unit. Push firmly until it stops against the atomizer extension and is engaged on the locking pins. Rotate high voltage ring clockwise

NOTE

- Before installing high voltage ring, fill the cavity in the high voltage ring with dielectric grease between the input and the outer diameter).

10-15° to lock ring into place. Some force may be required with a new ring, but a solid lock will be felt when properly installed.

Before installing the curved tube, ensure the outer ring of the high voltage input is filled with new dielectric grease. Reinstall high voltage cable and curved tube and tighten locknut securely by hand. Proper high voltage cable installation can be verified by checking probe resistance from the electrodes to the end of the high voltage cable per use of a Yakogawa megohm meter or equivalent. Attach one lead to the end of the high voltage cable and touch the other end to the wire at the top of each electrode, one at a time. The reading should be per "Chart A". If not, recheck connection in the high voltage ring.

Chart A Probe Resistance Check			
Ring Type	Part #	Resistance Reading	Used At (location)
8 Probe *	A11343-03	133-147 megohms	Above 5000 ft. W/In-Line Resistor
8 Probe	A11343-02	209-231 megohms	Sea Level

* See Note below.

NOTE

► When this electrode assembly is used, you must use the 78442-00 In-Line Resistor Assembly for the 74793-XX RansPak cascade and the 78809-00 ground resistor assembly. The ground resistor assembly is placed between the atomizer ground connection and a true earth ground source.




Figure 16: 78441-00 Ferrule Orientation




Figure 17: Shroud Removal




Figure 14: 78842-00 In-Line Resistor Assembly




Figure 15: 78809-00 Ground Resistor Assembly




Figure 18: High Voltage Cable Installation

HIGH VOLTAGE CONNECTIONS FOR SHIELDED/NON-METALLIC CORE CABLE - A10560-XX

NOTE

- ▶ Remove curved tube (A11691-00) and locknut (A11318-00) to ensure proper grooves are filled with dielectric grease before cable installation (see Figures 16 or 49). Remove and clean any excess grease after assembly.

High Voltage Connection - Cascade End

Insert end of cable (end of cable with the green grounding wire attached) thru compression nut of output tube of RansPak™ cascade (74793-01 or 74793-02) until it bottoms into banana jack receptacle. Tighten compression nut by hand, then tighten 1/2 turn more with a wrench. **DO NOT** over-tighten as this may damage cable.

Secure green wire with yellow stripe (attached to high voltage cable) to any known good earth ground, such as a water pipe, etc., using the attached ring terminal.

⚠ WARNING

- ▶ Arcing/fire hazard exists if ungrounded metal connections (air or fluid) are used in the spray area. Use plastic nonconductive connections, or ensure metal connections are at ground potential.






Figure 19: Atomizer Removal

Bell Cup Removal/Replacement

NOTE

- ▶ The bell cup should always be the first component removed if any maintenance is performed. Following the procedure will minimize the risk of damage to the cup itself.

Using the large open end of the wrench (A12061-00) on the flats of the turbine shaft, carefully hold the outside of the bell cup with one hand while applying a clockwise force to the wrench. The bell cup is a right hand thread and must be turned counter-clockwise to remove. Use latex gloves to obtain a firmer grip on the cup.



HOLD WRENCH BY HAND
AND TURN BELL CUP
COUNTER CLOCKWISE TO

Figure 20: Bell Cup Removal


Place the bell cup in a safe, secure place. Carefully inspect the cup for any damage. If there is any damage to the cup, it must be replaced.



CAUTION

- ▶ Failure to replace a damaged bell cup will cause premature turbine failure. Warranty will not be honored if the bell cup is damaged.

To re-install a cup, position the wrench as shown. Insert a torque wrench into the square in the wrench to approximately 50-70 lbs•in (5.65-7.9 Nm) torque. Hold the cup and tighten the torque wrench in a counter-clockwise direction.



HOLD BELL CUP SECURELY BY HAND.
TURN TORQUE WRENCH COUNTER
CLOCKWISE TO TIGHTEN
TIGHTEN TO 50-70 LBS-IN. (5.65-7.9 Nm)

Figure 21: Bell Cup Installation

NOTE

- ▶ There is a 3-inch center-to-center distance between the bell cup and the 3/8-inch socket square on the wrench. This distance must be factored in when reading the proper torque on the wrench.

Example: A desired true torque is desired using a 9-inch effective length torque wrench. Wrench offset is 3-inches.

L = 9-inches
 TT = 50 lbs•in
 E = 3-inches

DR is dial reading.

$$DR = \frac{50(9)}{9+3} \quad DR = 37.5 \text{ lbs}\cdot\text{in}$$




Figure 22: Effective Length Torque Wrench

Splash Plate Removal

After removing the bell cup from the applicator, put it on a plastic or wood surface to prevent damage to the edge of the cup. Using the splash plate removal tool (A11388-00), insert the small end of the tool into the end of the splash plate assembly. Press the splash plate out. It may be necessary to tap lightly with a hammer.




Figure 23: Splash Plate Removal

Splash Plate Insertion

Turn the splash plate removal tool over and use the large diameter end to press the splash plate back in place by hand. It may be necessary on occasions to use an arbor press to install the splash plate. Press splash plate to a hard stop (see Figure 24).

Care must be taken not to over-press the splash plate assembly into the bell cup. Damage may occur.




Figure 24: Splash Plate Insertion

CAUTION

► Failure to tighten the bell cup in place may cause vibration of the applicator and/or premature turbine failure.

Rear Shroud Removal/ Replacement

Removal

Loosen flat head screws until they are loose. Screws are captured in the shroud and will come off with it as an assembly. Pry the edge of the shroud away from the atomizer extension while pulling it away from it. Repeat for other side.




Figure 25: Shroud Removal

Replacement

Align the cut out notch of the shroud with the high voltage cable access hole of the atomizer extension. Snap into place and tighten all flat head screws to 3-5 lbs•in (.34-.56 Nm) torque.

Shaping Air Manifold, Solvent Tube Removal/Replacement

Removal

Remove the outer shaping air ring by turning it off by hand in a counter-clockwise direction. Remove the fitting, ferrule, and exterior cup wash line from the inner shaping air manifold by turning the fitting in a counter-clockwise direction using a 3/16" end wrench. Loosen set screw on inner shaping air manifold with a 5/64" hex wrench enough to allow manifold to be removed from the turbine body. Remove the inner shaping air manifold by turning it off in a counter-clockwise direction. A 1/4-20 threaded screw may be screwed into the cup wash port to provide additional leverage to remove the inner shaping air ring.




Figure 26: Interior/Exterior Shaping Air
Manifold Removal

Reassembly

(Lightly lubricate all o-rings prior to assembling.) Carefully install the inner shaping air ring onto the turbine threads. Tighten in a clockwise direction until it seats against the turbine. Tighten set screw to 5 lbs•in (0.564 Nm) torque to prevent shaping air ring/manifold from rotating. Do not overtighten! (Use a 5/64" hex key wrench.) If replacing the solvent tube, install into the atomizer body first and tighten with a 3/16" end-wrench. Before installing the other end into the inner shaping air ring, check the position of the 1/4-20 threaded hole. If it is less than 180° from the fitting installed in the atomizer body, you must install a loop (as shown in Figure 26) to prevent tube from becoming pinched when outer shroud is installed. Do not kink the tube when installing loop (granny knot).

Turbine Removal / Replacement

Remove the turbine retaining ring by using the wrench (A12088-00), turning the turbine retaining ring in a counter-clockwise direction. Pull the turbine out while rocking it from side to side.




Figure 27: Turbine Removal

Replacement

Apply a light coating of o-ring lubricant to all the o-rings and the threads of the turbine and turbine retaining ring prior to assembly. Push the turbine down into the cavity in the atomizer body. Align the mark on the turbine with the mark on the atomizer body. Install the turbine retaining ring and o-ring by hand. Use the spanner wrench to tighten an additional 1/8-1/4 turn. (Lightly lubricate o-ring with petroleum jelly.) Check centering of fluid tube. If fluid tube is centered, the turbine is fully seated. If not, check tightness with spanner wrench. If tube is not centered, again remove turbine and check for causes, such as an o-ring fell off, fiber optic not fully installed, foreign material on seating surface, etc. Reinstall and recheck tube centering.

Fluid Tip Removal/Replacement

Removal

To remove the fluid tips, use the tip/tube removal tool (A11229-00). Insert the tool over the tip and engage the four (4) prongs of the tool into the four (4) slots in the tips (see Figures 25 and 26).




Figure 28: Fluid Tip Removal

NOTE

- To remove, turn the tip **CLOCKWISE**. The thread on the tip is **left handed**.




Figure 29: Fluid Tip Replacement

The fluid tip may be removed either with the turbine in place, or the turbine off the unit. Figure 30 shows removing/reinstalling the tip with the turbine in place.

This allows removal and replacement of the fluid tip while the applicator is on line.

Check for leaks.




Figure 30: Reinstall Fluid Tip

Replacement

Ensure the tip openings are fully open and clean. Apply an o-ring lubricant to the o-ring to help hold it in place on the fluid tip. Insert the o-ring into the undercut groove on the tip. Place the tip on the tool and tighten in a **counter-clockwise** direction into the fluid tube. **Do not over-tighten.** There will be a small gap between the flange of the fluid tip and the fluid tube (see Figure 31). Insure the o-ring is properly positioned when complete. Tighten to 25-30 lbs•in (2.83-3.4 Nm) torque.




Figure 31: Fluid Tip / Tube Gap

CAUTION

- ▶ When removing fluid tip while turbine is still installed, make sure to clean paint or fluid that may have leaked or run onto the shaft or threads.

Fluid Tube Removal/Replacement

Removal

Using the fluid tip/tube removal tool (A11229-00), place the pinned end of the tool towards the fluid tube retaining nut and engage the pins into the holes. Turn the tool counter-clockwise to remove (see Figure 32).




Figure 32: Fluid Tube Removal

Replacement

Lubricate all o-rings with a suitable o-ring lubricant. Push the fluid tube into the pocket of the atomizer body. Seat the tube by pushing while rocking the tube from side to side. Install the fluid tube retaining nut over the tube. Tighten the retaining nut firmly tight using the removal tool in a clockwise direction. Tighten to 65-75 lbs•in (7.34-8.47 Nm) torque.

Exterior Solvent Wash Line Removal/Replacement

Occasionally the exterior solvent wash line assembly (A11351-04) will have to be removed and replaced due to kinks or fitting ferrule leakage.

To remove, loosen fitting from valve manifold assembly (A11692-00) using a 3/16" end wrench. Cut the tubing above the fitting. Fitting may be reused, but the ferrule must be replaced.

Loosen the fitting at the shaping air inner ring and the atomizer body. Pull the entire tube through the atomizer body. Again, fittings can be reused, but ferrule must be replaced.




Figure 33: Interior / External Cup Wash Tube Locations




Figure 34: External Cup Wash Tube Route

To reinstall, insert open end of A11351-04 assembly into front of atomizer body and push all the way through. Install ferrule and fitting over tube and install at valve manifold end first! Tighten fitting to a stop, then 1/4 more turn. Next, pull some of the slack out of the line before tightening the next fitting and ferrule into the atomizer body. Tighten to stop and then 1/4 turn more. Next, tighten the remaining end of the tube into the inner shaping air ring. Tighten to stop and tighten 1/4 turn more.

Cup Wash Manifold Removal/ Replacement (Applicator Off Robot)

(See Figures 35 and 36)

Removal

Remove the mounting ring by first removing the break-away ring. Loosen the six (6) 1/4-20 screws (using a flat blade screwdriver) that holds the break-away ring to the rear plate assembly. The break-away ring and the mounting ring will now come off.

Loosen the fiber optic assembly in the rear plate by loosening the set screw with a 3/32" hex key. Pull the fiber optic cable from its hole in the solvent manifold and rear plate assembly. Leave end loose in the atomizer extension.

Using the tubing removal tool (A11373-00), select the appropriate size end for the tube to be removed, 8mm or 6mm. The 8mm end will also fit over the 10mm green turbine air tube. Place the opening around the tube and press down on

the quick release collet. Using your other hand, pull the tubing from the collet. Remove all tubing from the collets. Also, remove the fluid tubes held on with compression nuts.

On the cup wash manifold end, remove the cup wash line from the manifold by unscrewing the 1/4-inch fitting using a 3/16" end wrench. Leave line loose in atomizer extension.

Remove the six (6) 6mm screws holding the rear manifold to the atomizer extension using a 5mm hex key. Slide the rear plate and cup wash manifold assembly out. All the tubing should come with the assembly except the fiber optic and cup wash line.


Replacement:

To replace the cup wash manifold and rear plate assembly, you must have all the tubing in place on the cup wash manifold except the fiber optic and the solvent wash line. Lightly tape the tube ends together to ease installation. Slide the tubing into the atomizer extension, helping the tube make the bend at the front end of the atomizer extension.

Align the locating pin and the rear plate with the locating hole of the atomizer extension. Install the six (6) 6mm socket head screws. Tighten to 15 lbs•in (1.69 Nm) torque (see Figure 35).

Reattach all tubing at the atomizer end, reinstall the fiber optic cable into the rear plate. Tighten set screw to 10 lbs•in (1.13 Nm) torque.

Install the mounting ring onto the atomizer extension, threads facing rearward. Install the break-away ring. Align the four (4) locating dowel pins with the corresponding four (4) holes on the break-away ring. Install the six (6) 1/4-20 stainless steel screws. Tighten to 15-20 lbs•in (17 - 2.3 Nm) torque. If you are using the optional plastic break-away screws, tighten evenly to 5 lbs•in (.56 Nm) torque. The break-away ring must lie flat against the face of the rear manifold.



its hole in the solvent manifold and rear plate assembly. Leave end loose in atomizer extension. Loosen and remove the cup wash line from the manifold by unscrewing the 1/4-inch fitting with a 3/16" end-wrench from the solvent manifold and leave loose in the atomizer extension.




Figure 35: Cup Wash Manifold Removal / Replacement




Figure 37: Fiber Optic Installation/Removal




Figure 36: Cup Wash Manifold Removal




Figure 38: Tubing Removal

Separating Atomizer Body From Atomizer Extension (Applicator off Robot)

(See Figures 37, 38, and 39)

Removal

Remove the mounting ring by first removing the break-away ring. Loosen the six (6) screws that hold the break-away ring to the rear plate assembly (see Figure 39). The break-away ring and the mounting ring will now come off.

Loosen the fiber optic assembly in the rear plate by loosening the set screw with a 3/32" hex key (see Figure 37). Pull the fiber optic cable from




Figure 39: Break-Away Ring

Tubing Removal (Atomizer End) (Reference Figure 38)

Using the tubing removal tool (A11373-00) select the appropriate size end for the tube you want to remove, 8mm or 6mm. The 8mm end will also fit over the 10mm green turbine air tube. Place the opening around the tube and press down on the quick release collet. Using your other hand, pull the tubing from the collet. Remove all tubing from the collets and also remove the fluid tubes held on with compression nuts. Remove the four (4) mounting screws (M8 SHCS) that hold the atomizer body to the atomizer extension using a 6mm hex key.

Reinstalling Atomizer Body Onto Atomizer Extension

NOTE

- It is important that the following procedure be adhered to in order that all tubing and fitting connections can be reached.

Before installing the atomizer body, the fiber optic sensor and cable must be installed as well as the small solvent line for the cup wash. Slide the cable and solvent line into the atomizer extension as you are guiding the atomizer body toward the extension. Rotate the atomizer body and align the "black" locating pin with the hole in the atomizer extension (see Figure 40). The atomizer body will pilot into a hole of the extension. When parts are flush, thread the M8 SHCS into the atomizer body from inside the atomizer extension. Tighten to 25-30 lbs•in (2.82-3.39 Nm). Install the paint and dump lines first. Make sure that the tubing is fully into the fitting before tightening the compression nuts using a 14mm wrench for the paint fitting nut and an 11/16" wrench for the dump fitting nut. It may be necessary to use a wrench on the fitting. Use a 13mm wrench for the 6mm paint fitting and a 16mm wrench for the dump fitting.

Starting with the tubing at the center most of the atomizer body, insert the tubing into the quick disconnect collets. Make sure tubing is fully inserted. (Reference Figures 41 and 42 for proper tubing locations.)

Install the fiber optic cable to the rear plate by going through the hole in the solvent/cup wash manifold.

NOTE

- Make sure fiber optic cable is flush with face of rear plate assembly.

Align the flat on the fiber optic cable with the set screw and tighten to 10 lbs•in (1.13 Nm) torque. Next connect the solvent line from the atomizer body to the solvent/cup wash manifold. Tighten carefully in place.

Slide mounting ring over atomizer extension, threaded end facing towards the rear.

Reinstall break-away ring by aligning the four (4) holes with the dowel pins on the recessed face of the rear manifold. Reinstall the six (6) stainless steel screws. Tighten evenly to 15-20 lbs•in (1.69 - 2.26 Nm) torque. If you are using the optional plastic break-away screws, tighten evenly to 5 lbs•in (.56 Nm) torque. The break-away ring must lie flat against the face of the rear manifold.

Special Note: When replacing the tubing in the atomizer extension, make sure to slide tubing (76998-04 - Item 53) over the paint line (A10841-03 - Item 43) before installing nuts and ferrules onto fittings and tightening. This tubing is required as an extra dielectric shield when the high voltage cable is installed.




Figure 40: Installing Atomizer Body Assembly Onto Atomizer Extension




Figure 41: Atomizer Body Port Identification




Figure 42: Cup Wash Manifold Port Identification

Valve and Seat Removal/ Installation (Cup Wash Manifold)




Figure 43: Weep Port Locations

Inspect weep ports for contamination or other visible leakage around valves. Follow instructions as follows for damage to valves, seats, or performing preventative maintenance.

Using the valve removal tool (A11922-00), engage the four (4) pins on the tool to the corresponding four (4) hole pattern in the top of the valve. Using a 1/2-inch (13mm) socket, end wrench, or adjustable wrench, remove the valve by turning counter-clockwise.




Figure 44: Valve Removal




Figure 45: Seat Removal

Using the seat removal tool (A10756-00), insert the smaller hex end into the block to engage the seat hex. Using a 3/8-inch (10mm) socket, end wrench, or adjustable wrench, remove the seat by turning counter-clockwise.

Valve and Seat Inspection

Inspect the valves and seats for any build-up or leakage of materials. Valves should be cleaned with an appropriate cleaning solvent to remove the material on it.

NOTE

- ▶ A seat should not need to be replaced unless there are indications of valve leakage in operation.

Replacement

Lubricate the o-ring on the seat assembly using a suitable lubricant, then by hand, using the seat removal tool (A10766-00), carefully start the seat assembly into the pocket of the manifold.

NOTE

- ▶ Carefully start the seat assembly into the pocket. It may be easily cross threaded.

Hand tighten the seat in place. Using a torque wrench with a 3/8-inch (10mm) socket, torque the valve seats to 15-20 lbs•in (1.7-2.3 Nm).




Figure 46: Valve Seat Torque

CAUTION

- ▶ Always use a torque wrench to torque the seats in place. Over-torquing the seats may cause permanent irreparable damage to the manifold.

Lubricate the valve o-rings with a suitable o-ring lubricant. By hand, thread the valve into the pocket in a clockwise direction. Tighten using a 1/2-inch (13mm) socket and torque to 15-20 lbs•in (1.7-2.3 Nm) after valve is down.




Figure 47: Valve Torque

Valve and Seat Removal (Atomizer Body End) (Figures 48 and 49)

Removal

Using the valve seat removal tool (A11922-00), engage the four (4) pins on the tool to the corresponding four (4) hole pattern in the top of the valve. Tighten knurled thumb screw and tool to engage 1-2 threads on the valve cap. This will aid in pulling the valve from its bore once it is loose.

Using a 1/2-inch (13mm) socket, remove the valve by turning clockwise until fully unthreaded. Pull the valve assembly from the pocket. Pull valve straight out.

Using seat removal tool (A10766-00), insert the smaller hex end into the valve cavity to engage the seat hex. Using a 3/8-inch (10mm) socket, remove the seat by turning counter-clockwise.

Replacement

Clean seat and valve pocket thoroughly. Lubricate valve pocket, o-rings on seat and valve assemblies with A11545-00 lubricant. Carefully start the seat assembly into the valve pocket. Hand tighten in place. Using a torque wrench with a 3/8-inch (10mm) socket, torque the valve seat to 15-20 lbs•in (1.73-2.3 Nm). Next place the valve onto the four prongs of the valve removal tool and insert into the valve pocket. Tighten by hand as far as possible. Tighten fully using a torque wrench with a 1/2-inch (13mm) socket and torque to 15-20 lbs•in (1.7-2.3 Nm) after valve is down.




Figure 48: Valve Extraction




Figure 49: Valve Extraction

Fiber Optic Cable and Transmitter Removal/Replacement

Removal

Remove the atomizer body from the atomizer extension as discussed earlier.

Remove the fiber optic nut from the inside cavity where the air bearing spindle seats using the fiber optic transmitter tool (78279-00). Loosen and remove nut. Carefully pull out the fiber optic transmitter from the front while pushing the cable from the opposite end. Loosen the black knurled nut holding the cable to the transmitter. Pull the nut off of the cable. The cable can be pulled out from the back side of the atomizer body.

Replacement

To replace, slide the new fiber optic cable through the hole in the back side of the atomizer body until it protrudes well out in front of the body. Slide the black knurled nut over the fiber optic cable approximately 1/4-inch (onto the black portion of the cable). Install the glass fiber portion into the rear of the transmitter until it bottoms. Slide the nut forward and tighten securely. Slide the entire assembly back into the atomizer body. Pull gently from the back side while pushing the transmitter from the front. Slide fiber optic nut over transmitter and tighten securely with transmitter tool (78279-00). Feel transmitter after installation. It should not be loose when properly installed.




Figure 50: Fiber Optic Removal/Replacement

QUICK RELEASE COLLET REMOVAL AND REPLACEMENT (Atomizer Body and Cup Wash Manifold) (Figure 51)

If collet or o-rings become damaged, they can be removed and replaced. To remove the collet, use a flat blade screwdriver or needle nose pliers. If using the screwdriver, lift collet with fingers and place screwdriver blade under the head. Pry up in several places if necessary until removed. If using the pliers, grasp the head between the inside and outside diameter and pull straight out or by pulling with a rocking motion.

Remove the o-ring with a **plastic** pick device. Do not scratch or nick the sealing surfaces.

To replace o-ring and collet, lubricate the o-ring with petroleum jelly and insert into hole and make sure it lies flat on its seating surface. Align the collet with the hole and push straight in. Some collets are tighter than others by design and may require a rocking motion while pushing.

This procedure is the same for all the collets, in the atomizer body, and the cup wash manifold.




Figure 51: Collet and O-Ring Removal/Replacement

Turbine O-Ring Replacement (Figure 52)

Remove air bearing turbine from the atomizer.

Remove all exterior o-rings.

Lightly lubricate all o-rings with A11545 Petrolatum jelly before reinstalling.

Kit A11534-00 contains all required o-rings for replacement.




Figure 52: Turbine O-Ring Replacement

CHECKING PROBES

Check atomizer voltage using the Ransburg Test Meter Kit (76652-01 or 76652-04). Verify that the output voltages have not varied much from the setup standard. A drastic change in voltage can be an early indicator of a component or system problem. The data shown was collected under the ideal lab conditions using a clean atomizer and an unloaded fluid delivery system.

The following data is for use with the RMA-303. The output voltage measured at the bell will normally range between 91% and 97% of the kV set point displayed at the control unit. Typically setting for spraying is 70 kV.

High Voltage Ring Inspection

Examine entire ring for burning marks indicated by melted plastic or blackened areas around or near where the electrodes are located, the area where the high voltage input tube is, and on the inner diameter of the ring.

If any area is found with the above conditions, the ring must be replaced.

After verifying, clean all old dielectric grease from the eight (8) protrusions on the front of the ring and from the concentric circles at the high voltage input protrusion.

Reapply dielectric grease (LSCH0009) to both of these areas. The eight (8) protrusions only require a thin film of grease. The high voltage input area must be filled with grease allowing no air voids. Excess grease will be squeezed out when the input tube and high voltage cable are installed. Wipe off all excess grease.




Figure 53: High Voltage Ring Lubrication

ELECTRODE RESISTANCE TEST

To verify that all indirect charge electrodes are functioning, place one lead of a Yokogama megohm meter or equivalent to the metal contact at the base of the electrode and the other end to the small metal wire at the tip of the electrode. Refer to the "Electrode Assembly Resistance Reading" chart in this section for the proper resistance reading for the electrode assembly.




Figure 54: Electrode Resistance Test

ELECTRODE ASSEMBLY RESISTANCE READING		
Part #	Resistance Reading (Megohms)	Used At (Locations)
A11343-02	209-231 megohms	Sea Level
A11343-03	133-147 megohms	Above 5000 ft.

If reading falls out of this range, disassemble electrode assembly and check reading of resistor only. If reading is in the acceptable range, discard the electrode body (A11342-00) and replace with a new one. Rebuild electrode assembly as follows: apply a small amount of dielectric grease to each end of the resistor, slide resistor into the electrode body (A11342-00). Install the contact assembly after the resistor. Finally, apply a small amount of dielectric grease to contact area of plunger contact assembly. Thread plunger contact assembly into electrode body by hand until it stops. Hand tight is good enough. Over-tightening will damage the electrode body (see Figure 55).




Figure 55: Disassembly / Assembly Electrode Assembly

Before Installing A New or Used Electrode Into the High Voltage Ring
 Replace the dielectric grease in the area as shown in Figure 56. A thin film is all that is required.




Figure 56: Replacing Dielectric Grease

Electrode Tip Inspection

Inspect the electrode tips weekly or sooner. If a collision has occurred, immediate inspection is required. The tip of the electrode should be sharp and pointed. After time, the tip will wear. If the tip is rounded or worn jagged it must be replaced. Depending on use, electrode tips will last 3-6 months. The electrostatic field generated by these electrodes are very important to maintain paint transfer efficiency, pattern uniformity, and atomizer cleanliness.




Figure 57: Inspection of Electrode Tip

OPERATOR / MAINTENANCE

WARNINGS



Do not attempt to hold a rag or a gloved hand against the bell edge to stop or slow down a rotating bell.



Do not attempt to place a high voltage probe on the bell edge unless rotation is full stopped.



Do not attempt to clean the bell edge while the bell is rotating.



Do not reuse an atomizer bell that shows signs of damage such as nicks, heavy scratches, dents, or excessive wear (defined under "Bell Cup Cleaning" in the "Maintenance" section).



Do not attempt to use sharp or abrasive materials to clean the bell, which will scratch or damage the bell.

TROUBLESHOOTING GUIDE

General Problem	Possible Causes	Corrective Action
Bad Spray Pattern	<ol style="list-style-type: none"> 1. Bell cup damaged 2. Low voltage 3. Paint lodged in shaping air ring 	<ol style="list-style-type: none"> 1. Replace bell cup. 2. See "Low or No High Voltage" below. 3. Disassemble and clean (see "Maintenance" section).
Low or No High Voltage	<ol style="list-style-type: none"> 1. High current draw 2. MicroPak controller cascade 3. Improperly mounted air turbine 4. Faulty low voltage connections (usually indicated by MicroPak feedback fault light) 5. Faulty high voltage connection 6. MicroPak or cascade failure 7. MicroPak settings not correct 8. Damaged high voltage cable 9. Dielectric breakdown of high voltage parts 10. Improper color change (i.e., paint or solvent in dump line) 	<ol style="list-style-type: none"> 1. Check resistance of electrodes. 2. Inspect low voltage at the MicroPak and the cascade. <ol style="list-style-type: none"> a. Faulty low voltage cable. 3. Verify ground connection of air turbine to earth ground at less than 1 MΩ. 4. <ol style="list-style-type: none"> a. Make sure quick disconnection electrical connection is aligned and clean. b. Check low voltage connection at cascade. 5. Verify that high voltage cable is fully seated in the cascade and the high voltage ring. 6. Refer to current MicroPak manual for detailed Troubleshooting Guide. 7. Refer to current "MicroPak" manual for detailed "Troubleshooting Guide." 8. Remove and inspect/measure resistance. 9. Check cascade, high voltage ring, and high voltage cable. Replace defective parts. 10. Optimize color change.
Low Transfer Efficiency (or light coverage)	<ol style="list-style-type: none"> 1. Low or no high voltage 2. Poor grounding of parts being coated 	<ol style="list-style-type: none"> 1. Verify high voltage at electrodes. Normally, a high voltage setting of 30-70 kV is appropriate for most applications. 2. Verify that parts being coated are properly grounded (the electrical resistance between the part and ground must not exceed 1 megohm).

(Continued On Next Page)

Troubleshooting Guide (Cont.)

General Problem	Possible Causes	Corrective Action
Low Transfer Efficiency (or light coverage) (Cont.)	3. Excessive turbine speed 4. Excessive robot speed 5. Excessive inner/outer shaping air 6. Excessive target distance	3. For optimum transfer efficiency and spray pattern control, the bell rotational speed should be set at the minimum required to achieve proper atomization of the coating material. 4. For optimum transfer efficiency, spray pattern control, bell speed, and robot speed should be set at the minimum to achieve desired results of part to be coated. 5. Shaping air should be set at the minimum volume required to gently direct the spray pattern toward the part being coated. Excessive shaping air will cause some atomized particles to "blow-by" the part or bounce back onto the atomizer. 6. The recommended target distance is between 6 and 12-inches (152.4-304.8mm) (see "Target Distance" in the "Operation" section of this manual).
No Turbine Air	1. Turbine drive air not present 2. Bearing air return signal not present 3. Brake air is activated	1. Verify supply air pressure. 2. a. Verify bearing air return signal. b. Increase bearing air supply pressure to 90 psig (±10 psig) (620.5 +/- 69 kPa). 3. Remove brake air signal (turbine air and brake air must be interlocked to prevent both from being used simultaneously).
Speed Feedback Fault	1. Damaged fiber optic cable between robot plate and control panel 2. Connection at robot or bell plate is loose 3. Fiber optic transmitter failure 4. Bad transceiver module 5. Excessive vibration	1. a. Repair or replace fiber optic cable.. b. Bad splice connection or too many splices. Maximum three (3) splices permitted. 2. Re-install cable and tighten locking set screw. 3. Replace fiber optic transmitter. 4. Replace transceiver module. 5. a. Check bell cup for damage b. Check bell cup for excessive paint buildup c. Insure bell cup is tightened properly d. Check cup and shaft tapers for cleanliness

(Continued On Next Page)

Troubleshooting Guide (Cont.)

General Problem	Possible Causes	Corrective Action
No Fluid Flow	<ol style="list-style-type: none"> 1. Turbine is not rotating 2. Fluid valve does not actuate 3. Clogged fluid tube/fluid tip 4. Bad transceiver module 	<ol style="list-style-type: none"> 1. Verify rotation of turbine (the paint valve air pilot must be interlocked with the turbine speed feed back signal to ensure that paint does not flow into the air bearing). 2. <ol style="list-style-type: none"> a. Verify that air pilot signal is present. b. Fluid valve air pilot pressure is too low. Increase air pressure to 70 psig minimum. c. Replace fluid valve. 3. Remove and inspect fluid tube or fluid tip. 4. Replace transceiver module.
Continuous Fluid Flow	<ol style="list-style-type: none"> 1. Fluid valve open 2. Fluid valve seat damaged or worn 	<ol style="list-style-type: none"> 1. <ol style="list-style-type: none"> a. Remove air pilot signal. b. If still open, replace fluid valve. 2. Replace fluid valve seat.
Uncontrollable Fluid Flow	<ol style="list-style-type: none"> 1. Insufficient back pressure to fluid regulator 2. Fluid regulator does not control flow (system) 	<ol style="list-style-type: none"> 1. Replace fluid tip with the next smaller inner diameter size. 2. Disassemble fluid regulator and inspect for failed components (system).
Fluid and/or Air Leakage Between the Robot and Bell Manifold Plates	<ol style="list-style-type: none"> 1. Atomizer mounting ring is loose 2. O-ring is missing 3. O-ring is damaged 	<ol style="list-style-type: none"> 1. Tighten mounting ring. 2. Install o-ring. 3. Visually inspect for damage and replace.
Fluid Leakage In Fluid Manifold or Bell Plate	<ol style="list-style-type: none"> 1. O-ring is damaged 2. Fluid tubing not properly installed or tightened. 	<ol style="list-style-type: none"> 1. Replace o-ring. 2. Inspect and retighten.
Fluid Leakage Around Fluid Valve	<ol style="list-style-type: none"> 1. Damaged o-ring(s) on outer diameter of valve body 2. Damaged or worn needle seals inside valve assembly 	<ol style="list-style-type: none"> 1. Replace o-ring(s). 2. Replace valve assembly.

(Continued On Next Page)


Troubleshooting Guide (Cont.)

General Problem	Possible Causes	Corrective Action
Turbine Cannot At-tain Desired Speed	1. Excessive vibration 2. Low or no bearing air 3. Loss of fiber optic/no feed back	1. a. Check bell cup for damage b. Check bell cup for excessive paint buildup c. Bell cup loose - tighten to proper torque d. Check cup and shaft tapers for cleanliness e. Have manufacturing check bell cup balance 2. a. Check bearing air pressure (minimum 80 psi) (352 kPa) b. Check filters for contamination c. Check for bent or damaged bearing air line d. Poor turbine air pressure - plant air e. Damaged speed control cards 3. Damaged fiber optic sensor, bad cable, too many splices. Maximum three (3) slices permitted.
Loss of Exterior/ Interior Cup Wash or Lack of Flow	1. Bent or kinked supply tube 2. No fluid flow 3. Blocked fluid tip or external nozzle. 4. Ferrules holding tubing over-tightened.	1. Replace. 2. Check microvalve, check fluid supply source. 3. Clean parts, remove obstruction. 4. Replace tubing and ferrule assembly.

PARTS IDENTIFICATION

RMA-303 INDIRECT CHARGE ROTARY ATOMIZER MODEL IDENTIFICATION *

When ordering, use A11600-AABBC as indicated by Tables A, B, and C. Five digits must follow the basic part number, for example:



* Model number and serial number of the atomizer is located on the face of the rear plate assembly.

TABLE A - Bell Cup/Shaping Air Style			
Dash #	"A"	"B"	Description
06	A12086-00	A11089-08	65mm Mono Flex, Serrated Titanium (TIS)
07	A12086-01	A12089-08	65mm Mono Flex, Non-Serrated Titanium (TI)
08	A12087-00	A12089-08	65mm Mono FlexI, Serrated Titanium (TISF)
09	A12086-00	A12089-11	65mm Dual Flex, Serrated Titanium (TIS)
10	A12086-01	A12089-11	65mm Dual Flex, Non-Serrated Titanium (TI)
11	A12087-00	A12089-11	65mm Dual Flex, Serrated Titanium (TISF)
12	A12087-01	A12089-11	65mm Dual Flex, Non-Serrated, Titanium (TIF)
13	A12087-01	A12089-08	65mm Dual Flex, Non-Serrated, Titanium (TIF)

TABLE B - Fluid Tip Style		
Dash #	Description - Ø "A"	"E"
01	.028 / .7mm Opening	A11240-01
02	.035 / .9mm Opening	A11240-02
03	.043 / 1.1mm Opening	A11240-03
04	.047 / 1.2mm Opening	A11240-04
05	.062 / 1.57mm Opening	A11240-05
06	.039 / 1.0mm Opening	A11240-06




Figure 58: Fluid Tip Sizes

Table C - Electrode Assembly			
Dash #	"F"	Description	Used At (locations)
1	--	--	--
2	--	--	--
3	A11343-02	8-Probe, 220 Megohm Resistor	At Sea Level
4	A11343-03	8-Probe, 140 Megohm Resistor	Above 5000 ft. Sea Level




Figure 59a: RMA-303 Assembly




Figure 59b: RMA-303 Assembly

RMA-303 ASSEMBLY - PARTS LIST (Figure 59a & 59b)				
Item #	Part #	Description	Qty	Where Used
1	Table C - "F"	Electrode Assembly	8	
2	A12079-00	High Voltage Ring	1	
3	LSOR0005-14	O-Ring, Encapsulated, (2-047)	1	
4	A11318-00	Lock Nut, High Voltage Tube	1	
5	A11691-00	High Voltage Tube	1	
6	Table A - "A"	Bell Cup Assembly	1	
7	78441-00	Ferrule Nut, 3/8" OD	1	
8	Table A - "B"	Shaping Air Kit	1	
9	--	--	-	
10	76566-24C	Screw, 1/4-20 X 3/4" SHCS	3	
11	7683-16C	Break-Away Screw, 1/4-20 Stainless Steel	6	
12	--	--	-	
13	--	--	-	
14	A11081-00	Turbine Assembly	1	
15	A11226-00	Retainer, Fluid Tube	1	
16	79001-42	O-Ring, 13mm ID	1	
17	Table B - "E"	Fluid Tip Assembly	1	
18	79001-40	O-Ring, Solvent Proof	1	
19	79001-41	O-Ring, Solvent Proof	1	
20	A11699-00	Turbine Manifold Assembly	1	
21	A11687-00	Cover	2	
22	A11686-00	Top Cover	1	
23	A11685-00	Atomizer P-Extension	1	
24	LSOR0005-15	O-Ring, Encapsulated, (2-048)	1	
25	A11688-00	Shroud, Right	1	
26	A11689-00	Shroud, Left	1	
27	A11692-00	Valve Manifold Assembly	1	
28	A11693-00	Rear Plate Assembly	1	
29	A11201-00	Ring, Quick Disconnect	1	
30	A11315-00	Break-Away Ring (RMA-303 Indirect Charge)	1	
31	A11690-00	Screw, Captured	8	
32	A11682-00	Screw, Captured	7	
33	A11338-00	Screw, Socket Head Cap, G-10, Fiberglass	4	
34	A10468-20	Screw, Socket Head Cap, Stainless Steel	6	
35	75911-00	Fiber Optic Transmitter Assembly	1	
36	78278-00	Nut, Fiber Optic Tensioning	1	
37	A11351-04	Assembly, Cup Wash Tubing	1	CWA
38	75921-01	Cable Assembly, Fiber Optic	1	
39	A10840-08	Tubing, 6mm OD X 4mm ID, Yellow, Nylon	13 1/4"	BA
40	A10840-09	Tubing, 6mm OD X 4mm ID, Orange, Nylon	12 1/8"	BRK
41	A10839-06	Tubing, 10mm OD X 8mm ID, Green, Nylon	12"	TA
42	A10893-04	Tubing, 8mm OD X 6mm ID, Gray, Nylon	11 3/4"	SAO
43	A10841-03	Tubing, 6mm OD X 4mm ID, PFA, Natural	10 5/8"	PAINT
44	A10841-01	Tubing, 10mm OD X 8mm ID, PFA, Natural	9 7/8"	DUMP
45	A10893-07	Tubing, 8mm OD X 6mm ID, Blue, Nylon	12 3/4"	SAI
46	77536-03	Tubing, 5/32" OD X .106" ID, Green, Nylon	12 3/4"	PT
47	77536-06	Tubing, 5/32" OD X .106" ID, Silver, Nylon	12 3/4"	PD
48	A11351-03	Assembly, Cup Wash Tubing	1	CWA
49	A11245-00	Fluid Tube Assembly	1	
50	79001-44	O-Ring, Solvent Proof	1	
51	79001-45	O-Ring, Solvent Proof	8	
52	A11696-00	Ground Wire Assembly	1	
53	76698-04	Tubing, 1/4" ID X 3/8" OD, PFA, Natural	8"	
54	A11894-00	Fitting, Solvent Y, RMA-303	1	

PARTS LIST BULLET DEFINITION TABLE (Figures 59a and 59b)

- 14 ▶ Slide Item #53 over Item #43 before installing nut and ferrules onto Item #43. After assembly and tightening of nuts and ferrules, slide Item #53 up against nut at rear most portion of atomizer assembly.
- 13 ▶ Lightly coat this area with LSCH0009 dielectric grease. No grease on threads.
- 12 ▶ Torque fluid tube into atomizer body using tool A11229 to 65-75 lbs•in (7.34-8.47 Nm).
- 11 ▶ Torque fluid tip using tool A11229 to 25-30 lbs•in (2.83-3.39 Nm).
- 10 ▶ Tighten set screw in rear plate for F.O. to 5-10 lbs•in (.56-1.13 Nm).
- 8 ▶ Tighten the break-away ring mounting screws, alternately to a final torque reading of 10-15 lbs•in (1.13-1.7 Nm) (stainless steel). Tighten optional plastic screws 3-5 lbs•in (.35-.56 Nm).
- 7 ▶ Tighten bell cups to a final torque of 50-70 lbs•in (5.65-7.91 Nm).

TYPICAL BELL CUP PARTS BREAKDOWN (Figure 60)

Item #	Complete Assembly ①	Description	Cup Only ②	Splash Plate Assembly ③
1	A12086-00	65mm Serrated, 65mm (TIS)	A12069-00	A12071-00
2	A12086-01	65mm Non-Serrated, 65mm (TI)	A12070-00	A12071-00
3	A12087-00	65mm Serrated, 65mm (TISF)	A12076-00	A12071-00
4	A12087-01	65mm Non-Serrated, 65mm (TIF)	A12474-00	A12071-00




Figure 60: Bell Cup Parts Breakdown




Figure 61: Bell Cup Styles




Figure 62: Bell Cup Part Numbers/Styles (Part number is bell cup only - no splash plate included)




Figure 63: A11693 Rear Plate Assembly

A11693 REAR PLATE ASSEMBLY - PARTS LIST (Figure 63)			
Item #	Part #	Description	Qty
1	A11684-00	Rear Plate (RMA-303 Indirect Charge)	1
2	79001-06	O-Ring, Solvent Proof	4
3	77506-00	Medium Air Stud, Machined	4
4	79001-05	O-Ring, Solvent Proof	4
5	77507-00	Small Air Stud, Machined	4
6	79001-39	O-Ring, Solvent Proof	6
7	79001-40	O-Ring, Solvent Proof	10
8	79001-07	O-Ring, Solvent Proof	2
9	77505-00	Large Air Stud, Machined	2
10	SSF-2052	Set Screw, #10-24 X 3/8" Long	1
11	A11694-00	Banana Plug Assembly	1

PARTS LIST BULLET DEFINITION TABLE (Figure 63)

- ▶ Tighten to 5-10 lbs•in (.56-1.13 Nm) torque.
- ▶ Apply a thin film of A11545 lubricant to o-rings before assembly.
- ▶ Apply 7969-10 thread sealer to threads prior to assembly.




Figure 64: A11699 Turbine Manifold Assembly

A11699 TURBINE MANIFOLD ASSEMBLY - PARTS LIST (Figure 64)			
Item #	Part #	Description	Qty
1	A11698-00	Atomizer Body Assembly	1
2	79001-22	O-Ring, Solvent Proof	1
3	----	----	--
4	----	----	--
5	79001-34	O-Ring, Solvent Proof	2
6	77762-04	Collet, 8mm	2
7	77762-02	Collet, 10mm	2
8	79001-31	O-Ring, Solvent Proof	2
9	77762-01	Collet, 6mm	2
10	79001-32	O-Ring, Solvent Proof	2
11	78266-00	Fitting, 10mm AN	1
12	78272-00	Ferrule, Back, 10mm	1
13	78274-00	Nut, Modified, 10mm OD	1
14	78271-00	Ferrule, Front, 10mm	1
15	79001-30	O-Ring, Solvent Proof	2
16	77516-04	Collet, 4mm	2
17	78265-00	Fitting, 6mm AN	1
18	78269-00	Ferrule, Front, 6mm	1
19	78270-00	Ferrule, Back, 6mm	1
20	78273-00	Nut, 6mm OD	1
21	78949-00	Valve Assembly	2
22	77367-00	Valve Seat Assembly	2

PARTS LIST BULLET DEFINITION TABLE (Figure 64)	
4	Apply A11545 lubricant onto all o-rings before installation.
3	Torque to 15 lbs•in (1.7 Nm) after fitting is seated.
2	Torque to 15-20 lbs•in (1.7-2.3 Nm).
1	Torque to 15-20 lbs•in (1.7-2.3 Nm) after valve is down.




Figure 61: A11692 Valve Manifold Assembly

A11692 VALVE MANIFOLD ASSEMBLY - PARTS LIST (Figure 61)

Item #	Part #	Description	Qty
1	A11683-00	Solvent/Air Chop Manifold	1
2	77762-01	Collet, 6mm	2
3	79001-32	O-Ring, Solvent Proof	2
4	79001-30	O-Ring, Solvent Proof	2
5	77516-04	Collet, 4mm	2
6	79001-34	O-Ring, Solvent Proof	2
7	77762-04	Collet, 8mm	2
8	78266-00	Fitting, 10mm, AN	1
9	78272-00	Ferrule, Back, 10mm	1
10	78274-00	Nut, Modified, 10mm OD	1
11	78271-00	Ferrule, Front, 10mm	1
12	78265-00	Fitting, 6mm, AN	1
13	78269-00	Ferrule, Front, 6mm	1
14	78270-00	Ferrule, Back, 6mm	1
15	78273-00	Nut, 6mm OD	1
16	79001-31	O-Ring, Solvent Proof	1
17	77762-02	Collet, 10mm	1
18	78949-00	Valve Assembly	2
19	77367-00	Valve Seat Assembly	2

PARTS LIST BULLET DEFINITION TABLE (Figure 65)

- ▶ Apply A11545 lubricant onto all o-rings before installation.
- ▶ Install valve assemblies as shown. Apply A11545 lubricant onto o-rings. Torque to 15-20 lbs•in (1.7-2.3 Nm) after valve is down.
- ▶ Install valve seat assemblies as shown. Torque to 15-20 lbs•in (1.7-2.3 Nm).




Figure 66: A11351-03/04 Cup Wash Line Assemblies




Figure 67: A12089-08 Shaping Air Kit
(Single Swirl Shape Air)




Figure 68: A12089-11 Shaping Air Kit
(Dual Swirl Shape Air)




Figure 69a: A11678-XXXXX Tubing Bundle Assembly




Figure 69b: A11678-XXXXX Tubing Bundle Assembly

**A11678-XXXXX TUBING BUNDLE ASSEMBLY - PARTS LIST
(Figures 69a and 69b)**

Item #	Part #	Description	Qty	Port Location
1	A11679-00	Robot Mounting Plate	1	
2	77544-01	Male Conector, 5/32" OD X 10-32 THD.	5	PT,PD,ST,AT1,BRG,RTN
3	Table E - "O"	Ground Cable Assembly	1	
4	A11283-00	Solvent Circulation Line Assembly	1	SOL
5	A11258-00	Fitting, 10mm AN	1	DL
6	A11259-00	Fitting, 8mm AN	1	P
7	A10891-03	Fitting, 1/4" BSP X 8mm ODT Straight	2	SAO, SAI
8	A10891-04	Fitting, 1/4" BSP X 10mm ODT Straight	1	TA
9	A10891-02	Fitting, 1/8" BSP X 6mm ODT Straight	3	BRG, BRK, CWA
10	77545-01	Cap, 5/32" OD Tube, Blue Identification	1	ST
11	77545-03	Cap, 5/32" OD Tube, Green Identification	1	PT
12	77545-11	Cap, 5/32" OD Tube, Gray/Silver Identification	1	PD
13	77545-12	Cap, 5/32" OD Tube, Yellow Identification	1	BRG, RTN
14	77545-13	Cap, 5/32" OD Tube, Orange Identification	1	AT1
15	77536-04	Tubing, 5/32" OD X .106" ID, Blue, Nylon	H	ST
16	77536-03	Tubing, 5/32" OD X .106", Green, Nylon	H	PT
17	77536-06	Tube, 4mm OD X 2.7mm ID, Gray/Silver, Nylon	H	PD
18	77536-07	Tube, 4mm OD X 2.7mm ID, Yellow, Nylon	H	BRG, RTN
19	77536-08	Tube, 4mm OD X 2.7mm ID, Orange, Nylon	H	AT1
20	A10839-06	Tube, 10mm OD X 8mm ID, Green	6 Ft.	TA
21	A10893-04	Tube, 8mm OD X 6mm ID, Gray, Nylon	15 ft.	SAO
22	A10893-07	Tube, 8mm OD X 6mm ID, Blue, Nylon	15 ft.	SAI
23	A10840-08	Tube, 6mm OD X 4mm ID, Yellow, Nylon	H	BRG
24	A10840-09	Tube, 6mm OD X 4mm ID, Orange, Nylon	15 ft.	BRK
25	A10840-06	Tube, 6mm OD X 4mm ID, Green, Nylon	H	CWA
26	SSF-2052	Set Screw, #10-32 UNC X 3/8" Long,SHCS	1	----
27	A11260-03	Ferrule, 10mm	1	DL
28	A10841-01	Tubing, PFA, 10mm OD X 8mm ID	H	DL
29	A11260-02	Ferrule, 8mm	1	P
30	A10841-02	Tubing, PFA, 8mm OD X 6mm ID	H	P
31	A11261-02	Nut, 8mm OD, Tube	1	P
32	A11261-03	Nut, 10mm OD, Tube	1	DL
33	Table C - "L"	Fiber Optic Cable	1	FO
34	76566-24C	Screw, 1/4 - 20 X 3/4" Long, SHCS	6	----
35	88010-00	Tape, Black Electrical	A/R	----
36	Table D - "M"	Adapter	1	----
37	Table B - "N"	High Voltage Cable Assembly (Not Shown)	1	----
38	--	----	--	----
39	A11207-06	Cap, 10mm OD Tube, Green Identification	1	TA
40	A11209-06	Cap, 6mm OD Tube, Green Identification	1	CWA
41	A11209-03	Cap, 6mm OD Tube, Orange Identification	1	BRK
42	A11209-05	Cap, 6mm OD Tube, Yellow Identification	1	BRG
43	A11208-08	Cap, 8mm OD Tube, Gray Identification	1	SAO
44	A11208-10	Cap, 8mm OD Tube, Blue Identification	1	SAI
45	A10895-01	Insert, Metric, 10mm	1	D
46	A10895-02	Insert, Metric, 8mm	1	P
47	A10890-02	Fitting, Metric, 8mm	1	GND

7

3

3

3

7

7

7

4

4

4

4

4


11

PARTS LIST BULLET DEFINITION TABLE (Figures 69a and 69b)

- 11 ➤ After installing A11680-00 ground cable assembly, tighten nut to 175 lbs•in (19.77 Nm) torque. Check resistivity from A11679-00 robot plate to ring. Terminal at end of cable must be 10 ohms or less.
- 10 ➤ Apply A11545 lubricant onto face sparingly to prevent galling. Torque to 170 lbs•in max. (19.21 Nm).
- 7 ➤ Apply 7969-031 to threads as required.
- 4 ➤ Install tube inserts fully into tubing before installing tubing into fitting.
- 3 ➤ Apply 7969-10 thread sealer to threads prior to assembly.

A11678-XXXXX TUBING BUNDLE ASSEMBLY MODEL IDENTIFICATION

When ordering, use A11678-ABCDE as indicated by Tables A, B, C, D, and E. Up to five digits must follow the basic part number, for example:



Tubing Bundle Nomenclature	
SAO	Outer Shaping Air (Outer Air)
SAI	Inner Shaping Air (Inner Air)
BA	Bearing Air Supply
BRG, RTN	Bearing Air Return
PD	Dump Trigger
DL	Dump Out
PT	Paint Trigger
P	Paint Supply
ST	Solvent Trigger
SOL	Solvent Supply
TA	Turbine Air Supply
LV	Low Voltage Cable Port
FO	Fiber Optic Cable Port
CWA	Cup Wash Air
ATI	Cup Wash Air Trigger
BRK	Brake Air
GND	Ground Cable

TABLE A Tubing Bundle Length		
Dash No.	Description	"H"
0	Air Tubing (Not Included)	N/A
1	15' Long Tubing Assembly	15 ft.
2	30' Long Tubing Assembly	30 ft.

NOTE:

For lengths above 15 ft., the SA1, SA2, and BRK require the next larger nominal size ID tubing. This tubing is to be supplied by user or integrator.

The turbine air (TA) to be supplied at a maximum length of 6 ft. User or integrator must increase to 12mm OD tube after 6 ft.

TABLE B High Voltage Cable Length		
Dash No.	Description	"N"
0	High Voltage Cable Assy. (Not Included)	N/A
1	High Voltage Cable Assy., Shielded, Non-Metallic Cen. Cond., 15 Ft.	A10560-16
2	High Voltage Cable Assy., Shielded, Non-Metallic Cen. Cond., 20 Ft.	A10560-20
3	High Voltage Cable Assy., Shielded, Non-Metallic Cen. Cond., 25 Ft.	A10560-25
4	High Voltage Cable Assy., Shielded, Non-Metallic Cen. Cond., 50 Ft.	A10560-50
5	High Voltage Cable Assy., Shielded, Non-Metallic Cen. Cond., 75 Ft.	A10560-75
6	High Voltage Cable Assy., Shielded, Non-Metallic Cen. Cond., 100 Ft.	A10560-100
7	High Voltage Cable Assy., Shielded, Non-Metallic Cen. Cond., 100 Ft.	A10560-100

TABLE C Fiber Optic Cable Length		
Dash No.	Description	Part #
0	Fiber Optic Cable Assembly (Not Included)	N/A
1	Fiber Optic Cable Assembly, 3 Ft.	A12409-01
2	Fiber Optic Cable Assembly, 6 Ft.	A12409-02
3	Fiber Optic Cable Assembly, 10 Ft.	A12409-03
4	Fiber Optic Cable Assembly, 15 Ft.	A12409-04
5	Fiber Optic Cable Assembly, 25 Ft.	A12409-05
6	Fiber Optic Cable Assembly, 40 Ft.	A12409-06
7	Fiber Optic Cable Assembly, 50 Ft.	A12409-07
8	Fiber Optic Cable Assembly, 65 Ft.	A12409-08
9	Fiber Optic Cable Assembly, 75 Ft.	A12409-09
10	Fiber Optic Cable Assembly, 100 Ft.	A12409-10

TABLE D Robot Adapter		
Dash No.	Description	"M"
0	Adapter (Not Included)	N/A
1	Adapter (Fanuc P-155, P-145)	78983-00
2	Adapter (ABB 5400, 5002)	79107-00
3	Adapter (Fanuc P-200, 250)	79131-00
4	Adapter (Kawasaki - KE610L)	A10847-00
5	Adapter (Motoman - PX2850)	A10848-00
6	Adapter (Motoman - PX2900)	A10849-00
7	Adapter (B & M LZ2000)	A10851-00

TABLE E - High Voltage Ground Cable Assembly		
Dash No.	Description	"O"
0	None	N/A
1	Cable, High Voltage Ground, 10 Ft.	A11680-10
2	Cable, High Voltage Ground, 25 Ft.	A11680-25
3	Cable, High Voltage Ground, 50 Ft.	A11680-50
4	Cable, High Voltage Ground, 75 Ft.	A11680-75
5	Cable, High Voltage Ground, 100 Ft.	A11680-100

RMA-303 INDIRECT CHARGE RECOMMENDED SPARE PARTS		
Part #	Description	Qty
A11258-00	Fitting, 10mm AN	0-1
A11259-00	Fitting, 8mm AN	0-1
A10891-03	Fitting, 1/4" BSP X 8mm ODT Straight	0-1
A10891-04	Fitting, 1/4" BSP X 10mm ODT Straight	0-1
A10891-02	Fitting, 1/8" BSP X 6mm ODT Straight	0-1
77544-01	Male Connector, 5/32" OD X 10-32 Thread	8-10
A11260-03	Ferrule, 10mm	0-2
A11260-02	Ferrule, 8mm	0-2
A10895-01	Insert, Metric, 10mm	1
A10895-02	Insert, Metric, 8mm	1
A11261-02	Nut, 8mm OD, Tube	0-1
A11261-03	Nut, 10mm OD, Tube	0-1
78441-00	Ferrule Nut, 3/8" OD	0-1
A11305-00	Lower Ferrule, Solvent, Cup Wash	0-1
A11276-00	Fitting, Solvent, Cup Wash	0-1
78266-00	Fitting, 10mm AN	0-1
78272-00	Ferrule, Back, 10mm	1-2
78274-00	Nut, Modified, 10mm OD	0-1
78271-00	Ferrule, Front, 10mm	1-2
78265-00	Fitting, 6mm AN	0-1
78269-00	Ferrule, Front, 6mm	1-2
78270-00	Ferrule, Back, 6mm	1-2
78273-00	Nut, 6mm OD	0-1
77762-01	Collet, 6mm	2-4
77516-04	Collet, 4mm	2-4
77762-04	Collet, 8mm	2-4
77762-02	Collet, 10mm	1-2
A11682-00	Screw, Captured	6
A11690-00	Screw, Captured	8
A11338-25	Screw, Socket Head Cap, G-10 Fiberglass	8
A11337-22	Screw, Socket Head Cap, Stainless Steel	4-6
76566-24C	Screw, 1/4-20 X 3/4" Long, SHCS	4-6
7683-16C	Break-Away Screw, Machined	6
SSF-2052	Set Screw, #10-32 UNC X 3/8" Long, SHCS	1
77536-04	Tubing, 5/32" OD X .106" ID, Blue, Nylon	--
77536-03	Tubing, 5/32" OD X .106" ID, Green, Nylon	--
77536-06	Tubing, 4mm OD X 2.7mm ID, Gray/Silver, Nylon	--
77536-07	Tubing, 4mm OD X 2.7mm ID, Yellow, Nylon	--
77536-08	Tubing, 4mm OD X 2.7mm ID, Orange, Nylon	--
A10839-06	Tubing, 10mm OD X 8mm ID, Green	--
A10839-04	Tubing, 8mm OD X 6mm ID, Gray, Nylon	--
A10893-07	Tubing, 8mm OD X 6mm ID, Blue, Nylon	--
A10840-08	Tubing, 6mm OD X 4mm ID, Yellow, Nylon	--
A10840-09	Tubing, 6mm OD X 4mm ID, Orange, Nylon	--
A10840-06	Tubing, 6mm OD X 4mm ID, Green, Nylon	--
A10841-01	Tubing, PFA, 10mm OD X 8mm ID	--
A10841-02	Tubing, PFA, 8mm OD X 6mm ID	--
A12409-XX	Fiber Optic Cable	1
A10560-XX	High Voltage Cable Assembly	1
A11680-XX	Cable, High Voltage Ground	1
A11283-00	Solvent Circulation Line Assembly	1
76698-04	Tubing, 1/4" ID X 3/8" OD, PFA	6 Ft.
A11252-01	Tubing, 3/38" OD X 1/16" ID, FEP	--

(Continued on next page)

RMA-303 INDIRECT CHARGE RECOMMENDED SPARE PARTS (Cont.)		
Part #	Description	Qty
A11351-03	Assembly, Cup Wash Tubing	1
A11351-04	Assembly, Cup Wash Tubing	1
75911-00	Fiber Optic Transmitter Assembly	1
78278-00	Nut, Fiber Optic Tensioning	0-1
75921-01	Cable Assembly, Fiber Optic	0-1
A11342-00	Electrode Body Only	1-2
A11343-00	Electrode Assembly	1-2
A12079-00	High Voltage Ring	0-1
A11318-00	Locknut, High Voltage Tube	0-1
A11691-00	Bent Tube	0-1
A11081-00	Turbine Assembly	0-1
A11245-00	Fluid Tube Assembly	0-1
78949-00	Valve Assembly	2-4
77367-00	Valve Seat Assembly	2-4
A12071-00	Splash Plate Assembly	1
79001-05	O-Ring, Solvent Proof	5-10
79001-06	O-Ring, Solvent Proof	5-10
79001-07	O-Ring, Solvent Proof	3-5
79001-11	O-Ring, Solvent Proof	1-2
79001-30	O-Ring, Solvent Proof	2-4
79001-31	O-Ring, Solvent Proof	2-4
79001-32	O-Ring, Solvent Proof	2-4
79001-34	O-Ring, Solvent Proof	2-4
79001-39	O-Ring, Solvent Proof	6-12
79001-40	O-Ring, 6.4mm ID	10-15
79001-41	O-Ring, 2.1mm ID	1
79001-42	O-Ring, 13mm ID	1
79001-44	O-Ring, Solvent Proof	1
79001-45	O-Ring, Solvent Proof	1-2
79001-46	O-Ring, Solvent Proof	1
79001-47	O-Ring, Solvent Proof	1
LSOR0005-12	O-Ring, Encapsulated	1
A11534-00	O-Ring Kit (Turbine - Exterior, 5 O-Rings)	1
A12071-00	Splash Plate	1-2
Select Option Below	Fluid Tip Size	
A11240-01	.028" / .7mm Opening	0-1
A11240-02	.035" / .9mm Opening	0-1
A11240-03	.043" / 1.1mm Opening	0-1
A11240-04	.047" / 1.2mm Opening	0-1
A11240-05	.062" / 1.57mm Opening	0-1
A11240-06	.039" / 1.0mm Opening	0-1
Select Option Below	Bell Cup Assembly W/Splash Plate	
A12086-00	65mm Titanium Serrated (TIS)	1
A12086-01	65mm Titanium Serrated (TI)	1
A12087-00	65mm Titanium Serrated Flip Edge (TISF)	1
A12087-01	65mm Titanium Non-Serrated (TIF)	1
Select Option Below	Bell Cup Only	
A12069-00	65mm Titanium Serrated (TIS)	1
A12070-00	65mm Titanium Non-Serrated (TI)	1
A12071-00	65m Serrated Flip Edge (TISF)	1
A12474-00	65mm Titanium Non-Serrated Flip Edge (TIF)	1

(Continued On Next Page)

**RMA-303 INDIRECT CHARGE RECOMMENDED
SPARE PARTS (Cont.)**

Part #	Description	Qty
Select Option Below	Electrode	
A11343-02	Electrode Assembly, 220 Megohm	1-2
A11343-03	Electrode Assembly, 140 Megohm	1-2
Select Option Below	Shaping Air Parts - Shaping Air Kit A12089-08	
A12068-03	Outer Shroud (Mono Flex)	0-1
A12083-02	Shaping Air Ring Assembly (Mono Flex)	0-1
A12078-02	Turbine Retaining Ring (Mono Flex)	0-1
	Shaping Air Kit A12089-11	
A12074-03	Outer Shroud (Dual Flex)	0-1
A12084-02	Shaping Air Ring (Dual Flex)	0-1
A12085-02	Inner Shaping Air Ring (Dual Flex)	0-1
A12066-02	Turbine Retaining Ring (Dual Flex)	0-1
79001-54	O-Ring	1




Figure 70: Assembly Tools

ASSEMBLY TOOLS (Figure 70)		
Item #	Part #	Description
1	76772-00	Wrench, Spanner
2	A12088-00	Wrench, Turbine Retaining Ring
3	A11373-00	Tool, Tubing Removal (RMA-303 Indirect)
4	A12061-00	Wrench, Swirl Bell Cup
5	A11229-00	Tool, Fluid Tip/Tube Removal
6	A11388-00	Tool, Splash Plate Removal
7	A11922-00	Tool, Valve Removal
8	78279-00	Tool, Fiber Optic
9	A10766-00	Microvalve Seat Removal Tool




Figure 71: A11536-00 High Voltage Ring Kit

A11536-00 HIGH VOLTAGE RING KIT - PARTS LIST (Figure 71)			
	Part #	Description	Qty
1	Table A	Electrode Assembly	8
2	A12079-00	High Voltage Ring	1
3	LSOR0005-14	O-Ring, Encapsulated (2-047)	1
4	79001-45	O-Ring	8
5	A11318-00	Locknut, High Voltage Tube	1
6	A11317-00	Bent Tube	1
7	78441-00	Ferrule Nut, 3/8" OD	1

ELECTRODE ASSEMBLY RESISTANCE READING		
Part #	Resistance Reading (Megohms)	Used At (locations)
A11343-02	220 megohms	Sea Level
A11343-03	140 megohms	Above 5000 ft.

LUBRICANTS AND SEALERS	
Part #	Description
A11545-00	Petrolatum Jell Lubricant for all O-Rings
7969-031	Thread Sealant (Blue,) Adhesive 23971
7969-10	Thread Sealant (White), Adhesive 59231, Paste

ACCESSORIES	
Part #	Description
LSCH0009-00	Dielectric Grease (.88 oz. Tube)
76652-01	Kit for measuring high voltage. (Includes Multi-Function Meter (76634-00) and High Voltage Probe Assy. (76667-00).
76652-02	Kit for measuring short circuit current (SCI), resistance, and sprayability. Includes Multi-Function Meter (76634-00) and Test Lead Assy. (76664-00).
76652-03	Kit for measuring paint resistivity. (Includes Multi-Function Meter (76634-00) and Paint Probe Assy. (7922-00).
76652-04	Deluxe Kit (Performs all functions listed above.) Includes Multi-Function Meter (76634-00), Paint Probe Assy. (7922-00), Test Lead Assy. (76664-00), and High Voltage Probe Assy. (76667-00).
A11565-00	White Stretch Lint Free Covers
A11564-00	Foam Elastic Covers (Green)

SERVICE KITS	
Part #	Description
RPM-32	Pre-Filter Replacement Element
RPM-33	Bearing Air Filter Element
74947-06	Cable Assy. (Low Voltage Cable), 30 Ft.
74947-04	Cable Assy. (Low Voltage Cable), 75 Ft.
74947-05	Cable Assy. (Low Voltage Cable), 100 Ft.
74793-01	Cascade RansPak 1000, Right Angle Connection
74793-02	Cascade RansPak 1000, Straight Connection
A11570-01	Reducing Straight Connector, Push To Connect, 6mm OD Tube To 4mm OD Tube
A11570-02	Reducing Straight Connector, Push To Connect, 8mm OD Tube To 4mm OD Tube
A11570-03	Reducing Straight Connector, Push To Connect, 8mm OD Tube To 6mm OD Tube
A11570-04	Reducing Straight Connector, Push To Connect, 10mm OD Tube To 4mm OD Tube
A11570-05	Reducing Straight Connector, Push To Connect, 10mm OD To 6mm OD Tube
A11570-06	Reducing Straight Connector, Push To Connect, 10mm OD To 8mm OD Tube
A11570-07	Reducing Straight Connector, Push To Connect, 12mm OD To 8mm OD Tube
A11570-08	Reducing Straight Connector, Push To Connect, 12mm OD To 10mm OD Tube




Figure 72: A11065-05 Air Heater




Figure 73: A12247-00 Bell Cup Tool




Figure 74: 78842-00 In-Line Resistor Assembly




Figure 75: 78809-00 Ground Resistor Assembly

REPLACEMENT HARDWARE	
Part #	Description
LSFA0004-40C	Screw, 1/4-20 X 1.25", Fillister Head, Nylon
77302-16F	Screw, 10-31 X 1/2", Fillister Head, Nylon
78805-00	Clamp Block
78804-00	Clamp

WARRANTY POLICIES

LIMITED WARRANTY

Ransburg will replace or repair without charge any part and/or equipment that fails within the specified time (see below) because of faulty workmanship or material, provided that the equipment has been used and maintained in accordance with Ransburg's written safety and operating instructions, and has been used under normal operating conditions. Normal wear items are excluded.

THE USE OF OTHER THAN RANSBURG APPROVED PARTS VOIDS ALL WARRANTIES.

SPARE PARTS: One hundred and eighty (180) days from date of purchase, except for rebuilt parts (any part number ending in "R") for which the warranty period is ninety (90) days.

EQUIPMENT: When purchased as a complete unit, (example: guns, power supplies, control units, etc.), is one (1) year from date of purchase. **WRAPPING THE APPLICATOR IN PLASTIC, SHRINK-WRAP, ETC., WILL VOID THIS WARRANTY.**

RANSBURG'S ONLY OBLIGATION UNDER THIS WARRANTY IS TO REPLACE PARTS THAT HAVE FAILED BECAUSE OF FAULTY WORKMANSHIP OR MATERIALS. THERE ARE NO IMPLIED WARRANTIES NOR WARRANTIES OF EITHER MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. RANSBURG ASSUMES NO LIABILITY FOR INJURY, DAMAGE TO PROPERTY OR FOR CONSEQUENTIAL DAMAGES FOR LOSS OF GOODWILL OR PRODUCTION OR INCOME, WHICH RESULT FROM USE OR MISUSE OF THE EQUIPMENT BY PURCHASER OR OTHERS.

EXCLUSIONS: If, in Ransburg's opinion the warranty item in question, or other items damaged by this part was improperly installed, operated or maintained, Ransburg will assume no responsibility for repair or replacement of the item or items. The purchaser, therefore will assume all responsibility for any cost of repair or replacement and service related costs if applicable.

MANUAL CHANGE SUMMARY

This manual was published to supercede Service Manuals **LN-9252-06.3 RMA-303 Robot Mounted Rotary Atomizer Indirect Charge** to make the following changes:

1. Change logo.

Service Manual Price: \$50.00 (U.S.)

Manufacturing

1910 North Wayne Street
Angola, Indiana 46703-9100
Telephone: 260/665-8800
Fax: 260/665-8516

Technical/Service Assistance

Telephone: 800/ 233-3366
Fax: 419/ 470-2071
www.ransburg.com

Technical Support Representative will direct you to the appropriate telephone number for ordering Spare Parts.