


## Kurzanleitung Short Description

## Netzteil / Vibratoransteuerung Power Supply / Vibrator connection

ITW Art.-Nr. 1'007'494



**Input**

- 110VAC-240VAC

**Output**

- 24VDC / Power PP06
- Vibrator Connection 1-phase

**Schalterstellung / Switch Position**

<p><b>I</b></p> <p><b>II</b></p> <p><b>0</b></p> <p><b>I</b></p>	<p><b>ON</b> Vibrator manuell / manual</p> <p><b>ON</b> Vibrator extern</p> <p><b>OFF</b> (Power PP06)</p> <p><b>ON</b> (Powder PP06)</p>
---	--

## Stromlaufplan / Wiring Diagram

